


# **Orca Mini PCI Express Card**


## *User Manual*

## ● USB Driver Installation


1. To install the VIA USB Windows device driver, you must first start the Setup application, **VIA USB Drivers 2.1.5 (32-Bit).exe**, by double-clicking the associated icon.
2. Choose the directory for the application to be installed.



3. Click **Install**, then this setup program will copy all the files into the directories on the local system drive of your PC. The following dialog box will appear upon execution.




4. Click **Finish** when this action has been completed.
5. Power up the notebook which has Shamu PCIe data card installed inside. Then Windows will install all the related drivers automatically. You can find **“VIA Telecom USB Modem”**, **“VIA Telecom AT Port”**, **“VIA Telecom LBS Port”**, **“VIA Telecom Voice Port”** and **“VIA Telecom USB ETS”** in Device Manager.



# ● Dial up Application Setup

## 1. Select “New Connection Wizard”




2. Select Connect to the Internet




3. Select "Set up my connection manually"




4. Select "Connect using a dial-up modem"



5. Enter your ISP name



6. Enter your Number to Dial



**New Connection Wizard**

**Phone Number to Dial**  
What is your ISP's phone number?

Type the phone number below.

Phone number:

You might need to include a "1" or the area code, or both. If you are not sure you need the extra numbers, dial the phone number on your telephone. If you hear a modem sound, the number dialed is correct.

< Back   Next >   Cancel

7. Select Anyone's use



**New Connection Wizard**

**Connection Availability**  
You can make the new connection available to any user or only to yourself.

A connection that is created for your use only is saved in your user account and is not available unless you are logged on.

Create this connection for:

Anyone's use  
 My use only

< Back   Next >   Cancel

8. Enter user name and password



**New Connection Wizard**

**Internet Account Information**  
You will need an account name and password to sign in to your Internet account.

Type an ISP account name and password, then write down this information and store it in a safe place. (If you have forgotten an existing account name or password, contact your ISP.)

User name:

Password:


Confirm password:

Use this account name and password when anyone connects to the Internet from this computer


Make this the default Internet connection

< Back   Next >   Cancel

9. After finishing the configuration, you can set up a connection



**Connect Dial-up Connection**



User name:

Password:

Save this user name and password for the following users:

Me only

Anyone who uses this computer

Dial:

Dial   Cancel   Properties   Help



If Driver is properly installed, you can see “VIA Telecom USB Modem” in the *properties* menu.



- **IMPORTANT NOTE:**

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. As long as these conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end

product (including the transmitter) and obtaining a separate FCC authorization.

#### End Product Labeling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users. The final end product must be labeled in a visible area with the following: “Contains FCC ID: X2U-ORCA-PCIE01”.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.