

# CC2541S BoosterPack Development Kit Quick Start Guide

BOOST-CC2541S is a CC2541S

BoosterPack development kit for the Texas Instrument LaunchPad boards, such as MSP430<sup>™</sup>, Stellaris<sup>®</sup> and C2000<sup>™</sup>. More

information about the LaunchPad is found at

This document will guide you through the initial

steps required in order to run the pre programmed

Bluetooth® low energy Weather Station demo

Introduction

www.ti.com/LaunchPad.

The

application.

Opening the Box and Evaluating *Bluetooth*® Low Energy

# BOOST-CC2541S Kit Content



- 1 x CC2541S BoosterPack
- Documentation

The RF Board in this kit are FCC and IC certified and tested to comply with ETSI/R&TTE over temperature from 0 to +35°C.



Caution! The kit contains ESD sensitive components. Handle with care to prevent permanent damage.

## Weather Station Demo

The Weather Station demo application runs from a MSP430G2553 processor on a Texas Instruments LaunchPad (MSP-EXP430G2). The application uses the WNP to enable a connection with a Bluetooth low energy SMART Ready device and transmit temperature data from the TMP006.

Hardware Setup Attach the CC2541S BoosterPack onto the LaunchPad as follows:



## CC2541S Boosterpack

The CC2541S is a Wireless Network Processor (WNP) and adds Bluetooth low energy support to a system. The WNP includes a complete Bluetooth low energy Host and Controller software stack which is accessed by a Host Controller Interface (HCI) protocol. The HCI protocol can be accessed over either UART or SPI.

The CC2541S is hosted on a BoosterPack board together with a Texas Instruments IR Temperature sensor, TMP006.

The CC2541S BoosterPack supply voltage should be between 2.2V (TMP006 minimum) and 3.6V (CC2541S maximum).

### **Evaluating Weather Station**

# **Additional Tools and Links**

## **BLE E2E Forum**

# **BLE Wiki**

# Useful Links

For additional help, visit the TI Bluetooth low Our BLE Wiki contains application examples,

instant support during your development.

C elebicom/support/low_s									
poly/KeyFebDe 🗋 11 Settiwares MG Ge	nai - Johnspe	er-}- (	) EE 🏘 NT-E	E · Pojectiya	RE	er de Miki			
DEXAS INSTRUMENTS				Winnsheak	funtari s	et) Germani	an I Thomas and	United Street 1 cm	CTL LODGE
Products Products	Design Se	*pport	Semple & D	<i>y</i> •	Al Baardan	depth b	y part number or	keyeard.	1,00
								Sign In with m	
TI E2E <sup>™</sup> Community									. II Loga
o Support Forums - Videos - Blogs o Groups						Search Comma	the strange and the strange	60	
Iptions	1.00		ver RF &	Missian	C	a still like			C Share
Sabetribe via RSS	mahar	the the first	Loss Pepser AT & IND		Gartino of			Can this Ap	t feed
	profiler Field	rea with fai	for anyteen. To	post a quastion, i	the second second	Grunn tail; the	n Theor		
opular Discussions									
rnamic AdvartData spoke									
	. Here	ne []	Aroasoareeta	Forums	Frei	Design N	ites	New P	test (
C2540 bootleader Nich Smar is used by OSALMAL			frequencies				tes	New P	iest
C2540 USB Dongle as a steve C2540 bootinader früh Smar is used by OSAL/HAL antionelky?	Low P	Power R		ow Energy &	ANT Foru			New P	ușt.
C2540 booticader fruh Smar is used by OSALMAL	Low P	Power R	F Bluetooth B L	ow Energy &	ANT Foru			Best P	vol
C2540 bootleader Nich Simer is used by OSALMAL Indionality?	Low P A place	Power R	F Bluetooth B L	ow Energy &	ANT Foru			Best P	ust.
C2540 bootleader Nich Simer is used by OSALMAL Indionality?	Low P A place	Power R	F Bluetooth B L rai discussions an invertied	ow Energy &	ANT Foru			Seat 7	
C2540 bootleader Nich Simar is used by OSAUMAL Indionality?	Low P A place	Power R e for gere cost   5 Tops V	F Blactoothill L r9 december an inverted	ow Energy & . E collaboration on	ANT Foru	n for Skaton			
C2540 bootleader Nich Simar is used by OSAUMAL Indionality?	Low P A place	Fower R e for gene cost   5 Tops V Standard T Data	F Bluetooth B L rai decusions an invertied	ow Energy & . E collaboration on Engle (B.com/bil	ANT Foru TT's solute	n for Skutton Date V O Sep 10	dhit law energy.		teen T
C2540 bootleader Nich Simar is used by OSAUMAL Indionality?	Low P A place	Power R e for pres cent   5 Tops V brown T Dus Diste Texas	F Bluetooth B L rsi Gecutions an invertiad i second theoth LE wilking	ow Exergy &. collaboration on mge (D.comibil .E Stack 1.2.1 ii	ANT Foru TT's solute	Date V O Sete V O Sete 10 Sete 10 S	chill low energy.	Kaplan V	•
C2540 bootleader Nich Simar is used by OSAUMAL Indionality?	Low P A place	Power R e for gene cost ( ) Tops V Tops Tops Tops Tops Tops Tops	F BlactoothB I rsi discussions an inverted internet tooth LE withing instruments Bi iso AdvertData I SC-DEBUGGER	ow Energy &. collaboration on https://t.com/bi E. Stack 1.2.11 update	ANT Foru Ti's soluts e-wilki) Released	n for Skatter Data V O Sector O Sector O Sector Sector Sector	this law snerge.	Kaplan V	111 111

energy E2E forum, <u>www.ti.com/ble-forum</u>, for guides and documentation covering those extra steps you might need help with. The Wiki is not only managed by Texas Instruments employees but also E2E community members. Anyone can share, edit and make use of the information posted here. The Wiki is found at www.ti.com/blewiki.

LaunchPad Product Page: www.ti.com/LaunchPad

CC2541S User Guide: www.ti.com/lit/pdf/swru ####

TI BLE Stack and Software: www.ti.com/ble-stack

CC2540/41 User's Guide: http://www.ti.com/lit/pdf/swru191

CC2541S Product Page: www.ti.com/cc2541S

TMP006 Product Page: www.ti.com/TMP006



Web sites: www.ti.com/ble www.ti.com/ble-forum E2E Forum:

#### **EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS**

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit www.ti.com/esh or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

### **REGULATORY COMPLIANCE INFORMATION**

As noted in the EVM User's Guide and/or EVM itself, this EVM and/or accompanying hardware may or may not be subject to the Federal Communications Commission (FCC) and Industry Canada (IC) rules.

For EVMs **not** subject to the above rules, this evaluation board/kit/module is intended for use for ENGINEERING DEVELOPMENT, DEMONSTRATION OR EVALUATION PURPOSES ONLY and is not considered by TI to be a finished end product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or ICES-003 rules, which are designed to provide reasonable protection against radio frequency interference. Operation of the equipment may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

#### General Statement for EVMs including a radio

User Power/Frequency Use Obligations: This radio is intended for development/professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability of this EVM and its development application(s) must comply with local laws governing radio spectrum allocation and power limits for this evaluation module. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by Texas Instruments unless user has obtained appropriate experimental/development licenses from local regulatory authorities, which is responsibility of user including its acceptable authorization.

#### For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

#### Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

#### FCC Interference Statement for Class B EVM devices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### For EVMs annotated as IC – INDUSTRY CANADA Compliant

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Concerning EVMs including radio transmitters

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### Concerning EVMs including detachable antennas

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada.

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

#### Concernant les EVMs avec appareils radio

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

#### [Important Notice for Users of this Product in Japan]

#### This development kit is NOT certified as Confirming to Technical Regulations of Radio Law of Japan

If you use this product in Japan, you are required by Radio Law of Japan to follow the instructions below with respect to this product:

- Use this product in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
- 2. Use this product only after you obtained the license of Test Radio Station as provided in Radio Law of Japan with respect to this product, or
- 3. Use of this product only after you obtained the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to this product. Also, please do not transfer this product, unless you give the same notice above to the transferee. Please note that if you could not follow the instructions above, you will be subject to penalties of Radio Law of Japan.

#### Texas Instruments Japan Limited (address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan

http://www.tij.co.jp

【ご使用にあたっての注】

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

- 1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
- 2. 実験局の免許を取得後ご使用いただく。
- 3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社 東京都新宿区西新宿6丁目24番1号 西新宿三井ビル http://www.tij.co.jp

#### EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS

For Feasibility Evaluation Only, in Laboratory/Development Environments. Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

- 1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
- 2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
- 3. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
- 4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

**Certain Instructions.** It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

Agreement to Defend, Indemnify and Hold Harmless. You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

Safety-Critical or Life-Critical Applications. If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2012, Texas Instruments Incorporated