NT04 说明书　　尺寸：70x80mm

128G哑粉纸，风琴页，单黑双面印刷

nulaxy

NT04

Nutag

User Manual

Product Overview



① Hanging Hole
② Button
③ Built-in CR2032 Battery
④ Buzzer
⑤ Battery Cover Opening

Quick Instructions

1. Enable the device
a) Activating for the first time:
After activating the battery, the device will emit a series of beeps "didididit~". This indicates that the device is enabled.
b) Enabling after power off:
Press the button once, and the device will emit a single beep "di~". This indicates that the device is enabled.

2. Pair the device
Open the Find My app.
Hold the device close to your iPhone, tap the Items tab, tap +, and then Add Other Item.
Tap Connect.
Type a name for your device, and select an emoji.
Tap Agree to acknowledge that this item will be linked to your Apple ID.
Tap Finish.

3. Enable Lost Mode
Open the Find My app, tap the Items tab, then tap your item.
Under Lost Mode, tap Enable.
Read the instructions, tap Continue, and enter a phone number or email address.
Confirm the information, customize the lost message, and tap Activate to complete the setup.

4. Remove the device
Open the Find My app, tap the Items tab, then tap your item.
Tap Remove Item and then tap Remove to complete the operation.
Note: After removing the device from the app, it will beep; it will not shut down and will be in pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and app cannot be paired now. If you need to pair the device, double-press the device button; the device will beep. At this point, the device enters the pairing state and can be re-paired with the app.

Main Functions

1. Locate your item
If your Apple device isn't nearby, the Find My app can still help you track it down using the Find My network — hundreds of millions of iPhone, iPad, and Mac devices worldwide. Nearby devices securely send the location of your missing devices to iCloud, then you can see where it is in the Find My app. It's all anonymous and encrypted to protect everyone's privacy.

2. Play Sound
Open the Find My app, tap the Items tab, then tap your item.
Click Play Sound, and the device will beep so that you can find the item easily.

Instructions for device button

1. Power on
After installing the battery, the device will beep, and the device will be turned on.

2. The device enters the pairing state again
After removing the device from the app, the device will beep. It will not shut down and will be in the pairing mode. The device will leave the pairing state if there is no re-pairing within 10 minutes. If you want to pair a device now, click the device button once; the device will beep. At this time, the device enters the pairing state and can be paired with the app again.

3. Factory Reset
First, remove the item from the Find My app. Then, after the device is powered on, click the device button 5 times, and hold the button for 3 seconds until the device beep. Release the button (finish the operation in 5 seconds) to complete the factory reset. The device can now be paired.

4. Power off
When the device is on, long press the device button for 3 seconds, and the device will beep "DIDI", and the device will be powered off.

FAQ:

1. When can the device be located?
When an item is separated from its owner for some time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the device's location.

2. How to confirm whether the device has been turned on?
Double-click the device button, and the device will beep "DI," indicating that the device is working. If the device emits a power-on tone, the device was previously off and is now on.

3. How is the device designed to discourage unwanted tracking?
If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified.
Find My will notify your Apple device if you have an iPhone, iPad, or iPod touch. This feature is available on iOS or iPadOS 14.5 or later.

4. How is my privacy protected?
Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. Not even Apple knows who else's device knows your device's location or the device's identity that helps find it.

5. How to replace the battery:
1) Open the device from the notched side.
2) Replace the battery with a new one. (Positive pole upward).
3) Assemble the device, and the device is ready to use.

6. What is the Find My Network? And how does it work?
The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, or Mac. You can also use Find My to locate your Apple Watch or other compatible product with the Apple Find My app to view it alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, including Apple or Nutag, can view its location.

Important tips:

when pairing a device with the Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:
1. Change the phone's network, such as switching between WIFI and mobile network.
2. Factory Reset for the device. when the device is powered on, click the button 5 times, and hold the button for 3 seconds until the device beeps (the same tone as the power-on tone) ，Release the button (finish the operation in 5 seconds) to complete the factory reset.
3. Pair with the Find My app.

Regulatory Safety Information

WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN
Swallowing a coin cell battery can lead to severe injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
If you suspect your child has swallowed or inserted a button battery immediately call the 24-Hour Poison Information Centre for fast expert advice.

KEEP BATTERIES OUT OF REACH OF CHILDREN

Keep in original package until ready to use.
Call a local poison control center for treatment information.
In the U.S., call 1-800-222-1222 (Poison Help)
1-800-451-8911(EN) 1-800-451-8912(FR) 1-800-451-8913(ES) - (Quebec) US: 800-498-8666. Verify suitable emergency call numbers for your country.
Do not use if battery compartment is not secure.
Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.
Risk of fire and burns.
Do not recharge, disassemble, heat (>212°F/70°C) or incinerate.

Rated voltage 3V
Rated current: <15 mAh

Safety Statement

Article12
Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

Article14
The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The low power frequency electric machinery shall be able to tolerate the telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

European Union-Disposal Information
The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Watch, iPad, iPadOS, iPod touch, Mac, macOs, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by TEAM YTO CO., LIMITED is under license. Other trademarks and trade names are those of their respective owners.

Any problem or suggestion, please contact
support@nulaxy.com

FC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirements.
The device can be used in portable exposure conditions without restriction.
NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

24/7

Visit **www.nulaxy.com** for our 24/7 live chat or send an email to **support@nulaxy.com** for support.

MADE IN CHINA

UK	REP	CET PRODUCT SERVICE LTD. Beacon House Stokenchurch Business Park, Bristone Rd, Stokenchurch High Wycombe HP14 3FE,UK **Email:** qxiang.eurups@gmail.com **Phone:** +441491520288
EC	REP	**UAB Qxiang Europe** Pranciškonų g. 6–46, LT-01133 Vilnius, Lithuania **Technical Information Center** Trakehner Str. 7-9, 60487 Frankfurt am Main, Germany **Email:** qxiang.eurups@gmail.com **Phone:** +49697695074