PANEL FUNCTION



1. LED MODE
2. EQ
3. MIC PRI
4. REC
5. LED
6. MIC.IN
7. DC 9V
8. AUX IN
9. USB
10. MICRO SD
11. MODE
12. PREV
13. PLAY/TWS
14. NEXT
15. POWER

PANEL OPERATION EXPLANATION

Warranty

Basic Warranty Statement

Supersonic Inc.("Supersonic") warrants this product to the original purchaser ONLY, to be free from defects in materials and workmanship under normal use, for ninety (90) DAYS from the date of original purchase. Proof of purchase (receipt) required.

Please visit http://www.supersonicinc.com/warranty for additional information.

OPERATION MANUAL

IQ sound®

IQ-7028DJBT

Carefully read operating manual to operate this unit properly, and keep this manual handy for further reference.

FUNCTION DESCRIPTION

● OPERATION INSTRUCTION FOR KARAOKE & WIRELESS MICROPHONE

1. Insert the microphone plug into the microphone input MIC2.
2. Adjust the microphone volume knob MIC VOL for proper volume.Then adjust the echo depth to the proper position. Now you can start the karaoke.
3. Open wired MIC " on & off " button, Adjust the microphone volume knob MIC VOL for proper volume. and adjust the echo depth to the proper position.The you can start the wireless Microphone.

● BT Connection

1.When using the Bluetooth,please tap Settings,then open ''Bluetooth''

2.Scan from your phone,tablet,notebook for "**IQ-7028DJBT**" and pair the device to listen audio files through speaker.

3.Unpair from speaker when finished listenning.

● FM FUNCTION

1.Choose"MODE"to switch to FM radio
2.Choose"PLAY/PAUSE"forautomatic searching and saving.
3.Choose"PREV"and"NEXT"to switch channels.

● Using Microphone

1. When using Microphone-plug your microphone into the microphone jack on unit main control panel .
2. Use the MIC VOL knob to control the voice level of the microphone
3. Use the"ECHO"knob to control microphone echo.

● Using Aux(LINE IN 3.5mm)

1.Press the audio input on unit main panel on the top

2.Insert the Aux cable plug into the Aux input ,then connect with your phone,tablet,notebook for using.

3.Pull out the cable when finished listenning.

● Using Guitar Jack.

1. When using Guitar-plug your guitar into the guitar jack on unit main control panel.
2. Use the Guitar VOL knob to control the volume level of the Guitar.

"BASS"&"TREBLE"on unit control panel can be used to adjust sound when using MICRO SD, USB, FM."EQ" button on unit control panel or remote control can be used to adjust sound effect to preset levels.

● Accessories included package contains

1.Instruction book.....1PC
2.Adapter.....1PC
3.Wired Mic.....1PC
4.Remote control.....1PC
5.Aux Line..... 1PC

● Record Function

press: IN the recording.
press: play the recording and play USB conversion.
REMARK: Need to insert the USB/SD when recording.
When recording the sound from outside (such as the voice of people) need to use WIRELESS MIC / WIRED MIC.
When recording AUX IN no need to use WIRELESS MIC / WIRED MIC just insert USB.

● TWS mode

Switch on the two speakers of the same model (IQ-7028DJBT), press and hold
Press the keyboard play / pause / TWS for a few seconds and connect the two
Put the speakers together Turn on wireless mode in your device (mobile), find
The forum you want to post is a A device Once connected, you can hear it
Your music is on both speakers at the same time

● Charging Instructions

1.The IQ-7028DJBT takes approximately 4 hours to fully charge.
2.The IQ-7028DJBT will automatically begin charging once the adapter is connected to the unit
The unit will also power on when connected to a power source even if the battery power is low.
When the battery is full, the charging indicator light on the front panel will OFF
3.with standard usage, a fully charged battery can play for about 2 hours..

MAIN TECHNICAL PARAMETER

Output power（RMS）:	46W
Output Impedance:	4（ohm）
S/N:	76dB
Input sensitivity:	500mV
Frequency response:	40Hz-20kHz
Rating voltage:	~ 110V-220V 50/60Hz

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20 cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.