Android mobile data terminal

Quick Reference Guide

1.Installation of SIM and TF card

downward

Open the back cover upward

1 Unscrew the fixing nut

2 Open the back cover downward

SIM

TF

### Attention:
To verify the device is shutdown properly when you replace the SIM, TF card or battery. Otherwise, it will cause equipment damage.

3 insert SIM and TF card.

4 put the battery in and put the cover on then screw fixing nut on.

2 Battery charge

power

1 This cell phone can be recharged via USB devices(trickle charge)
2 you can recharge(fast charge) by 5v,1A power adapter.

Attenti...

1 LED display... charge was...
2 We sugges...
3 It needs to... for a longti...
4 To use the...

3 star... and...

1 start-u...

1 Long pres... until the...

2 Restart

Long press the... seconds to res...

---

6 Barcode scanning

Function key for Up or down

Headphone jack

USB socket

SCAN enable barcode scanner

SCAN enable barcode scanner

SCAN enable barcode scanner

ESC use for exit the current application or current operation

Orange buttons use for switch numbers and English letters

Virtual keyboard

HOME to return to the main screen

Power button can be using for power on, off and lock in.

MENU use for bring up function menu of the current application

1 Start bar code scanning

SCAN
SCAN
SCAN

7 Starting WIFI Wi - Fi and 3G data application

1 Open the WiFi wireless network

Access to the Android system setup options, then click [network] operation, start the WLAN and enter WLAN setting, then to select the Wi-Fi network which you need. When the connection is successful the network icon is shown below:

WIRELESS & NETWORKS
WLAN

2 Open the applications of 3G Data

Enter setup options of the Android system ,
to click[network] ,[more],[mobile network],[start data flow]

3G means that currently accessing the 3G network

E means that EDGE is current network

G means that GPRS is current network.

There are three mobile data connections and it depending on your wireless network environment. Access speed of 3G is the fastest among them. Secondly, EDGE . The GSM data access is slowest.

Attention: it will generate traffic expense after connecting to mobile networks; the system will turn off the 3G data applications automatically When Wi-Fi wireless network is connected successfully. This cell phone support for GSM2G network and 3G, please refer to the product model(EEVDO Telecom 3G W WCDMA ChinaUnicom 3G)

9 Funct...

Manageme...

Home - menu
Suggest resett...

Android Mobile T...

Settings   Music   Cale...

OK-Guest user... which the cust...

Guest Permission

Guest Permission

Switch resources repla...
The resource of specified di... card can be replaced to syste...

Home page subtitles a...

| Battery Icon	Description
	Main battery
	State of charge
	Battery run out

AM 11:30

Attention:

1 LED display flashing red when charging, and the LED will normally on when the charge was completed.
2 We suggested to charge more than 12 hours with power adapter when first recharge.
3 It needs to ensure charge and discharge at least once within 2 months if left unused for a longtime.
4 To use the charging equipment which compatible please.

3 start-up, shutdown, restart and restore factory settings

1 start-up

2 To release the POWER key after once vibration

1 Long press the POWER Key, until the device screen is lit

3 It is starting when the startup screen appears

Restart

3 shutdown/Restart

Power off
Reboot
Airplane mode
Airplane mode is OFF

1 Press the POWER button for 2 seconds in the state of power on
2 Click on the " Shutdown " or " restart " button

ng press the POWER button for 7
conds to restart in the state of power on

3 Restore factory settings

Enter "setting" option, click on "personal", click on "restore factory settings"

Attention: all settings you have been made for this cell phone will be restored to the original settings, please operation carefully.

Settings
ACCOUNTS
+ Add account
SECURITY
Security
Location
Factory data reset

Network | My dev... | Personal | More

Factory data reset
You are currently signed into the following accounts:

本机

To clear music, pictures, and other user data, the **SD card** needs to be erased.

☑ Erase SD card
Erase all the data on the SD card, such as music or photos

Reset phone

4 Connect to PC

This device can exchange data with PC through the USB DATA cable. The operation process is as follows:

1 To insert the standard cable of this cell phone into USB port of PC and then insert the other end of the data wire into this cell phone.
2 There will pop up "USB has been connected" on the left top of the screen, to scroll down to connect Icon on the top of the screen, to click the " USB has been connected ".
3 To click " open the USB storage device " on the pops up interface.

5 Operations for touch screen and keys

1 Touch screen

The cell phone has adopted capacitive touch screen. It supports multi-touch and you can operate by slight touch, such as select, click, move, screen zooms in and out, soft keyboard input and other operations.

Attention:
Do not tap the screen with a touch pen; this operation is not valid for capacitive screen and the screen may not have any response when you operation wearing gloves that is normal phenomenon.

Function customization

Management permission

Home - menu - management permissions setting- default password 123456
ggest resetting the administrator password (shall not be less than 6 - bit)

Android Mobile Terminal

Application Ma | Browser | Calculator | Calendar
Camera | Clock | Contacts | Downloads
Email | File Explorer | Gallery | History
LockScreen Sc | Messaging | Music | Note
Sort
Permission Setting

Password input(Limit of 6)
Please input password(Limit
☑Show the password
1	2 ABC	3 DEF
4 GHI	5 JKL	6 MNO
7 PQRS	8 TUV	9 WXYZ
DEL ⌫	0	OK

Default password 123456

K-Guest user permissions (tick)- Guest application settings (tick the program
hich the customer cannot use (Users will not see the selected program)

st Permission
st Permission ✓
ch resources replacement
source of specified directory in the SD
be replaced to system resources.
e page subtitles display

Guest Apps Setting
Application | Browser | Calculator | Calendar
Camera | Clock | Contacts | Downloads

Android Mobile Terminal
Successfully set
Guest permissions
checked by the
user application
system has been

Permission release:

Homepage-menu-management permission settings-enter the administrator password-ok- remove the tick of guest user permission- Guest application settings-remove the tick on the program-save-return

Application Ma | Browser | Calculator | Calendar
Camera | Clock | Contacts | Downloads
Email | File Explorer | Gallery | History
LockScreen Sc | Messaging | Music | Note
Sort
Permission Setting

Guest Permission
Guest Permission ✓
Switch resources replacement
The resource of specified directory in the SD card can be replaced to system resources.
Home page subtitles display ☐
Guest Apps Setting
You can customize the main menu application
Set password for Admini

Guest Apps Setting
Application | Browser | Calculator | Calendar
Camera | Clock | Contacts | Downloads
Email | File Explorer | Gallery | History
LockScreen | Messaging | Music | Note
Save | Cancel

Customize the display text of homepage:

Home page – long press text strip- set text attributes and content - return - to confirm the modification

Android Mobile Terminal
Long press the text strip

Setting
Text content
Android Mobile Terminal
Text size
middle
Scroll speed
normal

Setting
Text content
a Android Mobile Terminal
Text size
Content changed

lies with part 15 of the FCC Rules. Operation is subject to the following two

y not cause harmful interference, and
st accept any interference received, including interference that may cause
on.Changes or modifications not expressly approved by the
for compliance could void the user's authority to operate the equipment.

as been tested and found to comply with the limits for a Class B digital
o part 15 of the FCC Rules. These limits are designed to provide
tion against harmful interference in a residential installation.

enerates, uses and can radiate radio frequency energy and, if not installed
dance with the instructions, may cause harmful interference to radio
However, there is no guarantee that interference will not occur in a
ion. If this equipment does cause harmful interference to radio or
on, which can be determined by turning the equipment off and on, the user
ry to correct the interference by one or more of the following measures:
ate the receiving antenna.
aration between the equipment and receiver.
oment into an outlet on a circuit different from that to which the receiver is

r or an experienced radio/TV technician for help.

Information and Statement:
USA (FCC) is 1.6 W/kg averaged over one gram of tissue.
C ID:2ADXO-MX-5050 has also been tested against this SAR limit.
value reported under this standard during product certification for use on
t the ear is 0.110W/kg and on the body is 0.128W/kg.

Europe (CE) is 2.0 W/kg averaged over one gram oftissue.Device types:
has also been tested against this SAR limit. The highest SAR value
s standard during product certification for use at the Head is 0.118W/kg
s 0.155W/kg.

e warning:
ne earphone maybe possible excessive sound pressure from earphones
can cause hearing loss.

:
xplosion if battery is replaced by an incorrect type.Dispost of used batteries
nstructions.
all only be connected to a USB interface of version USB 1.1.
e installed near the equipment and shall be easily accessible.
mum Operating temperature is 40℃.
nber of the adapter is TS39-502000A and the plug considered as
e of adapter.
arning:
ies with RF specifications when the device used at 1cm form your body.
/EC declaration:
nformity
Technology(ShangHai)INC.} declares that this { Android Moblie Data
t is in compliance with essential requirements and other relevant provisions
5/EC. A copy of the Declaration of conformity can be found at
ytrade.com/ }

6 Barcode scanning

1 Start bar code scanning

To view the scan status icon on the top right of the screen

Scanning has been activated if it is 『　　　　　　　』. Scanning has not activate yet if it is 『　　　　　　』.Need to open it in setting

Start Methods for bar code scanning

Method A: Starting the desktop application [scan setting] 『　　　　　』, General Settings->Bar Code Scanning->on / off√

Method B: to enter the setup option of the Android system, click [scan setting], start bar code scanning

2 Start Scanning

Open any text input box or client application, and you can activate the scanning by press the scanning key on both side.
Please run " Scan Settings " application if you want more barcode scanning settings option.

---

network.

Attention: it will generate traffic expense after connecting to mobile networks; the system will turn off the 3G data applications automatically When Wi-Fi wireless network is connected successfully. This cell phone support for GSM2G network and 3G, please refer to the product model(EEVDO Telecom 3G W WCDMA China Unicom 3G)

8 Care & Maintenance

1 This cell phone can achieve the industrial dustproof and waterproof , and tolerate a certain degree of harsh working conditions but do not use in circumstances beyond this standard for a long term.

2 The working temperature of this cell phone is 20℃-60℃. Just do not use in ultra - low temperature or high temperature environment long term.

3 This cell phone can bear fell down from 12 meters heights for many times. But its touch screen maybe damage in the process of falling down by contact with hard objects directly, and avoid slide down in use.

4 To charge the cell phone with the power adapter in line with national standards. Use our company's standard battery please.

5 Do not make the battery contact with metal objects , as that will cause polarity short circuit of the battery and battery damage temporarily or permanently even explosion.

6 Please avoid red dust - proof piece of the barcode scanner window scratches by sharp objects. Otherwise probably reduce the performance of bar code reading.

Guest Permission

Switch resources repla
The resource of specified dire
card can be replaced to syste

Home page subtitles d

Guest Apps Setting
You can customize the main-
application

Set password for Admi

Permission

ch resources replacement
source of specified directory in the SD
an be replaced to system resources.

e page subtitles display

t Apps Setting
en cuatomize the main menu
ation

assword for Admini

Save   Cancel

Application   Browser   Calculator   Calendar

Camera   Clock   Contacts   Downloads

Email   File Explorer   Gallery   History

LockScreen   Messaging   Music   Note

Guest permissions checked by the user application system has been disabled, and software icons hidden.

Music

Long press the text strip

Settings   Music   Calendar   Browser

Android Mobile Terminal

Text size
middle

Scroll speed
normal

Scroll effect
show and not scroll

Text color

Scroll background transparency

a Android Mobile Terminal

Text size

Content changed

Is apply the modify now?

Cancel   OK

Scroll background transparency