QUICK START

CHARGING

1. Attach the magnetic pins on the charging cord to the magnetic charging ports located on the back of the band (under the heart rate sensor).
2. Be sure the pins are aligned, then insert the other end of the charging cord into a USB port or AC adapter (not included).



BUTTON DIAGRAM

A. **[POWER / BACK]** - ***HOLD*** to Power On/Off. ***Press & Release*** to return to a previous screen

B. **[OK]** - ***Press & Release*** to select options

C. **[UP]** - ***Press & Release*** to scroll. ***HOLD*** while in **Golf Mode** to access Shot Distance screen

D. **[DOWN]** - ***Press & Release*** to scroll. ***HOLD*** while in **Golf Mode** to access Scorecard

To view complete user manual visit: **www.CallawayDMD.com/product-support**

GOLF MODE

1. From **Time Screen**, ***Press & Release*** Ⓐ the **[DOWN]** button twice to display **Golf Mode (A).**

2. ***Press & Release*** the **[OK]** button to select **Golf Mode**.
3. Device will begin searching for satellite signal (***Press & Release*** the **[BACK]** button to cancel).
4. Once satellite connection is established, the nearest golf courses will be listed. Use **[UP / DOWN]** buttons to scroll to desired course, and then ***PRESS*** **[OK]** button to select the course.
5. To end your round, ***PRESS*** **[BACK]** button. Scroll to the desired option then ***PRESS*** **[OK]** button to select.

- **SAVE** - Save your scorecard & exit **Golf Mode.**
- **DISCARD** - Discard your scorecard and exit **Golf Mode.**
- **EXIT** - Return to **Golf Mode.**

FREE APP

Search for **GOLFIT HR** in the Google Play Store™ or **GOLFIT HR** in iTunes™

Note: Compatibility depends on model of Smartphone and version of operating software. Features may vary or could be limited due to compatibility conflicts.

For Apple™: Compatible with iOS 9.0 or above.

For Android™: Compatible with OS 5.0 or above.

*ANDROID IS A TRADEMARK OF GOOGLE INC.

To view complete user manual visit: **www.CallawayDMD.com/product-support**

Callaway GOLFIT HR













Pairing the device

Go to next page if no device found

Show the device when found it













FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.