# SETTING UP THE POOL UNIT

Perform the following steps to set up the Pool Unit:

NOTE: Choose the Pool Unit location based on the **Recommendations for Pool Unit Installation**.

NOTE: The Pool Unit is delivered operational and already paired with the Home Unit. There is no need to turn on the Pool Unit power.

A
Use one of the following options to attach the Pool Unit to the side of the pool:

A1
Verify that the surface is completely dry.

Expose the double-sided sticker and attach it to the side of the pool by applying pressure to remove all air bubbles.

A2
Attach the attachment cone to the side of the pool using two screws (not provided).

A3
Verify that the surface is completely dry.

Use the suction cup to attach the Pool Unit to the side of the pool.

A4
Connect the attachment string to the Pool Unit using the attachment hook, and the other end to any anchor point on the side of the pool.

B
Connect the attachment string between the cone hook and the Pool Unit hook.

C
Place the Pool Unit in the water.

STARTING BCONE

STARTING USING THE APP

Once the Home Unit and Pool Unit are set up, perform the following steps to set up BCone using the mobile app:

A Download the BCone mobile application from Apple App Store

Download on the App Store

or Google Play Store

GET IT ON Google Play

TIP: Scanning the QR code using a mobile device links directly to BCone application download page.

TIP: BCone mobile application works with both Amazon Alexa and Google Assistant.

WORKS WITH amazon alexa

works with the Google Assistant

B Open the BCone application

BCONE
Smart & Simpool

Welcome! Let's set up your new Bcone

Start Set Up

C Start the installation wizard and follow the step-by-step instructions provided

D Verify installation is complete

NOTE: When using BCone without the mobile application, BCone is ready once the Home Unit and the Pool Unit are set up.

OPERATION

This chapter reviews the BCone routine operation and includes:

- **Operation Modes**
- **On Mode**
- **Swim Mode**
- **Adjusting Sensitivity**
- **Turning Alarm Off**

OPERATION MODES

Select one of the following operation modes according to the current use of the pool:

Off Mode – used to turn off the Pool Unit.

On Mode – used when the pool is not being used and there is a need to detect entrance to the pool.

Swim Mode – used when the pool is in use.

ON MODE

On mode is used when the pool is not being used and there is a need to detect entrance to the pool.

Perform the following steps to switch to On mode:

Via the Home Unit

A Press the **On** button

B A green LED indicates that BCone is in **On** mode

Via the Mobile Application

Click to switch to **On** mode

SWIM MODE

Swim Mode is used when the pool is in use. When BCone senses several minutes without activity, it goes back to On mode automatically.

Perform the following steps to switch to Swim mode:

Via the Home Unit

A
Press the **SWIM MODE** button

B
An orange LED indicates that BCone is in **Swim** mode

NOTE: While In Swim Mode the system does not sound an alarm.

Via the Mobile Application

Click to switch to **Swim** mode

TIP: Switching to Swim mode is also possible by taking the Pool Unit out of the water and holding it vertically for a few seconds. The Pool Unit beeps twice to indicate it is in Swim mode.

OFF MODE

Off mode is used to turn off the Pool Unit. In Off mode, the system does not sound an alarm when an entrance to the pool is detected.

Perform the following steps to switch to Off mode:

Via the Home Unit

A Press the **Off** button

B The red LED blinks and then turns off to indicate that BCone is in **Off** mode

Via the Mobile Application

Click to switch to **Off** mode

ADJUSTING SENSITIVITY

BCone sensitivity levels determine the reaction of the Pool Unit to water movement.

The lowest sensitivity level means the Pool Unit sensor is triggered only by sizable waves. The highest sensitivity level means the Pool Unit sensor is triggered by smaller ripples or waves.

The default sensitivity level is 3. Perform the following steps to set the sensitivity level:

A — Select the relevant BCone

B — Tap **Change sensitivity settings**

C — Set the sensitivity

TIP: See BCone mobile application for more features and optional configurations.

TURNING ALARM OFF

When BCone is triggered, the following indicators occur:

The **Home Unit** and **Pool Unit** sound an alarm, and the **mobile application** displays a notification.


The **Pool Unit** LEDs blink red.

The **Home Unit** Alarm LED display blinks red.

After checking the pool and verifying that no one is in danger of drowning, perform one of the following options to silence the alarm:

Swipe the screen on the **mobile application**.

Take the **Pool Unit** out of the water and hold it vertically for a few seconds. The Pool Unit will beep twice to indicate it is in Swim mode.

Press any button on the **Home Unit**.

NOTE: Once the alarm is silenced, BCone switches to **Swim Mode** and automatically turns back on once the pool is calm for several minutes.

SERVICE

This chapter reviews the BCone service and includes:

- **Troubleshooting**
- **Replacing Pool Unit Batteries**
- **Shut Down and Storage**
- **Technical Specifications**

NOTE: Should any issues arise with the home or Pool Unit, contact technical support:

www.lifebuoyalarm.com / info@lifebuoyalarm.com

Toll free US & Canada only: 1800-720-7160

CAUTION: Opening the home and Pool Unit for service or maintenance must be done by qualified service personnel only, with the exception of opening the Pool Unit battery compartment to replace the batteries (see Replacing Pool Unit Batteries on page 24).