Keychron

K2 Bluetooth Mechanical Keyboard

IN THE BOX:

Keychron K2 Bluetooth Mechanical Keyboard x 1
Type-C Cable * 1
Package * 1
User Guide * 1

K2 Bluetooth Mechanical Keyboard Specifications

Mac / Windows



If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions above to find and replace the following keycaps.

Number of keys: 84
Switch type: Mechanical
Number of multimedia keys: 12
Battery: 4000mAh
Working time: 3 - 5 weeks - depending on usage / 20 - 80 hours RGB lighting - varies with brightness and usage
Charging time: Around 6 hours
Charging port: USB Type-C
Mode: Bluetooth/Wired
Bluetooth operating distance: Within 10 meters (open space)
Name of Bluetooth device: Keychron K2
Size: 313.x x 123.x x 38.5mm / 317.x x 129.x x 38.5mm
Weight: 678g / 808g
Operating Environment: -10 to 50°C
Technical specifications can be subjected to change without notice, we apologize for any inconvenience caused.

K2 Bluetooth Mechanical Keyboard Overview

Windows

Mac

① Bluetooth indicator
② Charging port
③ Battery indicator
④ Win/Android Mac/iOS (OS Toggle Switch)
⑤ BT OFF Cable (Mode Toggle Switch)

LED STATUS OVERVIEW

LED Location	LED Color	Function	Status
Battery indicator	Red	Charging	Low battery - blinking Charging - Static Fully charged - Light off
Bluetooth indicator	Blue	Bluetooth	Pairing - fast blinking Paired - light off Switching - slow blinking

FUNCTION DESCRIPTION:

CHARGING

Plug the cable into a USB port and plug the other end into the keyboard port. Charging Indicator:
When the battery level is below 15%, the indicator will show red blinking light. A red light will stay on while charging; The red light will stay on while charging and it goes off after 6 hours when keyboard is fully charged.
*The Keychron keyboard is compatible with all USB ports. Please use a 5V 1A adapter and USB 2.0 or 3.0 for the best performance. The Keychron K2 can be charged in Bluetooth/on/off mode.
** This product supports up to 5V charging voltage and 1A charging current. We are not responsible for any problems caused by improper charging.

BLUETOOTH/WIRED MODE (TOGGLE SWITCH)

WIRED MODE

1.Switch the toggle switch to Cable option (it only works when a USB cable is plugged in).
2.Connect our cable with your PC and keyboard.
3.Backlit will be turned on.
*Under Wired Mode, keyboard will not enter into Battery Saver Mode.

BLUETOOTH MODE

1. Switch the keyboard to Bluetooth option.
2. Backlit will be turned on.
3. Hold "Fn+1" key for 3 seconds to activate Bluetooth pairing (the Bluetooth indicator fast flashes for 3 minutes to detect pairing. Notes: the Bluetooth indicators are located under these keys - "1", "2", "3").
4. Search for the Bluetooth device "Keychron K2" on your device and connect it (the Bluetooth indicator goes off after successful pairing).

Note: This keyboard supports pairing up to 3 devices simultaneously via combination key
"fn" + "1" / "fn" + "2" / "fn" + "3". Simply short press combination keys "fn" + "2" / "fn" + "3" to switch. Follow the above procedures to connect with other devices.
*The Bluetooth indicator will continue to flash for 3 minutes.
**Slow or failed connections may exist due to different Bluetooth versions, please make sure all the settings are correct.*

SWITCH BLUETOOTH DEVICES

Short press combination key "fn" + "1" / "fn" + "2" / "fn" + "3" to switch to other device.

Reconnect:

1. Switch the keyboard to the Bluetooth option to activate the keyboard (the keyboard will connect to the last connected device by default).
2. The Bluetooth indicator flashes for 3 seconds and automatically pairs with the last paired device.
3. If the Bluetooth indicator is off, press any button to enter the connection again.
* The keyboard must have been paired with the device to perform this function.

Turn off the Keyboard

Switch to "OFF"

BATTERY SAVER

Under Bluetooth mode, the keyboard backlight turns off when it is inactive for 10 minutes. Tap any button to wake the keyboard. It want to disable this auto battery save mode, press Fn+S+O for 4 seconds. Then if want to enter this power save mode again, press Fn+S+O for 4 seconds.

BACKLIT SETTING

- Short press [ ] to switch between different types of lighting effects.
- When backlit is on, press [ ] button to switch among them. Short press fn and "left arrow" or fn and "right arrow" to adjust light colors. (For RGB version only)

OS SWITCH

1–MAC/iOS

Turn the switch to Mac/iOS when you are connected to a Mac or iOS operating system.
To use multimedia keys, simply press F1 to F12.

2–WINDOWS/ANDROID

Switch the toggle to Windows/Android when the keyboard is connected to a Windows or Android operating system. To use multimedia keys, simply press "fn" and F1 to F12.

"When using the Windows/Android mode, [ ] [ ] keys are used for "Windows" and "Alt" functions.

3–INPUT METHOD SWITCH

For iOS:
Input method switch: Ctrl + Space
Caps Lock: Caps (Enable General>Keyboards>Hardware Keyboard>Caps Lock Language Switch)

For Android:
Input method switch: Shift + Space

NOTE: Functions of certain multimedia key may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS. We also recommend not to switch OS frequently as it may impact keyboard operations.

MULTIMEDIA FUNCTION



[1] In macOS, multimedia keys have been set as default, simply press fn+function key to use the function of F1~F12. In Widows OS, the function of F1~F12 have been set as default, simply press F1~F12 key to use the function of F1~F12, press fn+function key for the multimedia keys function.
Press fn+X+L simultaneously for 4 seconds to switch the function between the F1~F12 function and the multimedia keys. Then, you need to press the fn key to use F1~F12 function. (Notes: fn+X+L function only works in Widows OS, this doesn't apply to MacOS and other operating systems.)

TROUBLESHOOTING

If unable to pair keyboard to device, confirm that the device you're trying to pair with is Bluetooth-capable. If so, restart the device and try pairing it with the keyboard again.

Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates—a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (HID profile).

Go to Bluetooth Devices > Open Settings and select the following:
Allow Bluetooth devices to find this computer
Allow Bluetooth devices to connect to this computer
Alert me when a Bluetooth device wants to connect

My keyboard isn't working.
For the keyboard: Turn the keyboard off and back on.
Turn Bluetooth off and restart the computer. (Windows)
For the device:
Go to Bluetooth settings and turn off Bluetooth and "forget" the keyboard.
Restart the device and turn on Bluetooth to reconnect.

Bluetooth connection is interrupted even within 10 meter.
Check if the keyboard is resting on a metal surface that can interfere with the Bluetooth signal.

Third party input tools are not compatible with the keyboard.
Due to compatibility, versions, brands and drivers of Windows/Android OS, functions of third party input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

Certain fn keys or multimedia keys does not work under Windows/Android mode.
Functions of certain multimedia keys may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS.

Safety Precaution:
Keep the product, accessories and packaging parts out of reach of children to prevent any accidents and choking hazards.
Always keep the product dry to avoid corrosion.
Do not expose the product to extreme temperatures below -10°C (5°F) or above 50°C (131°F) to preserve the lifespan of the keyboard and battery.

COMPLIANCE AND SAFETY
FCC DECLARATION OF CONFORMANCE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

·Reorient or relocate the receiving antenna.
·Increase the distance between the equipment and receiver.
·Plug the equipment into an outlet on a circuit different from that to which the receiver is currently using.
·Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Keychron
K2 藍牙機械鍵盤規格

注意事項
請勿將水弄濕。如果將液體灑在裝置或裝置可能被暴露在液體中，請先關閉電源，拔掉電源線，然後擦乾。
請勿將產品保持在潮濕、髒污環境。
請勿將產品暴露在溫度低於0°C 或高於 50° C 的機械環境下。已損壞鋰電池等機械環境造成的危險事故。

模擬測試安全
關於連接設備兼容性問題說明
本裝置符合無線通訊設備檢測規則第 15 部分。本裝置已經過測試，符合第二類數字裝置的限制。這些限制旨在提供合理的保護，防止在住宅安裝中的有害干擾。本裝置會產生和使用射頻能量，如果不按照說明進行安裝使用，可能會對無線通訊造成有害干擾。

但是，無法保證在特定安裝中不會發生干擾。如果此裝置確實對無線電或電視接收產生有害干擾（通過關閉裝置確認），建議用戶採取以下一種或多種措施來正干擾：

* 重新調整接收或移動天線
* 增加裝置與接收器的距離
* 將裝置連接到與接收器連接的電路不同電源插座上
* 諮詢經銷商或有經驗的無線電/電視技術人員尋求協助

裝置已經過評估，符合一般無線電暴露等級出要求。該裝置可在受無限的情下使用，不受限制。

內容清單：
Keychron K2 藍牙機械鍵盤*1
Type-C 充電線*1
包裝盒*1
使用指南*1

K2 鍵盤規格
功能：
背光： 單色三段調整
多媒體鍵數： 12
電池： 4000mAh 可充電電池
工作時間： 3 - 5 週 - 根據使用狀況 / 20 - 80小時 RGB 照明 - 隨亮度與使用情況變化
充電時間： 約 6 小時
充電接口： USB Type-C
連接方式： 藍牙 / 有線
藍牙連接距離： 最大 10 公尺（開放空間）
藍牙裝置名稱： Keychron K2
尺寸： 313.x x 123.x x 38.5mm / 317.x x 129.x x 38.5mm
重量： 678g / 808g
使用環境： 10 ~ 50° C

K2 鍵盤概述



功能說明

功能	LED 顏色	LED 位置	狀態
充電	紅色	電源指示燈	閃爍 - 低電量 充電 - 長亮 滿電 - 熄滅
藍牙	藍色	藍牙指示燈	快閃 - 配對 慢閃 - 連接成功 慢閃 - 切換
大寫	綠色	Caps Lock	長亮 - 大寫
背光燈	RGB 白色	- -	19 種效果 17 種效果

充電
將連接線插入 USB 接口，並連接鍵盤。
充電指示燈：電池電量低於 15%，紅色電池指示燈快速閃爍；充電時，紅色指示燈恆亮；4 小時完成充電，指示燈熄滅。

*K2 鍵盤相容所有 USB 接口，要獲得最佳的鍵盤效果電腦，建議使用 5V 1A 變壓器以 USB 3.0接口。
*可在藍牙/有/關機狀下充電。
*有線模式下，充電指示燈不會熄滅
**本產品最高支援 5V 電壓，1A 電流；因不當充電產生損壞將無法提供保固服務。

常用模型
預設 燈光模 可以調整 17/19 種變化。
單次按鍵模式下，按住 Fn + 左 / 右方向鍵可調整背光亮度。
按住可增加或減少亮度，亮度上下的每個調整階段。

藍牙 / 有線模式
有線模式
1. 將滑動開關 Cable 位置（未連結時無反應）
2. 連接線與藍牙電腦與鍵盤
3. 背光燈將會開啟。
*有線模式下鍵盤不會進入省電模式。

藍牙模式
1. 將滑動開關 BT 位置
2. 開啟背光
3. 長按「Fn+1」3 秒開啟藍牙配對（藍牙指示燈閃爍 3 分鐘）
4. 在裝置上搜尋藍牙裝置 "Keychron K2" 並連接（藍牙指示燈熄滅，注意：長按「Fn+ 1/Fn + 2/ Fn + 3」 可同時最多配對 3 組裝置。
如何上述步驟配對其他裝置，配對指示燈同樣快速閃爍 "Fn + 2 / Fn + 3」 即可切換不同裝置。
*本款多裝置配對最長時長，但已配對可能有連線速度慢或失敗，請確保所有的設置都正確。

切換配對裝置
短按 "Fn + 1/Fn + 2/Fn + 3"，可快速切換到不同裝置。
**切換連線可能會因為裝置或藍芽的兼容問題，此時請耐心等待或重新切換。

回連
1. 將滑動開關至 Bluetooth 位置，將藍牙自動回連上次的裝置。
2. 藍牙指示燈會快閃 3 秒，自動連回裝置。
3. 如配對指示燈熄滅，可按任一按鍵進入回連狀態。
**只能回連已配對裝置

睡眠模式
閒置兩個小時，自動切換至睡眠模式。

省電
鍵盤有名長閒置 10 分鐘後關閉，點擊任一按鍵可喚醒鍵盤。省電後低於 15% 電源指示燈將持續綠燈進行充電。

系統切換
1 – mac / iOS
連接到 mac / iOS 系統，將開關 至 mac / iOS 位置，按下 F1-12 可直接使用多媒體鍵。
*在 mac / iOS 系統模式下，關於 numclear 鍵功能為 Clear，不能被重新賦予鍵義。

2 – Windows / Android
連接到 Windows / Android 時，開關至 Windows / Android 位置。
如需要使用多媒體鍵，同時按 Fn + F1-12 即可使用。

3 – 輸入法切換
iOS
輸入法切換：Ctrl + Space
大寫鎖定：Caps

關於 Android
輸入法切換：Shift + Space
注：由於 Windows / Android 的兼容性，版本、品牌和驅動程式，某些多媒體鍵可能不能使用。我們建議不要頻繁切換操作系統，因為有關鍵操作錯誤性。

多媒體功能
鍵盤功能鍵說明

F1
F2
F3
F4
F5
F6
macOS
iOS
Windows
Android
降低螢幕亮度
降低螢幕亮度
降低螢幕亮度
降低螢幕亮度
提高螢幕亮度
提高螢幕亮度
提高螢幕亮度
提高螢幕亮度
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
F7
F8
F9
F10
F11
F12
macOS
iOS
Windows
Android
播放 / 暫停
播放 / 暫停
播放 / 暫停
播放 / 暫停
下一首
下一首
下一首
下一首
靜音
靜音
靜音
靜音
降低音量
降低音量
降低音量
降低音量
提高音量
提高音量
提高音量
提高音量
Insert
Delete
Home
End
Page Up
Page Down
macOS
iOS
Windows
Android
Delete
Delete
Home
Home
End
End
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-
-