Manual of Alarm Clock Night Light Wireless Charger

Model: SY-W0241

I. Function Button

Hour display

Minute display

Night light

M button

"+" button

"-" button

Upper double dots: Second indicator

Lower single dot: Alarm indicator

Wireless charging area

Wireless charging indicator

Type-C power connection port

Night light button

USB-A output

II. Function

A. Power Connection
1. Plug the USB-A end of cable into the power adapter while plug Type-C end into the product.
2. The product will be ready and stand by after all indicators are on.

B. Wireless Charging
1. Output: 10w
2. Indicator display:
   Power connection successful - blue light flashes twice
   Standby – light off
   Charging – blue light on
   Charged – light off
   FOD – blue light flashes continuously

C. Alarm Clock Function
1. Buttons: M, +, -, night light button.
2. Time System Setting:
   Double click M button to setup 12-hour time system and 24-hour time system. AM and PM will display while 12-hour time system is set.
3. Time Setting:
   1) Click M button once to enter minute setting, adjust value with +/-.
   2) Click M button once after minute setting, to enter hour setting, adjust value with +/-.
   3) Click M button a third time to finish time setting.
4. Alarm Setting:
   1) Press "+" 3 seconds to activate Alarm; Press "-" 3 seconds to deactivate Alarm. Alarm indicator is on while Alarm is activated.
   2) While activated, press M button 3 seconds to enter alarm minute setting, adjust value with +/-.
   3) Click M button once after alarm minute setting, to enter alarm hour setting, adjust value with +/-.
   4) Click M button a third time to finish alarm time setting.
   5) Alarm bell rings 3 minutes until automatic off while no any operation.
   6) Tap product to enter Sleepy Mode when bell rings. Bell rings for two more times after 5 minutes. The indicator flashes and M button is out of function during the Sleepy Mode. If time setting is needed, please long press "-" to stop alarm. All buttons will function normally.
   7) Time display brightness is automatically adjusted by 3 grades. Max brightness during 7am-5:59pm. Mid brightness during 6pm to 11:59pm. Min brightness during 12am-6:59am.
   8) Time display brightness can also be adjusted manually to 3 grades. "+" and "-" can be used to adjust display brightness manually. The default grade is max brightness when power is connected. Single click "-" to dark the display one grade. The display brightness goes dark for the last grade and go bright automatically 7am next day. All manual adjustment will be synchronized to automatic adjustment.
   9) If do not need alarm clock ,click any button of the products to stop the bell and close alarm clock.
5. Night Light Setting:
   1) Night light brightness can be adjusted by 3 grades.
   2) Click the round button on left side of product to turn on the night light. The default brightness grade is mini brightness.

3) Click again to get mid brightness. Click a third time to get max brightness.

4) Click the round button a forth time to turn the night light off.

6. Eco-power function:

   1) Button cell inside is only for time keeping.

   2) All functions are out during power disconnection. Functions restored when power is connected.

D. Note

1. **Attention:** In order to function alarm, wireless charging, night light and USB output all together, power shall be connected by a QC2.0 or QC3.0 adapters. If connected by a 5V adapter, only wireless charging and alarm can work together.

2. Do not squeeze or collide.

3. Do not disassemble or put into the fire, water, to avoid short-circuit leakage.

4. Do not use wireless chargers in severe high temperature, humidity or corrosive environments to avoid leakage of damaged circuits.

5. Do not place too close to magnetic cards (ID cards, bank cards, etc.) with magnetic strips or chips to avoid magnetic card failure.

6. Keep more than 20cm between the implanted medical device (pacemaker, implantable cochlea, etc.) and the wireless charger to avoid potential disruption to medical devices.

7. Keep children from the product in case they play the wireless charger as a toy to avoid accidents.

8. Keep the wireless charger and receiver device away from water and other liquids.

9. To clean the charger, make sure the power supply is disconnected.

10. Usage temperature: 0-45℃.

11. Usage humidity: 20-85% (40℃)

* Pictures in this manual are all illustration. Final product is subject to fact.

* Inside package: alarm charger, charging cable, manual.

* power adapter is not included. Please purchase otherwise or use phone original adapter.

III. Specificaiton

Input: 5V/2A, 9V/1.67A

Output power: 10W (MAX)

Charging efficiency: 73%

Charging distance: ≤8mm

Size: 140x100x75mm

IV. Applicable Equipment

Products qualified with Qi standard.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void theuser's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received,including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator &you body.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuantto part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.