Wireless Range Extender 3 — Mobile phone setup 2.4G

1 Plug in your wifi extender and wait for 30s

Until the lights(2.4G) both on means able to start setting

* If Abnormal, please reset:
Press and hold the "Reset/WPS" or "Reset" key for 8 seconds and then release it. Wait until the 2.4G lights are on to indicate a successful reset.

2 Connect your extender SSID

Both are available

wifi-2.4g-xxxx
wifi- -xxxx

* NOTE:
Please remember to turn off your mobile network data. You have no access to Internet until you finish all setting steps, If your phone prompts that the network cannot be connected, click to continue

3 Open your browser webpage
(Google&Firefox Browser Recommended)

* NOTE:
Pls open the browser, entering 192.168.188.1 in the address bar and visit. If access fails, please check if the correct SSID(wifi -xxxx) is connected and the mobile data of the phone is turned off.

192.168.188.1
admin

4 Enter the default password: admin

REPEATER

Login Password
admin

5 Scan and select your host router to connect

Please select the main route to be extended

WIFI6
sohowifi
wifi, ,7755!C
meshhh6

Scan

6 Enter the password of your host router

Please enter the password of the host route
Wireless Name
sohowifi
Wireless Password

Back   Next

* NOTE:
Pls make sure of the right password
(special characters are not allowed,like ~,",blank,<,>)

7 Set your Extender SSID and password

Default SSID:
original SSID-pro-2.4G can be changed

Default router password

Please enter repeater wireless password
Wireless Name 2.4G
sohowifi-pro-2.4G
Wireless Password

Back   Next

* NOTE:
If you don't want to modify, you can proceed to the next step.

8 Check again and confirm the wireless information

Wireless Info:
Host Router Name   sohowifi
Extender Name 2.4G   sohowifi-pro-2.4G
Extender Name   sohowifi-pro
Extender Password   abc123321

* NOTE:
After check,click "Start Connect " and wait 30-60s, the extender will connect to the router

9 Wait for the repeater to connect to the router successfully.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the relay is successful. Please connect sohowifi-pro-2.4G/sohowifi to the Internet! otherwise reconnect.

Please wait 47 seconds

10 The "Extender" indicator lights on means successful connection.

*NOTE:

or   Extender

11 Reselect and reconnect to your extender wifi

sohowifi   wifi-2.4g-xxxx
Before
After
sohowifi   sohowifi-pro-2.4G

Re-select and reconnect to your extender wifi hospot
(The new wifi name defaults to the original wifi name plus pro-2.4G


Wireless Range Extender 3 — PC setup step 2.4G

1 Plug in your wifi extender and wait for 30s

Until the 2 lights(2.4G) both on means able to start setting

* If Abnormal, please reset:
Press and hold the "Reset/WPS" or "Reset" key for 8 seconds and then release it. Wait until the 2.4G lights are on to indicate a successful reset.

2 Connect your extender SSID

Both 2.4G

* NOTE:
Please remember to turn off your mobile network data. You have no access to Internet until you finish all setting steps, If your computer prompts that the network cannot be connected, click to continue

sohowifi
wifi- -xxxx

ENG

3 Open your browser webpage
(Google&Firefox Browser Recommended)

* NOTE:
Pls open the browser, entering 192.168.188.1 in the address bar and visit. If access fails, please check if the correct SSID(wifi- -xxxx) is connected.

192.168.188.1
Google

4 Enter the default password: admin

Login
User Name   Admin
Password   admin

Login

5 Scan and select your host router SSID

Please select the main route to be extended

Choose your host router and enter the router wifi password.
Both wireless of 2.4G can be extended choose only one of the two each time.

6 Enter the password of your host router

Please enter the password of the host route
Wireless Name   sohowifi
Wireless Password
Show Password

Back   Next

* NOTE:
Pls make sure of the right password
(special characters are not allowed,like ~,",blank,<,>)

7 Set your Extender SSID and password

Default SSID:
original SSID-pro-2.4G can be changed

Default router password can be changed

Please enter repeater wireless password
Wireless Name 2.4G   sohowifi-pro-2.4G

Auth Mode
Energy Type
Wireless Password   abc123321
Show Password
Hidden Network

Back   Next

* NOTE:
If you don't want to modify, you can proceed to the next step.

8 Check again and confirm the wireless information

Host Router Name   sohowifi
Extender Name 2.4G   sohowifi-pro-2.4G
Extender Name   sohowifi-pro
Extender Password   abc123321

Back   Start Connect

* NOTE:
After check,click "Start Connect " and wait 30-60s

9 Wait for the repeater to connect to the router successfully.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the relay is successful. Please connect sohowifi-pro-2.4G/sohowifi to the Internet!

Please wait 47 seconds

10 The "Extender" indicator lights on means successful connection.

*NOTE:

or   Extender

11 Reselect and reconnect to your extender wifi

sohowifi
sohowifi-pro-2.4G
Before
After
sohowifi   sohowifi-pro-2.4G

ENG

Re-select and reconnect to your extender wifi hospot
(The new wifi name defaults to the original wifi name plus pro-2.4G

展开尺寸: 225x210mm

成品尺寸: 75x105mm

四色双面印刷，先左右风琴折，后上下对折

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

§ 15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.