Bluetooth

KOSS
TWS250i TRUE WIRELESS EARBUDS

In the Box

Charging case

Earbuds

Charging cable

Pairing

1. For first use, hold the touch surfaces of both the left and right earbuds for 2 seconds or more

L Hold > 2 sec   Hold > 2 sec R

2. The earbuds will power on and enter pairing mode (shown with blue and red flashing LEDs)

Beeping   Beeping

Connecting To Bluetooth Device

1. Choose "KOSS TWS250i" to connect

Settings   Bluetooth
Bluetooth
DEVICES
KOSS TWS250i   Connected

2. Pairing successful

"Connected"

Note: earbuds will automatically connect to your device after initial connection as long as Bluetooth is on.

Touch Controls

Touch button functions and indications

Note: "t" is for tap and "Hold" is for touch and hold in the images below

1. Phone call

L   x2t   Hold > 1sec   x2t   Hold > 1sec   R

2. Music

L   x1t   x2t
Hold > 2sec   Hold > 2sec

x1t   x2t   R

Touch Controls

3. Voice assistant

Triple tap to prompt the voice assistant

L   x3t   x3t   R

4. Power off

Return earbuds to case to automatically power off or touch & hold earbuds for 5 seconds to manually power off

L   Hold > 5sec   Hold > 5sec   R

Light Language

R   R

Earbud Light Language

Power On	Blue light x3
Power Off	Red light x1
BT Paring	Flash
BT Connected	Flash once every 5s
Low Battery Reminder	Flashing red light
Charging in Progress	Red light on
Charging Complete	Red light off

Charging Case Light Language

	0~25%
	25~50%
	50%~75%
	75%~100%

Charging

1. Plug charging case into power source with supplied cable

2. When earbuds are in the charging case the light indicates that charging is in progress. The red light turns off when charging is complete.

L R

Reset

Step 1: Make sure both earbuds are in the charging case, touch & hold both earbud for 5 seconds to power off

Step 2: Touch & hold both earbuds for 8 seconds while they are in charging case and while powered off

① ②   ① ②

Hold > 5sec Hold > 8sec   Hold > 5sec Hold > 8sec

• The red light flashes for 4 seconds and a warning tone of two beeps occurs during this process

2. Pairing process begins again

L R

Beeping   Beeping

Product Specifications

Lithium Ion Batteries:
Model: 602030 , 3.7V , 300mAh
YJ POWER GROUP LIMITED
2F,B6 Building Tianrui Industrial Zone,Fuyuanyi Road, Fuyong Town, Baoan District, Shen Zhen, China

Model:581013 , 3.7V , 50mAh
DongGuan Nengyou Energy Science and Technology Co.,Ltd.
Building B,No.353, QingFeng Road,SanZhong Village, QingXi Town,DongGuan City,GuangDong Province.

Use this product in an environment with a temperature between 0℃ and 45℃; otherwise, it may become damaged.

KOSS Corporation
Model: KOSS TWS250i
Hereby declares that Bluetooth Headset, Model: KOSS TWS250i is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

KOSS Corporation
Model: KOSS TWS250i
Bluetooth Version: V5.0
DC input: 5V=280mA
Case Battery Capacity: 300mAh 1.11Wh
Combined Earbud Battery Capacity: 100mAh 0.37Wh
Made in China

WARNING

Using earbuds at high volumes for extended periods of time may result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety.
Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.
Earbuds may not work properly under high temperature or high humidity conditions.
Do not use any corrosive cleaner/oil to clean the earbuds.
If the earbuds come in contact with liquids, quickly wipe away. If submerged in water, do not turn the earbuds on until completely dried. Liquid submersion voids the warranty.
Keep the earbuds and packaging out of reach of children.

⚠ Battery warning!

* Do not disassemble, strike, crush or put the battery into fire.
* Do not expose the battery to conductive materials, liquids, fire, or high temperatures.
* Do not allow metal objects to touch the two poles of the battery.
* Do not continue to use the battery if it has bulges, leaks, discoloration, odors.
* Do not use the battery after it has been submerged in water.
* If the battery is used improperly, it may explode or leak, causing burns and other personal injuries.
* If the battery leaks, it should be carefully disposed of according to the local laws and regulations concerning battery disposal.

The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 14/02/2014, resulted in a major change in the treatment of electrical equipment at end-of-life. The purpose of the Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal.
The WEEE logo on the product or on its box indication collection for electrical and electronic equipment consist of the crossed-out wheeled bin, as shown below.

FCC STATEMENT

IC WARNING