amped wireless®

BASIC WIFI SMART PLUG

Product: SMART WI-FI POWER STRIP



MODEL:AWPS148W

PLEASE READ CAREFULLY BEFORE OPERATING THIS EQUIPMENT
KEEP IT IN A SAFE PLACE FOR FUTURE REFERENCE

IMPORTANT SAFETY INSTRUCTIONS



CAUTION: TO REDUCE THE ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER SERVICEABLE PART INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

DANGEROUS VOLTAGE: The lighting flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

ATTENTION: The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

WARNING: USE UNDER SUPERVISION OF AN ADULT DUE TO LONG CORD This unit has a long cord that can be easily tripped on or pulled on, causing injury. Please make sure it is arranged so that it will not drape over a tabletop, etc. Where it can be pulled on by children or tripped over accidentally.

FCC STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.

FCC NOTICE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC WARNING:

To assure continued operation, follow the attached installation instructions and use only shield cables when connecting to other devices. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To maintain compliance with FCC's RF Exposure guidelines, The 20cm is the minimum distance that has to be maintained between your body and the device.

IMPORTANT SAFETY INSTRUCTIONS

Before using the unit, be sure to read all operating instruction carefully, please note that these are general precautions and may not pertain to your unit. For example, this unit may not have the capability to be connected to an outdoor antenna.

1. Read these instructions

All the safety and operating instructions should be read before the appliance is operated.

2. Keep these instructions

The safety and operating instructions should be kept for future reference.

3. Heed all warnings

All warnings on the appliance and in the operating instructions should be adhered to.

4. Follow all instructions

All operation and use instructions should be followed.

5. Do not use this apparatus near water

The appliance should not be used near water; for example, near a bath tub,

washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

6. Clean only with dry cloth

The appliance should be cleaned only as recommended by the manufacturer.

7. Do not block any ventilation openings. **Install in accordance with the manufacturer's instructions.**

Slots and openings in the cabinet and in the back or bottom are provided for ventilation, to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or similar surface. This product should never be placed near or over a radiator or heat source. This product should not be placed in a built-in installation, such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

11. Only use attachments / accessories specified by the manufacturer.

12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

Portable Cart Warning

An appliance and cart combination should be moved with care. Quick stop, excessive fore and uneven surfaces may cause the appliance and cart combination to overturn.

13. Unplug this apparatus during lightning storms or when unused for long periods of time.

To protect your product from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or

moisture, does not operate normally, or has been dropped.

15. Power source

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other source, refer to the operation instructions.

16. Power lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

17. Overloading

Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

18. Object and liquid entry

Never push objects of any kind into the product through openings as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid on the product.

19. Outdoor antenna grounding

If an outside antenna is connected to the product, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electric Code ANSI/ NFPA 70 provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead- in wire to an antenna discharge product, size of grounding conductors, location of antenna- discharge product, connection to grounding electrodes and requirements for the grounding electrodes.



20. Service

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

21. Replacement parts

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original parts. Unauthorized substitutions may result in fire or electric shock or other hazards.

22. Safety check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

23. Wall or ceiling mounting

The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

24. Damage requiring service

Unplug this product from the wall outlet and refer service to qualified service personnel under the following conditions.

a)When the power- supply cord or plug is damaged.

b)If liquid has been spilled or objects have fallen into the product.

c)If the product has been exposed to rain or water.

d)If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an adjustment of other controls may result in damage and will require extensive work by a qualified technician to restore the product to its normal operation.

e)If the product has been dropped or the cabinet has been damaged.

f)When the product exhibits a distinct change in performance- this indicates a need for service.

25. Note to CATV system installer

This reminder is provided to call the CATV system installer' s attention to Article 820- 40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

NOTE: Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way such as the following: the power-supply cord or plug has been damaged, liquid has been spilled into unit, the unit has been exposed to rain or moisture, the unit has been dropped or the unit does not operate normally.

PREPARATION

- Smooth and rapid Wi-Fi network (2.4 GHz only)
- Smart Life APP and account
- One Smart Device: smart phone or tablet (not included)

SMART SOCKET OVERVIEW



LED Ring

- Press the power button to power on, the socket indicator will turn red.
- Press the power button again to power off the socket indicator will turn off.
- Press and hold the power button for about 5 seconds, the LED ring blinks fast with blue color, it is in pairing mode(EZ mode).
- Press and hold the power button for about 5 seconds in pairing mode until the LED ring blinks slowly with blue color, now it is in compatible pairing mode (AP mode).

LED Ring Color	Smart Socket Status
Blue (blink fast)	Pairing mode (EZ mode)
Blue (blink slowly)	Compatible pairing mode (AP mode)
Solid Blue	Successful connection

SMART LIFE APP

1. Search "Smart Life" on Apple APP store or Google Play, download and install it.
2. Once installed successfully, the icon will appear as the figure below.

Smart Life

REGISTER SMART LIFE APP

1. Tap the Smart Life App icon to open.
2. Tap "Register". (If you already have an account, tap "Login" to log in)
3. Tap the country columnn to select your country.
4. Tap "Mobile Number/Email" column to input your mobile phone number or email address. Tap "Next" to continue.
5. A verification code will be sent to your mobile phone or inbox on your phone. Input the verification code into the "verification code" column, then input a password on " Please Input Password" column.(6-20 digit password with letter and number)
6. Tap "Confirm" to finish registration.

CONNECT SMART SOCKET BY SMART LIFE APP

CONNECTION THROUGH EZ MODE

1. Tap "Smart Life" App and log in.
   When the below page appear,
   click "Add device" to continue.



2. When the below page appear,
   click "Electrical outlet" to continue.



3. Press and hold the ⏻ button for approx.5 seconds until the LED ring turns Blue and blinking fast, tap "Confirm indicator rapidly blink" to continue.



4. The window will remind you to confirm the Wi-Fi information.
   Input the Wi-Fi password and tap "Confirm" to continue.

5. The Smart Life is now connecting the available smart outlets.



6. The available smart outlets will be shown as below when successfully connected.



IMPORTANT!

ONCE DEVICE ADDED, CLICK TO RENAME, OTHERWISE, IT CAN NOT BE CONTROLLED BY ALEXA VOICE CONTROL.

7. After renaming, tap "Share with family" and set as on screen instructions to share with family, then your family can control on their smart phone with Smart Life APP.
Or you can set it later and tap "Done" to continue.





8. If connection fails, tap "Retry" to reconnect again as above steps.



CONNECTION THROUGH AP MODE

1. Click "Smart Life" App and log in.
   When the below page appear,
   click "Add device" to continue.



2. When the below page appear,
   click "Electrical outlet" to continue.



3. Press and hold the ⏻ button for approx. 5 seconds until the LED ring turns Blue and blink blinking slowly, tap "AP Mode" to skip to next interface.



4. Tap "Confirm indicator slowly blink" to continue.



5. The window will remind you to confirm the Wi-Fi information.
Input the Wi-Fi password and tap "Confirm" to continue.

6. Tap "Connect Now" to skip to your smart phone's wifi setting.



7. Select SmartLife-XXXX then return to APP.



8. The Smart Life is now connecting the available smart outlets.



9. The available smart outlets will be shown as below when successfully connected.



IMPORTANT!

ONCE DEVICE ADDED, CLICK TO RENAME, OTHERWISE, IT CAN NOT BE CONTROLLED BY ALEXA VOICE CONTROL.

10. After renaming, tap "Share with family"and set as on screen instructions to share with family, then your family can control on their smart phone with Smart Life APP. Or you can set it later and tap "Done" to continue.





11. If connection fails, tap "Retry" to reconnect again as above steps.



12. After completely connection, the page will appear as below, you can tap ⏻ near plug1, plug2 or plug 3 to power on or off the plug 1,2, 3 respectively.





13. Tap "Alarm" to set schedule to power on or off the plug 1, plug 2 or plug 3.







HOME PAGE

1. Tap "Back" to return to home page.



2. Tap "+" at the right top corner to add more device, the connection procedures refer to the previous two connection menthod, after successful addition, the interface will appear as below.



3. Tap "Scenes" at the bottom of the screen to create your own scene to suit your needs, For example, set your home to automatically turn on the lights and close.





4. Tap "+" to add your customized scene, here, tap "Good night" for example, then you need to finish two steps, step1: add a condition, step2: add a task.
when finish two steps, the "Perform" will be green, and you can tap "Perform" to execute task.





HOME PAGE

5. Tap "Profiles" at the bottom of the screen to set your profile, create scenes, sharing device, receiving message, using integration(the third side software) to operate by voice control or other operations, tap "Experience Center" to experience the scene, tap "Scan QR Code" to scan the QR code on some of the smart product, tap FAQ to check the requent ask questions.





NOTE: For Integration, here you can operate as the screen instructions to operate, expecially you can use Amazon Alexa for voice control operation.

NOTE: You can also tap on home page to send voice command to control the device. For example: "Turn off plug one", the plug one will be off.