TLC130_Manual_EN_A1(301-0106-00)

: 68x 68 mm ± 0.2 mm   : 680x 68 mm

80P   /   : 9

Pantone 151C

Before you start

Please make sure to follow these steps before you start:
1. Download the Brinno App
2. Fully charge the battery
3. Insert a Micro SD Card

App Store
Android

Brinno App

1. Camera: connect to a smartphone
2. Editing: video editing
3. Gallery: video playback
4. App settings
4-1. Video
4-2. Language settings

1-1. Connect to Android Phone

1. Turn on the camera (hold the "Power button" for 3 seconds or until the greenlight is on).
2. Turn on Bluetooth and Wi-Fi on your phone.
3. Open the Brinno App.
4. Press the "Camera Button".
5. List of cameras, select the camera (SSID) TLC130-XXXXXX.
6. Press "Connect".
7. Complete Bluetooth connection, "Connect Wi-Fi?" pops up, press "OK".

8. Shows Wi-Fi connection settings, "AP Mode" is set to default.
9. In the meantime, camera will automatically connect to your smartphone.
10. "Successfully Connected" pops up, press "OK".
11. Now you see the preview screen in the app.

1-2. Connect to iPhone

1. Turn on the camera (hold the "Power button" for 3 seconds or until the greenlight is on).
2. Turn on Bluetooth and Wi-Fi on your phone.
3. Open the Brinno App.
4. Press the "Camera Button".
5. List of cameras, select the camera (SSID) TLC130-XXXXXX.
6. Press "Connect".
7. Complete Bluetooth connection, "Connect to Wi-Fi?" pops up, press "Connect".

8. Then, pops up will illustrate "how to connect the Wi-Fi".
9. Go to Settings -> Wi-Fi -> select: TLC130-XXXXXX -> Password: 12345678.
10. Once you finished, go back to Brinno App
11. "Successfully Connected" pops up, press "OK".
12. Now you see the preview screen in the app.

1-3. Re-connect to The Smartphone

If the "Connect to Wi-Fi doesnot show up automatically after recording. Please connect to the smartphone again.

1. Press "Settings" icon.
2. Select "Wi-Fi Connection".
3. "Connect to Wi-Fi" pops up, press "OK".
4. Repeat steps 1-1, 1-2.

---

2. Record A Time Lapse Video In The App

1. When camera is successfully connected to a smartphone.
2. Press the scene filter icon.
3. Select a filter.
4. Press "<" to go back.

5. Press the record button to record.
6. When camera is recording, Wi-Fi connection will not be working.
7. Press the record button again to stop recording.

Camera offers 3 different functions: Photo, Time Lapse, Video.
Video mode allows you to record video up to a minute and share.

We recommend "Landscape" filter for beginners. Try 15 minutes video record for each filter to understand the difference.

For power saving purpose, camera will turn off the Wi-Fi connection during time lapse video recording. To re-enable camera preview, you must reconnect to the camera's Wi-Fi after you done recording.

---

3. Time Lapse Video Playback

1. When camera is successfully connected to a smartphone.
2. Select the File Icon.
3. Select a video in the folder.
4. Press the Play button.
5. Press "<" to return to folder.

Please save video into your phone incase the audio and video sync incorrectly.

---

4. Save Time Lapse Videos Into Smartphone

1. When camera is successfully connected to a smartphone.
2. Select the "File " icon.
3. Press "Select Button" on the upper right.
4. Select videos in the folder. (i)
5. Press "Transfer".

6. For iPhone users, please "Allow" camera to access to your phone's gallery.
7. Do not leave or turn off the App when transferring files.
8. After the videos are successfully transferred, you can watch them on your phone's gallery.

It is possible to transfer multiple videos at the same time, but the transmission process might be longer.

---

5. Time Lapse Video Editing

After the videos are successfully transferred, you can start editing.
1. Go back to the App.
2. Select Editing.
3. Press "Select" in "My Media" folder.
4. Select a video that you wish to edit. (One video at a time)
5. Select "+ " to start editing.

Editing functions:
1. Cut: Choose to keep.
2. Text: Add text in video.
3. Speed: Speed up or slow down the video.
4. Audio: add audio to the video.
5. Reverse: Play your video from the end to start.
6. Sign: Sign your video.
7. Share: Share your video to any social media or save to your phone.

Cutting:
1. Drag the two time bars to where you want to cut the video.
2. Select "confirm".

Music:
1. Press "Background Music".
2. Music: Import music from your phone.
3. My music: Free music is included.

Share:
Once you've done editing, you can choose to save the video into your phone, or share it on any social media platform.

WiFi Full HD Time Lapse Camera
TLC-130
User Manual
brinno

EN_A1-301-0106-00