



POWER GO USER GUIDE

power bank

Specification

Model: H306

Input: DC 5V 3A, 9V 1.67A, 12V 1.67A
 Output: Type-C: DC 5V 3A, 9V 1.67A, 12V 1.67A;
 Wireless Output: 5W, 7.5W, 10W, 15(Max)
 Battery: DC 3.85V 4500mAh

Product Overview



1. Wireless charging area
2. Power button
3. Dual Way USB-C
4. Charging Status indicator(Blue)
5. Battery Level Indicator(White)

Functions

1. Power Button and LED light indicator.

Power ON: Press once to power on, then the LED lights will turn on and indicate the battery level and charging status, if the blue light is blinking it is not charging, if it is on, it is charging.

Power OFF: Double-click the button to turn it off, the LED lights will turn off and the output will stop charging. (It automatically turns off after 30 seconds when it's not charging a device to preserve charge).

2. Charge devices using cable

Connect a cable to the USB type-C port and it will provide a wired charge to your device.




3. Charge devices with Magsafe (iPhone 12 >) or Qi wireless compatible devices with a MagSafe case.

Place your device on the charger as illustrated below, if it's MagSafe compatible or has a MagSafe case, it will be held in place and start charging wirelessly.



4. Charge your non Magsafe device

The charger can be attached to Non-Magsafe devices & cases using the adhesive magnetic ring (included).



5. Recharging your POWER GO:

Just connect a cord to the USB type-C port while connected to a power source. Charging your device with the Power GO while it's being recharged is permitted.



Precautions

1. Don't use an adapter with an output of 5V/3A(15W) or less. Use of a power supply or charger not recommended or sold by product manufacturer may result in a risk of injury to persons.

2. The advantage of wireless charging is that they are more convenient than wired chargers, but due to the limitations of wireless technology, their charging speed is slower than that of wired chargers.

3. High temperatures will reduce charging speed and restrict power, which is something that happens to all wireless chargers. It is recommended that you charge your device in environments with temperatures below 40°C to 40°C. Don't store the product in a hot or humid environment.

4. Charge speed will be affected by both your device's protective case and its position on the wireless charger. The farther it is placed from the center of the wireless charger, the slower the charging speed will be. There should be no metal or magnetic objects within 6cm of the back center of the phone during charging. Otherwise, the charging status indicator will flash and then the charger will cease charging.

5. As a result of the physical transfer of energy, a device may feel warm when it is being charged. This is a normal operating condition with wireless charging and should not be viewed as a cause for concern.

Includes:

- 1x Power GO
- 1x USB-C to USB-C Cable
- 1x User Manual
- 1x Packaging box
- 1x Adhesive Ring

About FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, this can be determined by turning the equipment off and on.

The user is encouraged to try to correct the interference by one or more of the following measures:
 Reorient or relocate the device.

Increase the separator between the equipment and the receiver.
 Connect the equipment to an outlet on a circuit different from that to which the receiver is connected to.
 Consult the dealer or an experienced technician for help.

The device has been evaluated to meet general RF exposure requirements.
 The device can be used in portable exposure conditions without restriction.