


GY-Z13英文说明书, 正反彩印

封面 100mm

75mm


USER MANUAL

2 IN 1 MAGNETIC WIRELESS CHARGER




Note: To ensure charging 3 devices safely and efficiently, you must use 9V/2A adapter (Qualcomm Quick Charger 2.0 or 3.0) and quick charge cable (if not use the appropriate adapter and quick charge cable, the charger may not charge phone, or may not charge 3 devices simultaneously, or may even damage the charger).


PRODUCT APPEARANCE



CHARGING SCHEMATIC DIAGRAM



Wireless charging of multiple devices



PRODUCT SPECIFICATION

Input: 9V/2A
 Phone Output: 15W /10W / 7.5W /5W
 Earphone Output: 3.0W
 USB Output: 5V/1A
 Input Interface: Type-C port
 Transmission Distance(Phone): ≤8mm
 Conversion Rate(Phone): ≥73%
 Product Size: 156.75x91 x91 (mm)

ACCESSORIES LIST

Wireless Charger*1, Type-C quick charge cable*1, User manual*1

APPLICABLE DEVICES

- Smart Phone:
 - Magnetic alignment is only available for iPhone 12 models (iPhone 12, 12 mini, 12 Pro, 12 Pro Max).
 - Mobile phones that support Qi wireless charging standard.
- Earphone:
 - Airpods 2/Pro, Other TWS earbuds which support wireless charging.
- Compatible iPhone 12 Case (Magsafe Silicone Case / Magsafe Clear Case).

SAFETY INSTRUCTIONS

- Charging devices that meet the Qi charging standard.
- Charging output maximum power fast charging 15W, compatible with fast charging 10W, 7.5W and general charging 5W.
- Magnetic calibration adsorption, mobile phone automatically adsorption charging when put on.
- Safety guarantee: overheating protection, overcurrent protection.

WARNING

- Do not pull the power cord hard to avoid the power cord from breaking or falling off.
- Do not disassemble by yourself or throw it into fire or water to avoid short circuit and leakage.
- Do not use in severely high temperature, humidity or corrosive environments to avoid leakage of electricity due to damage to the circuit.
- When using this product, keep a distance of more than 50cm from the pacemaker.
- Only use the wireless receiver conforming to Qi standard to connect with the transmitting terminal.
- The working environment temperature of the charger is -10°C-30°C.

- Do not place the magnetic card, magnetic recording medium and precision machine too close to the charge.
- Keep out of reach of children.

ANSWER QUESTIONS

- If you're experiencing interrupted or slow charging, check the following:
 - The back of your phone should not have any metal, pop sockets, or credit cards.
 - Put the phone in the center of the charging surface (this lets the charging coil in your phone lineup with the one inside the wireless charger).
 - The wireless charging coil on Sony phones is located slightly below center.
 - Phone cases should be no thicker than 5 mm for effective charging.
 - Check whether the adapter is QC3.0 fast charger.
- If you're failing to charge your device, please try out the following:
 - Please restart your cell phone and test with other USB cable.
 - Please check whether the indicator turns on or not.
 - The wireless charging coil on Sony phones is located slightly below center.
 - Phone cases should be no thicker than 5 mm for effective charging.
 - Check whether the adapter is QC3.0 fast charger.
- If you're failing to charge your device, please try out the following:
 - Please restart your cell phone and test with other USB cable.
 - Please check whether the indicator turns on or not.
 - Please check the Adapter is QC3.0 Quick Charger (Output:9V/2A) or not, iPhone original adapter does not match the wireless charger.
 - Please check your Phone case thickness(≤5mm). Metal ring or Magnetic Pad will not be available.
- If you're using the recommended wireless charger with the QC3.0 Adapter and have removed any potential charging obstructions, but are still experiencing issues, try:
 - Replacing the cable connecting your the wireless charger.
 - Rebooting your phone.
 - Unplug the adapter and reinsert.

5. Charging is still slow:

The mobile phone itself or the external receiving coil allows the wireless charging current to be different, or the application running consumes a lot of power when the mobile phone is charging. It is recommended to reduce or close the application.

6. The phone is charging intermittently, or the indicator light flashes:
 If the charging current is not enough, please use a charging head (adapter) with sufficient power 9V/2A or 18W above.

7. Charging fever:

It is normal for the receiving coil or transmitter board to generate heat during wireless charging. If the plate is too warm, take your phone off the plate, and switch the plate off. The plate may switch off automatically if it is too hot. when the plate has cooled down, try charging again.

8. The charger does not work:

Do not put metal debris or magnetic cards on the charging area. If the product does not work due to overheating, please take off the phone and wait for it to cool down and try charging again.

9. If the host fails, contact after-sales maintenance.

FCC Statement

This device complies with part 15 FCC Rules. Operation is Subject To the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC radiation exposure

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.