



CHIPS 3.0

WIRELESS HELMET AUDIO




Good call on picking up the Outdoor Tech® CHIPS® 3.0 , universal wireless helmet audio. Your experience of the universe will soon be enhanced wirelessly. This manual exists to help make sure that you use them correctly, so you're definitely going to want to relax for a hot second and look through this manual.

Kisses,



WARNING: For safety reasons, some state and local laws prohibit the use of headsets when operating a bicycle. Use Chips® only for off-highway activities. Do not use Chips® at excessive volumes because it may cause permanent hearing damage.

ANATOMY



- A. Left ear button
- B. Right ear button
- C. Charge port USB-C
- D. LED light
- E. Microphone

1

FUNCTIONS

RIGHT



FUNCTION	ACTION	VOICE PROMPT
POWER ON	LONG PRESS 4 SECONDS	"POWER ON"
PLAY	PRESS ONCE	
PAUSE	PRESS ONCE	
SKIP FORWARD	PRESS TWICE	
SKIP BACKWARD	PRESS THREE TIMES	
ANSWER CALL	PRESS ONCE	"ANSWER"
END CALL	PRESS ONCE	"CALL TERMINATED"
REJECT CALL	LONG PRESS 2 SECONDS	"REJECT"
SIRI/ GOOGLE ASSISTANT	PRESS RIGHT + LEFT	"BEEP"
CLEAR MEMORY	LONG PRESS 8 SECONDS	

2

FUNCTIONS


LEFT



FUNCTION	ACTION	VOICE PROMPT
POWER OFF	LONG PRESS 4 SECONDS	"POWER OFF"
VOLUME UP	PRESS TWICE	"MAX VOLUME"
VOLUME DOWN	PRESS ONCE	
MIC MUTE	PRESS THREE TIMES	
SIRI/ GOOGLE ASSISTANT	PRESS RIGHT + LEFT	"BEEP"

3

POWER UP



Charge Time
45 minutes

For best results, fully charge your CHIPS® 3.0 using the supplied USB to USB C charging cable before use.

The indicator light located on the right ear piece will flash red to indicate a low battery.

Once the Chips 3.0® are plugged into a power source, the indicator light will turn red. It will turn off once the CHIPS are completely charged.

NOTE: It only takes 45 minutes to give your CHIPS® 3.0 a full charge.

4

PAIRING



RIGHT



(From the OFF position press and hold until LED flashes red and blue alternately.)
VOICE PROMPT: "power on>>pairing"



Choose: "ODT Chips® 3.0" in your phone's Bluetooth settings.
VOICE PROMPT: "connected"
(If prompted by your device to connect, select "Yes". If prompted by your device enter password or use pairing code: 0000.)

5

TALK



The following are tips on how to use your CHIPS® 3.0 to speak on the telephone:

Answer a call..... Press right ear button

End a call..... Press right ear button

Reject a call..... Press and hold the right ear button for two seconds


Make a call..... Use your phone to dial as usual Listen & talk through the CHIPS®

Volume up..... Double press the left ear button


Volume down..... Press left ear button

Voice Activation..... Press and hold both left and right ear buttons simultaneously. Release and speak when you hear the voice prompt: "Beep".

PUT THE CHIPS IN YOUR HELMET



1. Drop the CHIPS® 3.0 into the slots inside your helmet liner.



2. Rock out, make calls, and, you know, ski and snowboard and whatnot.

SPECS



Battery life..... 13 hours of play time

*Battery life varies subject to different playing circumstances, such as music type and volume.

Bluetooth version.... V5.2

Bluetooth profiles.... HFP1.8, HSP1.2, A2DP1.3, AVRCP1.6

Operating distance.. 33 feet, 10 meters

Charging input..... DC 5.0V, 1A

Dimensions..... 2" diameter, 0.5" thick

Weight..... 0.18 lbs (81.6g)

Battery capacity..... 250mAh

FAQ



Why is the red LED flashing twice every 20 seconds? The battery is low. Recharge it.

Why is the red LED off when charging?

- A. Make sure the connection between the charging cable and the CHIPS® 3.0 is tight.
- B. If the CHIPS® 3.0 haven't been used in awhile, the light may not come on immediately. Charge the battery for at least 30 minutes.

Why can't I pair my CHIPS® 3.0?

- A. Your Bluetooth device and the CHIPS® 3.0 must both be in pairing mode.
- B. Your CHIPS® 3.0 should not be paired to any other devices.

Why do I have Bluetooth signal loss/dropout/unclear conversations?

- A. Move your device closer to your CHIPS® 3.0.
- B. Make sure your CHIPS® 3.0 are charged up.
- C. Turn off your CHIPS® 3.0 and device, then power up and reconnect.

Why can't the CHIPS® 3.0 hear my voice during a call?

- A. Make sure the CHIPS® 3.0 are on.
- B. Make sure the volume is not too low or muted.
- C. Make sure the CHIPS® 3.0 are properly connected with your device.
- D. Make sure the CHIPS® 3.0 are within range of your device.

CARE & MAINTENANCE



- Keep the CHIPS® 3.0 dry
- Keep the CHIPS® 3.0 away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Do not try to disassemble the CHIPS® 3.0.
- Do not let the CHIPS® 3.0 fall onto the floor or other hard surfaces. The internal circuit board may get damaged.
- Do not use intensive chemical products or detergent to clean the product.
- Do not scratch the surface with sharp things.

K, Later gator.

DON'T BE SO ANTISOCIAL



Facebook.com/outdoortechology
Twitter & Instagram: @outdoortech

Questions, comments, complaints, secret desires, or just to say what's up: email info@outdoortech.com

K bye.



www.outdoortech.com

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.