



MODEL:E1
SOMIC E1 Open-Ear Earbuds
User Manual

CONTENTS

English 01/08

US UK CA Thank you for choosing our E1 open-ear earbuds. Please read this manual carefully and keep it for future reference.

Product Features

1. Dual microphone ENC noise cancellation.
2. Support music/game dual sound effect switching.
3. The wireless earbuds weighs around 10.5g, which is light and comfortable to use.
4. Directional sound transmission technology for clear and natural sound.


Package Contents

- Open ear headphones
- Type-C charging cable
- Charging Case
- Instruction manual

Specifications

Model	E1
Bluetooth version	V5.3
Bluetooth connection distance	10m
Headphone battery life	7 hours
Time required to fully charge the charging case	1.5 hours
Time required to fully charge the headset	2 hours
Type of charging cable	Type-C

Product Overview



- ① Power on
After opening the charging case, the earbuds will be automatically turned on, then enter the Bluetooth pairing state.
Or press and hold the touch area for 3 seconds in the power off state to manually turn it on.
- ② Power off
Put the earbuds back into the charging case. When the lid is closed, the earbuds will automatically shut down and enter the charging state.
Press and hold the left/right ear touch area for 5 seconds in the power off state to manually turn it off.
- ③ Play/pause music
Double tap any touch area to play/pause the music.
- ④ Previous/Next track
When playing music, press and hold the touch area of the left earphone for 2 seconds to switch to the previous track.
When playing music, press and hold the touch area of the right earphone for 2 seconds to switch to the next track.
- ⑤ Answers to calls
Answering a call: In the incoming call status, double-tap the touch area of any side of the earphone.

End a call: During a call, double-tap the touch area of any earphone.
Reject an incoming call: In the incoming call status, press and hold the touch area of any side of the earbuds for 2 seconds.

- ⑥ Voice Assistant
Touch the left earphone touch area 3 times, then release to activate the voice assistant.
- ⑦ Sound mode
Touch the left earphone touch area 3 times, then release to activate the voice assistant.
- ⑧ Voice Assistant
Touch the right earphone touch area 3 times to enter the sound effect mode.
Enter the game mode, the earbuds will sound "Gaming Mode".
Enter the music mode, the earbuds will sound "Music Mode" (The default is music mode).

- ⑨ Reconnection
When the earbuds are successfully paired with the device, put the earbuds back into the charging case when not using it. If you want to take it out for use again, the earbuds will automatically connect to the last paired device. In reconnection mode, the blue light of the earbuds indicator flashes once every 1 second.
If the connection fails to pair back with the last device for more than 10 seconds, it will automatically enter the normal pending connection status. The pending connection status will remain for 3 minutes. Or it will automatically shut down after 3 minutes.

- ⑩ Disconnection
When the earbuds are disconnected, the earbuds will sound the prompt "disconnected".
After disconnection, it will enter the reconnection status and the reconnection state will remain for 3 minutes. If the connection is successful, the earbuds will sound the prompt "connected", otherwise, it will automatically shut down after 3 minutes.

- ⑪ The status of the earbuds when the battery is low
When the battery of the earbuds is lower than 10%, it will enter the low-battery alert status (low-battery alert). When the power is lower than 5%, the earbuds will power off.
When the earbuds' battery is low, it will sound "low battery". The prompt tone reminds every 3 minutes, and the red light on the earbuds flashes (once every 10 seconds).

- ⑫ Status of the charging case
A. The battery level display of the charging case
When opening/closing the charging case cover/headphones in and


of the charging case:
1) When the power is 0-30%, the 3 status indicators on the charging case will light up red for 5 seconds and then turn off.
2) When the power is 30-70%, the 3 status indicators on the charging case will light up blue for 5 seconds and then go out.
3) When the power is between 70-100%, the three status indicators on the charging case will light up green for 5 seconds and then turn off.
B. When the charger charges the battery in the charging case
1) When charging, the 3 status indicators on the charging case will light up with blue breathing lights (the 3 lights will gradually light up for 2 seconds and fade out in 2 seconds to form a breathing effect lighting. There will be no dazzling feeling when the light is at the brightest).

- ⑬ Forced clearing and pairing
Put the left and right earbuds into the charging case at the same time, and press and hold the button on the charging case for 5 seconds, the earbuds will clear the pairing record with other devices.
After successful clearing, the three lights of the status indicator on the charging case flash twice at the same time. Then the headset will enter the normal state of waiting to be connected, and can be

Connection Instruction

Before using it for the first time, put the 2 earbuds into the charging case and close the lid of the charging case. Then use the TYPE-C charging cable in the package to charge the charging case for more than half an hour. Turn on the earbuds after the earbuds and charging case are fully charged.

Open the charging case lid, the earbuds will automatically power on and search for devices. Open the phone's Bluetooth to search for SOMIC E1 connection. (Make sure the earbuds are paired and the distance between



FAQs

1. Why can't the earbuds be turned on?
Before using it for the first time, put the two earbuds into the charging case and close the lid of the charging case. Then use the TYPE-C charging cable in the package to charge the charging case for more than half an hour. Turn on the earbuds after the earbuds and charging case are fully charged.
2. Why can't the mobile phone's Bluetooth search for "SOMIC E1"? Why is the connection unstable?
Why is the connection disconnected/the sound is stuck?
① The Bluetooth connection of the mobile phone should not exceed a distance of 10 meters. At the same time, please avoid them being blocked by walls or crowds. (Subway stations, high-speed rail stations and airports will have strong interference to Bluetooth signals. It is normal for Bluetooth signals to be unstable in these scenarios.)
② Please make sure that the earbuds and charging case are fully charged.
③ Put the earbuds into the charging case and close the lid then take it out after 10 seconds. Turn on the Bluetooth of the mobile phone and search for the earbuds again.
④ If the connection still fails after doing the above steps, please check if the earphone has been connected by other Bluetooth devices nearby. Please turn off the Bluetooth devices nearby, and then repeat step 3.
3. Why does the earbuds only emit sound from one side?
Make sure the earbuds and charging case are fully charged. Then clear all the Bluetooth pairing records of the mobile phone and turn off the Bluetooth. Put the earbuds into the charging case and close the lid. After 10 seconds, take out the earbuds and hold for 5 seconds, then turn on the Bluetooth of the mobile phone to search for the earbuds again and connect them.
4. Why is the touch function of the earbuds not working?
① Make sure your finger touches the touch area of the earbuds accurately.
② Try to speed up the rhythm of double-click and triple-click (complete double-click and triple-click in about 1 second).
③ The earphone can't open the music app on the mobile phone. Therefore, the touch control such as playing/pausing/switching the tracks will only work when the music app is running.
④ Touch control has different sensitivities for different human bodies. Water or foreign objects on the finger or touch area will affect the touch effect. Please clean the surface of the earbuds and try again.
5. Why doesn't the call sound play from the earbuds when

incoming call is answered by operating the screen of the mobile phone, the call will be communicated with the mobile phone by default. If you want to use the earphone to answer the call, please double-touch either

Precautions

1. This product is compatible with Android and IOS systems.
2. If it does not work on an operating system not listed or on the device, please contact the support team for assistance.
3. When using the earbuds, if there is no sound from the earbuds, it may be caused by compatibility issues or improper use, please contact our service team for assistance.
4. If any parts are damaged, please stop using them and contact the after-sales service team for help to avoid unnecessary damage.
5. If you want to know more information, please visit SOMIC's official website www.itsomic.com.

Warranty

SOMIC's products are covered by a 12-month warranty from the date of purchase. If you have any questions, please contact the after-sales team, we will help you solve the problem at any time. For more information, please visit SOMIC's official website www.itsomic.com.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



www.itsomic.com

Service E-mail

NORTH AMERICA
support.us@itsomic.com(US)
support.ca@itsomic.com(CA)

ASIA PACIFIC
support.jp@itsomic.com(JP)

EUROPE
support.eu@itsomic.com(EU)

AUSTRALIA
support.au@itsomic.com(AU)

MANUFACTURER
Manufacturer:
Dongguan Branch of Guangdong SOMIC High-Tech Co., Ltd
Address:
No.9, Lianxin Road, Shangjiao Community, Chang'an Town,Dongguan
523000,Guangdong, China



RoHS
Made in China