



95mmx80mm

<h2 style="text-align: center;">User Manual</h2> <h3 style="text-align: center;">Ver-D1.0</h3>  <p style="text-align: center;">Thank you for purchasing this product.To ensure properly use and trouble-free operation,please read this manual carefully and store it in a safe place for future reference.</p> <p style="text-align: right;">1</p>	<h3>PACKAGE CONTENTS</h3> <table border="1"> <thead> <tr> <th>Parts</th> <th>LDB-D11/ LDB-D12</th> <th>LDB-D21/ LDB-D22</th> <th>LDB-D31/ LDB-D32</th> </tr> </thead> <tbody> <tr> <td>Receivers</td> <td>X1</td> <td>X1</td> <td>X2</td> </tr> <tr> <td>Transmitter</td> <td>X1</td> <td>X2</td> <td>X1</td> </tr> <tr> <td>Transmitter Opener</td> <td>X1</td> <td>X1</td> <td>X1</td> </tr> <tr> <td>3M Adhesive</td> <td>X1</td> <td>X2</td> <td>X1</td> </tr> <tr> <td>Screw</td> <td>X2</td> <td>X4</td> <td>X2</td> </tr> <tr> <td>Screw holder</td> <td>X2</td> <td>X4</td> <td>X2</td> </tr> </tbody> </table> <h3>PRODUCT OVERVIEW</h3>  <p style="text-align: right;">2</p>	Parts	LDB-D11/ LDB-D12	LDB-D21/ LDB-D22	LDB-D31/ LDB-D32	Receivers	X1	X1	X2	Transmitter	X1	X2	X1	Transmitter Opener	X1	X1	X1	3M Adhesive	X1	X2	X1	Screw	X2	X4	X2	Screw holder	X2	X4	X2	<h3>OPERATING INSTRUCTIONS</h3> <h4>1. Pairing Method</h4> <ol style="list-style-type: none"> 1) Plug the receiver into the power socket. 2) Press and hold + button on the receiver for 3 seconds to enter pairing mode.The Receiver Light Indicator will blink. 3) Press the transmitter Push Button and the receiver will chime "ding dong" to indicate the pairing is complete. <p>Note:</p> <ol style="list-style-type: none"> 1) Press any button on the receiver or wait for 60 seconds to exit the pairing mode. <h4>2. Switching Melodies</h4> <p>Press ◀ and ▶ buttons to switch among all the 56 melodies in sequence.</p> <h4>3. Adjusting Volume</h4> <p>Press + button to increase the volume and - button to decrease the volume.</p> <p style="text-align: right;">3</p>	<h3>INSTALLATION</h3> <h4>1. Transmitter battery installation</h4> <p>The battery is pre-installed in the transmitter.Insert the key into the allotted slot and twist the key clockwise to open. Peel off the insulating film on the button cell then close the cover.</p> <h4>2. Transmitter installation</h4> <ol style="list-style-type: none"> 1) Adhesive tape: apply the double-sided adhesive tape on the back of the transmitter.Remove the outer side of the tape and attach the transmitter in the desired location on the wall. 2) Screws and anchors: there are screw locator knockouts on the back of the transmitter,punch these out to allow the screws to pass through and fix the transmitter with the anchors in the desired location on the wall. <p>Notes:</p> <ol style="list-style-type: none"> 1) Please do not place this transmitter in areas close to metals. 2) The working distance varies with different blockage in the surrounding environments. <p style="text-align: right;">4</p>
Parts	LDB-D11/ LDB-D12	LDB-D21/ LDB-D22	LDB-D31/ LDB-D32																												
Receivers	X1	X1	X2																												
Transmitter	X1	X2	X1																												
Transmitter Opener	X1	X1	X1																												
3M Adhesive	X1	X2	X1																												
Screw	X2	X4	X2																												
Screw holder	X2	X4	X2																												

95mmx80mm

<h3>FEATURES</h3> <ol style="list-style-type: none"> 1. Melody Feature Built with 56 high quality melodies for your choices.Maximum sound pressure level up to 115dB. 2. Memory Feature The previously set volume level and melody will be remembered when you power on the device again. 3. Dust-proof and Waterproof Feature The transmitter is IP66 dust-proof and Waterproof,fit for various outdoor environments. 4. Reliable Feature Custom encoded software communication method ensures better privacy and no interference from other devices. <p style="text-align: right;">5</p>	<h3>TROUBLE SHOOTING</h3> <p>If the unit has a problem, try to follow the instructions below to solve it.</p> <table border="1"> <thead> <tr> <th>Problems</th> <th>Possible causes</th> <th>Solutions</th> </tr> </thead> <tbody> <tr> <td rowspan="3">The indicator on the transmitter does not light up</td> <td>The battery insulating film has not been peeled off</td> <td>Peel off the insulating film.</td> </tr> <tr> <td>The battery power is low</td> <td>Replace with new battery.</td> </tr> <tr> <td>The battery is not properly installed</td> <td>Take out the battery and install it again. Make sure the contacts are good.</td> </tr> <tr> <td rowspan="2">The receiver does not respond to the transmitter</td> <td>Unknown reason</td> <td>Please contact our e-mail.</td> </tr> <tr> <td>Unsuccessful pairing</td> <td>Pair the transmitter and receiver again.</td> </tr> <tr> <td></td> <td>Unknown reason</td> <td>Please contact our e-mail.</td> </tr> </tbody> </table> <p style="text-align: right;">6</p>	Problems	Possible causes	Solutions	The indicator on the transmitter does not light up	The battery insulating film has not been peeled off	Peel off the insulating film.	The battery power is low	Replace with new battery.	The battery is not properly installed	Take out the battery and install it again. Make sure the contacts are good.	The receiver does not respond to the transmitter	Unknown reason	Please contact our e-mail.	Unsuccessful pairing	Pair the transmitter and receiver again.		Unknown reason	Please contact our e-mail.	<h3>TECHNICAL SPECIFICATIONS</h3> <ul style="list-style-type: none"> • Receiver working voltage: AC 110-260v. • Receiver AC Power Consumption: <0.25W (standby mode). • Working Frequency : 433.92MHz • Transmitter Battery Type: CR2032 3V Lithium button cell • Operating temperature: 14~122 °F (-10~50°C) <h3>WARRANTY INFORMATION</h3> <p>Please kindly contact us if you are not pleased with our products, we will offer you a satisfied solution within 24 hours. For instance, if there is any defect or omission, we will send you the replacement.</p> <p>Here is our e-mail address: <u>supportringup@163.com</u></p> <p>For better help you, please contact us with following information, Your name: _____ Order number: _____ E-mail: _____</p> <p style="text-align: right;">7</p>	<h1 style="text-align: center;">RingUp™</h1> <p style="text-align: center;">Greetings! Thanks for your support! Here are two tips for you!</p> <div style="background-color: #cccccc; padding: 5px; text-align: center;"> <p>Tip 1: First Use</p> <p>Remove the battery insulating film before use</p> </div> <div style="background-color: #cccccc; padding: 5px; text-align: center;"> <p>Tip 2: Transmitter invalid</p> <p>Check the transmitter and receiver to verify that they are paired</p> </div> <p style="text-align: right;">8</p>
Problems	Possible causes	Solutions																			
The indicator on the transmitter does not light up	The battery insulating film has not been peeled off	Peel off the insulating film.																			
	The battery power is low	Replace with new battery.																			
	The battery is not properly installed	Take out the battery and install it again. Make sure the contacts are good.																			
The receiver does not respond to the transmitter	Unknown reason	Please contact our e-mail.																			
	Unsuccessful pairing	Pair the transmitter and receiver again.																			
	Unknown reason	Please contact our e-mail.																			

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure conditions without restriction