



C Lock adding

- a Turn on the Bluetooth and enter the interface of adding lock in app.




- b Light up the screen and add the lock



Note: Please keep your phone near the door lock within **10 meters**.

D Key management

After the administrator successfully adds the lock, owner owns the highest administrative rights to the lock. The owner can send keys to the others. Meanwhile, the owner can increase the key management that is about to expire.




Click the type of lock and it will show the time-limited ekey, one-time ekey and permanent ekey.


Time-limited ekey: The ekey is valid for the specified time.

Permanent ekey: The ekey can be used permanently.

One-time ekey: The ekey will be automatically deleted once it has been used.



The manager can delete an ekey, reset an ekey, and adjust the ekey. He can also check the lock record.




E Passcode management

After inputting the passcode on the keyboard of the lock, press the unlock button to unlock. Passcodes are classified into permanent, time-limited, one-time, empty, oop, custom, etc.

The password that has been set can only be unlocked, but cannot be locked.


a Permanent passcode

The permanent passcode must be used within 24 hours after it is generated, otherwise it will automatically expire.




b Time-limited passcode

The time-limited passcode has an expiration date, which is a minimum of one hour and a maximum of three years. If the validity period is within one year, the time can be accurate to the hour; if the validity period is more than one year, the accuracy is month when the time-limited passcode is valid, it should be used within 24 hours, otherwise it will automatically expire.




c One-time passcode

One-time passcode can only be used for one time, and is available for 6 hours. It will automatically expire.




d Erase passcode

Erase Passcode is VALID for 24 Hours from the current time. Caution -All passcodes used on this lock will be deleted on using this passcode.




e Custom passcode

You can configure your own passcode. It needs to be between 6- 9 digits in length. You can configure the customized passcode via Bluetooth or remotely via a gateway.




f Recurring passcode

The recurring password can be reused within a specified time period, including daily type, weekday type, weekend type, and more.




g Passcode sharing

The system adds new ways of communication, such as Facebook Messenger and WhatsApp, with the aim of helping users to share the access code.



h Passcode management


All generated passcodes can be viewed and managed in the password management module. This includes the right to change password, clear password, reset password and unlock password.



F Card management


You need to add the RFID card first. The whole process needs to be done via the app beside the lock. The validity period of the IC card can be set, either permanent or time-limited.

All RFID cards can be queried and managed through the RFID card management module. The remote card issuance function is displayed in the case of a gateway. If there is no gateway, the item is hidden.





a Add a RFID card


Click "Cards", then click "Add card".



There are three options for you. Select "permanent", "timed" or "recycling" as needed. Enter the name of the RFID card, and click "OK". Then, when the RFID card is close to the card sensing area of the lock for 2-3 seconds, the RFID card can be added successfully.




To add an RFID card again, click on the upper right corner of the "Cards" homepage, click "Add Card". Then repeat the operation of adding the RFID card.




b Delete RFID cards

Click on the upper right corner of the "Cards" homepage and click "Clear Card" to delete all RFID cards.



We can also choose a single RFID card to delete.




G Fingerprint management



Fingerprint management is similar to IC card management. After adding a fingerprint, you can use the fingerprint to unlock the door.

a Add fingerprint

Click "Fingerprint", then click "Add Fingerprint".




There are three options for you. Select "permanent", "timed" or "recycling" as needed. Enter the name of the Fingerprint, and click "OK". Then click "Start" and you will be required to place and remove your finger from the sensor 4 times.




H Records

It records who comes and goes. When it comes to 24/7 access logs, get all logs about door unlock/lock anytime anywhere.




I Setting

In the system settings, it includes touch unlock switch, group management, gateway management, security settings, reminder, transfer smart lock and so on.




a User management

The user name and phone number can be seen in the user list. Click the customer you want to view to get the door lock information.



b Key groups management


In the case of a large number of keys, you can use the group management module.



c Transfer admin rights


The administrator can transfer the lock to other users or to the apartment (Room Master user). Only the account that manages the lock has the right to transfer the lock. After inputting the account, you will receive a verification code. Filling in the correct number, you will transfer successfully.

... The apartment transfer account received must be the account of the administrator.



d Lock recycling station

If the lock is damaged and cannot be deleted, the lock can be deleted by moving it into the recycling station.



Gateway Management

(Gateway needs to be purchased separately.)

The smart lock connects directly via bluetooth, so it is not attacked by the network. The gateway is a bridge between smart locks and home Wi-Fi networks. Through the gateway, user can remotely view and calibrate the lock clock, read the unlock record, meanwhile, can remotely delete and modify the password.




Gateways must be added through the app before they can be used. Here are the steps:

- (1) Open the TTLOCK app;
- (2) Touch the "≡" icon on the top left of the screen;
- (3) Select [Gateway];
- (4) Select the "G2";
- (5) Plug in the Gateway and power it on;
- (6) While the light is flashing alternately in red and blue, press "+" sign;
- (7) Add Gateway;
- (8) Select the network and input your WiFi password.


⚠ Notice: If the above process times out, please power off and try again.

Low Power



When the smart lock is open, the screen will brighten up and "beep" to warn that the battery is low power.

Emergency Power




If the lock is low power and unable to operate, there is a micro USB power socket at the bottom of lock for power supply.

Factory Default Setting


| Settings | Factory Default |
|------------------------|-----------------|
| Master Code | 123456 |
| Auto Lock | |
| Silent Mode | |
| Wrong Code Entry Limit | |
| Shutdown Time | |

Restore Factory Settings

Restore on app



Select
“Settings”
in the app



Select “Delete”
and insert user
login password

Troubleshooting

I forgot my Master Codes.

Perform a reset in order to erase all passcodes. Once the reset is complete, all passcodes will be erased and the Master code will return to the default value (123456).

FCC Warning

This device complies with part 15 of the FCC Rules. Its operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

GEONFINO

Dear customer,

Greetings!

Thank you very much for your purchasing! We are so honored to have you as our customer, and we have great confidence to provide you with premium products and friendly service.

About GEONFINO

As an innovative and high high-tech, GEONFINO is dedicated to R&D, designing, producing and marketing of Smart lock products. Our top-guns in the Smart lock field have constantly developed a series of products with features like fashion, human care, energy efficiency, and environment protection. And we highly value concepts of "People Oriented, Practical and Innovative." a professional seller in the smart lock field will always be a nice company to your life!

Warranty

GEONFINO not only provides a 1-year warranty for all our products but also offers high-level after-sales service. Please kindly contact us immediately and we will supply a replacement or refund if you encounter any of the followings:

- 1.Receiving defective items;
- 2.Lacking of packaging;
- 3.Parts are broken in transit;
- 4.Item stops working within warranty;
- 5.Wrong order.

Importance

Valuable customers, if you like our products and service, your positive feedback and reviews will be inspiring comments on our work. If you're dissatisfied with what you get, before writing negative feedback, please contact us, we will try our best to solve the issue to your satisfaction. Thanks for your vote of confidence! Wish you a very happy life!

Best regards!

Customer Service E-mail: geonfino@afterservice.vip

TEL: +1 833 637 2188

Scan here to contact us
[24Hrs Online]



<https://geonfino.afterservice.vip>