vLinker MS (Bluetooth) **Quick Start Guide for iOS & Android**



KEY FEATURES:

- 1. Work in 12V or 24V automotive systems.
- 2. Apple MFI certified device.
- 3. World's fastest Bluetooth OBD-II adapter (baudrate:
- 4. Hacker-proof.
- 5. Free firmware updates
- 6. OBD request bytes up to 4K bytes.
- 7. Supports HS-CAN, MS-CAN, SW-CAN, CH-CAN, LS-CAN 5 CAN channels.
- 8. BatterySaver technology low power mode.
- 9. Automatic sleep & wake-up.
- 10. Superior compatibility works with more 3rd party apps & software than any other adapter.

How do I know whether my vehicle is OBDII compliant?

1996 or newer model year vehicle sold in the United States. United States legislation requires all cars and light trucks model year (MY) 1996 and newer to be OBD2 compliant.

2001 or newer model year gasoline vehicle sold in the European Union. 2004 or newer model year diesel vehicle sold in the European Union.



2. I want to know which OBDII protocols supported by vLinker MS (Bluetooth)?

√ ISO 14230-4(slow)
√ ISO 14230-4(fast) √ ISO 15765-4(CAN)
√ SAE J1939(CAN)
√ ISO 11898(raw can) √ Medium Speed CAN(MS-CAN)

3. Download & Install APP.

√ Torque Lite<Most Popular Lite Version is Free> √ OBD Auto Doctor<Excellent App, Upgrade to Pro in-App> √ OBD Fusion<Excellent 3rd Party App> V FORScan for Windows<Download from www.forscan.org>and for Android < Download from Google Play>

FORScan is a powerful software for Ford, Mazda, Lincoln and Mercury vehicles, designed to work over OBDII protocol and J2534 Pass-Thru compatible adapters.



Scan My Tesla









4. I want to know which App does vLinker MS (Bluetooth) support?

Android system can support:

Such as Car Scanner ELM OBD2, FORScan Lite, Torque Lite/Pro OBD Auto Doctor car scanner, Carista OBD2, Scan My Tesla, OBD JScan, Shift OBD, Infocar, RaceChrono, PHEV Watchdog, FasLink X, ActiveOBD DBD AutoMate, Hybrid Assistant, Harry's GPS/OBD Buddy, Harry's LapTimer, AlfaOBD, FFConfig, TrackAddict, ect. iOS system can support:

FORScan Lite

Such as FORScan Lite, FORScan Viewer, Car Scanner ELM OBD2 Shift OBD Complete, Shift OBD, Link ON, OBD Auto Doctor car scanne tes · LAX - CAN Bus Explorer, ROUSH Lap Timer, Harry's Lap Timer To Harry's Dyno, Harry's LapTimer Rookie, Harry's GPS/OBD Buddy, Harry's LapTimer GrandPrix, Harry's LapTimer Petrolhead, arry's HeavyDuty - Camper Edition, etc.



Many apps may be added to the compatibility list. Product page will be updated accordingly or contact us regarding app compatibility.

5. Plug vLinker MS (Bluetooth) into the OBD port.

The OBDII DLC is usually located under instrument panel (Dash) on the driver's side. If you want to know more about DLC, please visit:

https://en.wikipedia.org/wiki/Data_link_connector_(automotive)



6. Turn ignition to Key On, Engine Off.




7. Torque (Lite) Connection Guide for Android (for example)

Step 1: Insert the adapter into the OBD interface of the car.Turn ignition to Key On, Engine Off.

Press the "Connect" button on vLinker MS (Bluetooth)

IMPORTANT NOTE





Name "vLinker MS XXX" (Searching for luetooth may take some time.) BD2 Adapter Settings





Step 4: Select OBD2 Adapter Settings.



Step 6: Choose the connection type Bluetooth.



Step 8: If the communication is successful, you can select the control unit you want...

Step 7: Choose Bluetooth Device "vLinker MS 00003".

vLinker MS 00003 [E0:FF:F1:6F:C0:07]



8. Car Scanner Connection Guide for iOS (for example).

Step 1: Insert the adapter into the OBD interface of the car.Turn ignition to Key On, Engine Off.

Press the "Connect" button on vLinker MS (Bluetooth)





device name "vLinker MS 00003" and click Pair. (00003 is the product serial number, each product has




Note: Please select the Bluetooth Device Name "vLinker MS XXX" (Searching for uetooth may take some time.)

Step 2: Open the Bluetooth settings. Search for the a different serial number)



Step 3: Open Car Scanner APP, Click Step 4: Click" Connection".



Step 6: Return to the main page and click "CONNECT".

evice name

This may take a few minutes.





selectthe control unit you want...





Features of vLinker MS (Bluetooth)

Automatically OBD device wake up and Super Power Saving

I Allow the user to leave the vLinker MS (Bluetooth) in OBD Socket without unplug and plug operation. Supper low powerconsumption <sleep mode> is low to " 3mA" level.

√ Wake up vLinker MS (Bluetooth) in standby mode by pressing the key.

Please email to us at any time: sale@vgate.com.cn We will reply you within 24 hours of the working



Product Upgrade (PC):

To upgrade the product, please download the upgrade package

Product Upgrade (MobilePhone):



2.Open the APP to scan the same QR code to upgrade the firmware.

Vgate Forums:

and user manual of the corresponding model.



1.Scan the QR code to download "VgateFwUpdater" APP.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to

comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. -Increase the separation between the equipment and

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator &

ISED Warning:

your body.

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

(1) L'appareil ne doit pas produire de brouillage: (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS-102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 etla conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne surl'exposition et la conformité de rf.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ouémetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.