

# iCam365快速操作手册

WiFi摄像机



请务必扫描上方二维码下载“iCam365”APP

## A 连接设备



### 下载APP

使用手机的“扫一扫”功能扫描二维码，下载并安装“iCam365”APP



### 连通电源

将设备连通电源，持续1分钟左右直到发出提示音


## B 添加设备



01.登录“iCam365”APP 02.添加设备 03.扫描机身二维码 04.等待自动识别 05.选择要连接的WiFi,并输入密码 06.等待设备配置网络 09.添加完成,设备命名 完成后设备会出现在你的首页

App会不断更新,界面以App为准

## C 功能说明



报警消息 添加设备和四分屏 设备实时与回放 设置管理 与他人分享设备 更多功能 AI服务 云录像服务 更多功能 声音开关 全屏 卡回放 云回放 方向控制 对讲

App会不断更新,界面以App为准

## D 常见问题

问题	原因/解决方案
添加设备不成功怎么办?	检查WiFi密码是否正确,并且可以正确连接网络,然后复位摄像机,完成后重新添加一次。
如何将录像下载到手机中?	在回放时点击“录屏”按钮,录制一段后点击红色停止按钮,录像文件就会保存到手机;
显示设备离线怎么办?	先确认电源和网络是否正常,没有问题再给摄像机断电重启。如果重启后依然掉线,请在APP里移除该摄像机,然后重新添加。
存储卡满了,如何处理?	无需手动处理,摄像机当存储卡容量剩余小于等于500M时会自动覆盖最早的录像文件
存储卡显示无存储卡或异常	1.摄像机不支持热插拔,插储存卡的时候,需要断电,请重启下摄像机。 2.重启摄像机依然识别不到内存卡,请更换新卡再测试。 3.更换新卡依然无法识别,可能是卡槽损坏,或者是排线故障,联系供应商更换设备。
收不到告警消息怎么办?	确认系统是否关闭了iCam365的消息推送权限,如关闭请在手机设置中开启“消息通知”权限并检查在设备设置中是否关闭了消息推送。 告警消息最多保存7天


App会不断更新,界面以App为准

## A Connect the device



### Download the app


Use the "Scan" function of your mobile phone to scan the QR code, download and install the "iCam365" APP



### Connect power

Connect the device to the power supply and wait for about 1 minute


## B Add device



01.log in 02.Add device 03.Scan the QR code of the fuselage 04.Waiting for a utomatic recognition 05.Select the WiFi to connect to and enter the password 06.Waiting to configure the network 09.The addition is complete, the device is named The device will appear on your homepage

App will be updated continuously, and the interface is subject to App

## C Function Description



Alarm message Add device Live and playback Settings Share the device More features Intelligent Recognition Cloud recording Settings More settings Sound switch Recording screen Screenshot Video clarity Full screen Card playback Cloud playback Direction control Intercom

App will be updated continuously, and the interface is subject to App

## D Common problem

Problems	Solution
What should I do if the device is unsuccessfully added?	Check whether the WiFi password is correct, and the network can be connected correctly, then RESET the camera, and add it again after completion.
How to download video?	Click the "Record Screen" button during playback, and click the red button after recording, and the video file will be saved to the phone;
What if the display device is offline?	First confirm whether the power supply and network are normal, and there is no problem before powering off the camera and restarting it. If the connection is still disconnected
The memory card is full, what should I do?	No manual processing is required. When the remaining memory card capacity is less than or equal to 500M, the camera will automatically overwrite the oldest video file.
The memory card shows no memory card or abnormal	1. The camera does not support hot swapping. When inserting a memory card, it needs to be powered off. Please restart the camera. 2. The memory card is still not recognized after restarting the camera, please replace with a new card and test again. 3. If the new card is still not recognized, the card slot may be damaged or the cable is faulty. Contact the supplier to replace the device.
What should I do if I cannot receive the warning message?	Confirm whether the system has turned off the message push permission of iCam365. If it is turned off, please turn on the "message notification" permission in the phone settings and check whether the message push is turned off in the device settings. Alarm messages are stored for up to 7 days

App will be updated continuously, and the interface is subject to App

## Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement  
To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.