



FIG FLIP Phone User Manual

Android™ 8.1

Basic Operations

Switch on

Touch and hold the Power button until the phone switches on.

Note: If you have enabled USIM/SIM locking in the Settings menu, enter the correct PIN number upon power-on before you use the phone.

Caution: Three consecutive attempts of entering an incorrect PIN will lock the SIM card. If it is locked, use a PUK provided by the operator to unlock it.

Switch off

Touch and hold the Power button until the Phone Options screen displays. Tap "Power off" to switch off the phone.

Unlock

Short press the "Power button" light up the screen, according to the clues of the screen interface can be unlocked.

Touch screen Usage

Use your fingers to perform operations directly on icons, buttons, and the on-screen keypad.

Tap/Touch/Click

Tap the icon of an App to start it.

Touch & Hold

Touch and hold an item to display a pop-up menu of options. For example, go to Address Book, touch and hold a contact on the Address Book page, and a menu of options pops up.

Scroll

Similar to sweeping, but faster.

Home Screen

- 1. Notification bar:** Slide down at the top of the main screen to view notifications and shortcuts. Then you can choose or tap the “clear all” to clear the notifications.
- 2. App icon:** Tap an app to open it.

Phone Settings

To display the Settings menu, tap the Settings icon directly.

1.SIM card: In the Settings menu, choose SIM Card. You can then manage your SIM cards on the pop-up page.

2. Network: In the Settings menu, select WLAN to configure your radio network; or select Traffic usage to configure your mobile data services; or select Mobile Network under More to configure data services of your phone.

3. Sound: In the Settings menu, choose Sound. The allows you to set the volume, enable/disable vibration during ringing, and select ring tones for incoming calls and messages, as well as enable/disable keypad touch sound effect, touch alert tone, and screen lock tone

4. Display: allows you to configure the brightness, wallpaper, sleep duration, and home UI switch.

5. Security& Location: In the Settings menu, choose Security. The Security page allows you to set the screen locking mode and privacy. **App Permission:** allows you to configure certain permissions for an App and monitor their usage.

6. Apps & Notifications: In the Settings menu, choose Apps. Then you can view or manage your apps.

7. FIG Messages app: Access by pressing the message button on the keypad.

On the Message page, tap the “+” button on the bottom right of the screen to start a new message.

When messaging a friend hit the “+” button on the left of the input field to attach a contact, schedule a message for the future, attach a photo or take a photo. Tao the phone icon on the top right of the screen to call that contact.

Call

To initiate a call, start dialing a contacts name from the home screen.

Choose a contact and hit the call button to call. Additionally, while a contact is selected you can tap the menu button to send a message, edit contact or go to call history.

You are also able to initiate a call by selecting a phone number from the contacts app or from a sms thread.

Missed Call: If you missed a call while your phone was shut, you can view the missed call in the following ways. Open the phone and either swipe down from the top of the screen to bring up notifications drawer or press the “call” button from the home page to view the missed call in the “recent calls” screen.

Contacts

Tap Contacts to open it. The Contacts page offers management functions. It allows you to view the list of contacts and related details, make a call or send an SMS to a certain contact, and share the contact.

Contact import: On the Contacts page, tap the Menu button, and choose Import/Export to select a mode for importing or exporting a contact.

Add a contact: On the lower right of the Contacts page, tap the create new contact button to add a contact to your phone or USIM/SIM. Enter the name and number, and tap Finish. In this way, a contact is created.

Contact list: On the Contacts page, tap any of the contact info. Details about the contact is displayed. This allows you to quickly make a call or send an SMS to the contact.

Search contact: On the Contacts page, tap Search, and enter related information about a certain contact to search it among the list of contacts.

Message

We're proud to announce that the current version of the phone boasts the newly launched FIG Messages app.

New message:

a) Tap the Add icon on the upper right of the Message page. The message creating page is displayed. Enter the name or phone number of the target contact into the Recipient bar. The phone will automatically search among the list of contacts for one that best matches the entered info. (You can also select the contact from the list of contacts or groups.)

b) Additionally, you can start a new message by typing out the contact's name from the home screen. From the search results, navigate to the desired contact, press the menu button and then select "message".

Input method: Tap the text editing zone to invoke the on screen keyboard. Short press the # key to switch your input method.

Send: After an SMS is complete, tap Send and choose between card 1 and card 2 for sending the SMS.

Gallery

Gallery saves and manages all pictures obtained via the camera, Internet, and the MMS received.

On the Home screen, tap Gallery to open it. The Gallery page is displayed. It supports management of all pictures.

Open a picture and then click the share button at the top. In this way, the picture is shared via the Bluetooth, message, and mail.

Multimedia Function

The phone also supports many multimedia functions, such as camera, music, and recorder. Tap any icon of theirs to open any one of them.

APP Switcher

To activate this function; Long press the right side button of the phone. This function allows you to quickly switch between screens and close down apps.

Switch Keyboards

The FIG Flip has two input methods. A T9 traditional keyboard and an on screen touch keyboard.

To disable or enable one or more of the keyboards navigate to the system menu in settings. In “Language & Input” you can toggle keyboard on/off.

Troubleshooting

To save time and avoid unnecessary cost, please conduct the following checks before contacting our after-sale personnel:

1. Unable to turn on the phone: Check whether you have tapped and hold the Power button for over three seconds. Check whether the battery is in good contact. If not, remove the battery, re-install it, and turn on the phone again. Check whether the battery runs out. If yes, charge it.

2. Poor signal: It is possibly because of where you are, for example, on the basement or near a high-rise, that deteriorates the reachability of radio waves. Please move to someplace with better signal reachability.

3. Echo or noise: The network trunk line of certain carriers may be in poor quality. Please tap the hang-up icon and redial, so that you may switch to another trunk line with better quality.

4. Unable to charge the battery: Your battery may fail. Please contact the dealer.

5.SIM card error: The metal surface of the SIM card is dirty. Rub the metal contact terminals with a clean dry cloth.

The SIM card is not installed properly. Install it again as specified in the user manual.

The SIM card breaks down. Contact the network service provider.

6. Unable to enter anything into Phone Book: This is possible because that your phone book memory is full. Please delete needless data from Contacts.

We advise you to follow above instructions and precautionary measures. Please take your phone to the nearest authorized service center when it does not operate normally.

The actual situation of the phone usage is related to local environment, SIM card and way of use.

FCC Warning

This device complies with part 15 of the FCC Rules.

Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This 4G phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: F26 (FCC ID: 2A6B4-FIGF26) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.470W/kg and when properly worn on the body is 1.335W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components.

Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.