


S100 Pro 说明书  
 尺寸: 120mm x 170mm  
 80g书写纸, 黑白印刷, 折页, 双面印  
 料号: 416-D33PL091-WOR



**USER MANUAL**

Hi!  
Let's get started.

Model: S100 Pro

### Important Safety Instructions

- Read these Instructions.
- Keep these Instructions.
- Read all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.


**Special note:** When placing your unit on a lacquered or natural finish, protect your furniture with a cloth or other protective material.

**Additional Warnings:**  
 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.  
 L'appareil ne doit pas être exposé aux écoulements ou aux éclaboussures et aucun objet ne contenant de liquide, tel qu'un vase, ne doit être placé sur l'appareil.


Caution marking is located at the rear or bottom of the apparatus.  
 Attention: marquage est situé sur le panneau arrière ou inférieur de l'unité.  
 The marking information is located at the rear or bottom of apparatus. Le marquage est situé sur le panneau arrière ou inférieur de l'unité.

### 1 What's in the box


Make sure you read all the safety information before you use this product.



### 2 Overview



### 3 Install the subwoofer




Connect the subwoofer cable to the subout port on the bar.

### 4 Sound Bar LED Indicator


--	Standby Mode	0-32	Volume 0-32
DPE	Optical Input	E9 1	Music Mode
USB	USB Input	E9 2	Movie Mode
RUH	AUX Input	E9 3	News Mode
bt	BT Input	F 1	Light Dynamic Mode Switch
C 1 ~ C 7	Color Switch	b-3 ~ b03	Bass Intensity -3 ~ 3

### 5 Install or replace the remote batteries

Battery type: 1.5V AAA Alkaline battery x 2 (Battery not supplied, please use yours)



### 6 Using the Remote



### 7 Using & Connect to your TV


#### 7a Optical

Step 1, Turn off the sound bar and TV, connected the sound bar to the TV through the optical cable. **(Remove the white cover on cable).**

Step 2, Turn on the sound bar, press the "INPUT" on the sound bar remote, then select the input mode "OPT" which is shown on the LED display.

Step 3, Turn on the TV, press the home on the TV remote, go to **TV setting** → **audio(sound)** → **TV speaker** → select **external speaker** or turn off **TV speaker**, save the **setting**, then back to **audio** (sound setting) → select **expert setting** → **digital audio output** (or optical output) → select **PCM** (some TV called **SPDIF** or **optical**). Save the **setting**.

Step 4, Play TV show to test the sound bar.



**Kindly Note:** for optical connection, please change TV audio output to PCM (or SPDIF and optical) and external speaker (refer to page 8), otherwise you will get cracking noise or no sound.

TV Brand	Setting Steps (PCM & ARC Setting)
Samsung	Settings > Sound > Sound Output > Select Receiver (HDMI) Settings > Sound > Expert Settings > Digital Output Audio Format > PCM Settings > General External Device Manager > Anynet+ (HDMI_CEC) > ON
Vizio	Settings > Audio > TV Speakers > OFF Settings > Audio > Digital Audio Out > PCM Settings > System > CEC > Enabled
Sony	Settings > Display & Sounds > Audio Output > Speakers > Audio System Settings > Display & Sounds > Audio Output > Digital Audio Out > PCM Settings > Display & Sounds > Audio Output > Pass Through Mode > OFF Settings > Channels & Inputs > External Inputs > BRAVIA Sync > BRAVIA Sync Control > ON
LG	All Settings > General Devices > HDMI Settings > SIMPLINK (HDMI_CEC) > ON All Settings > Sound > Advanced Settings > Digital sound output > PCM All Settings > Sound > Sound Out > Use Wired Speaker > HDMI (ARC) Device
TCL ROKU	Settings > Audio > Digital Audio Format > Select Stereo
Hisense ROKU	Settings > Audio > TV Speakers > Select Disabled Settings > Audio > Digital Audio Out > Select Stereo
ONN ROKU	Settings > Audio > TV Speakers > Select Disabled Settings > Audio > Digital Audio Format > Select Stereo
Toshiba/Fire/Amazon Fire 4 Series and Chris Series /Roku Fire	Settings > Display & Sounds > Audio Output > TV Speakers > Select OFF Settings > Display & Sounds > Audio Output > Digital Audio Format > Select PCM Settings > Display & Sounds > HDMI CEC Device Control > ON
TCL (Powered by Android)	TV Settings > Audio > Advanced Settings > Digital Audio Out > Select PCM TV Settings > System > T.Link > Select ON
Hisense (Powered by Android)	Settings > Sound > Speakers > Select ARC Settings > Sound > Advanced Settings > Digital Audio Out > Select PCM
Sharp	Settings > Sound > Advanced Audio Settings > TV Speaker & ARC > Select ARC Settings > Sound > Advanced Audio Settings > Digital Audio Out > Select PCM
Panasonic	Menu > Audio Settings > Advanced Audio > TV Speakers > Select OFF Menu > Audio Settings > Advanced Audio > HDMI > Select DIGITAL Menu > Audio Settings > Advanced Audio > HDMI > Select DIGITAL
Sharp (Powered by Android)	Settings > Devices Preferences > Sound > Digital Audio Out > Select PCM Settings > Devices Preferences > Sound > Speakers > External Audio System
ROKU TV Stick	Settings > Audio > Digital Output Format > Stereo Settings > Audio > Audio Mode > Select Stereo
Fire TV Stick	Settings > Display & Sounds > Audio > Surround Sound > PCM Settings > Display & Sounds > HDMI CEC Device Control > ON

**Kindly Note:** TV settings may differ according to TV models difference, if the listed method can not work, or your TV is not listed, please contact us via service mail: [support@wohomeshop.com](mailto:support@wohomeshop.com), or contact the TV manufacturer for help, thank you!


### 7b AUX

Step 1, Choose line in cable (3.5mm to 3.5mm) or RCA cable connect the soundbar to your TV.

Step 2, Turn on the sound bar, press the "INPUT" on the sound bar remote, then select the input mode "AUX" which is shown on the LED display.

Step 3, Turn on the TV, press the **home** (or menu) on the TV remote, go to **TV setting** → **audio(sound)** → **TV speaker** → select **external speaker** (turn off TV speaker), save the **setting**. (For some TVs, please back to **audio(sound)** → select **analog output** → select the **Variable**, save the setting).

Step 4, Play TV show to test the sound bar.




3.5mm to 3.5mm cable (supplied)

### 7c BT

The BT connection


- Press the "INPUT" on the sound bar remote, then select the input mode "BT" which is shown on the LED display, the "BT" will be flash.
- Turn on BT on the BT device. (see the device's manual for more information)
- Select "**Soundbar S100 Pro**" from the device BT list, connect it. When your BT device is connected, the LED display will stop flash.
- Play music from the BT device to test the sound bar.



**Kindly Note:** only for **USB flash drive** to play MP3 music and update firmware, can not compatible with other USB devices.

### 7d USB

- Connect your USB drive to the USB jack on the soundbar.
- Press the "INPUT" on the sound bar remote, then select the input mode "USB" which is shown on the LED display.
- Play music to test.



**Kindly Note:** only for **USB flash drive** to play MP3 music and update firmware, can not compatible with other USB devices.

### 8 Specifications

Model	S100 Pro
Power Supply	DC18V
Speaker	(58mmx98mm)x2PCS+5.25" Subwoofer x1
Volume Level	0-32
BT Version	5.0
Distortion	<1%
Product Weight	10.3lb
Product Dimension	Soundbar: 15.9(L)x3.54(D)x2.87(H) inch Subwoofer: 5.5(L)x8.3(D)x13.7(H) inch

### 9 Dynamic Lights

**Light on/off Button:** short press: light on (bright) → low light → light off

**Color Change Button:** short press: white light → purple light → blue light → yellow light → pink light → colorful breathing light → colorful flow light

**Dynamic Light Button:** short press: OFF → F1 (Dynamic Light Mode 1) → F2 (Dynamic Light Mode 2); the brightness of the light changes with the rhythm of the music, bringing you an immersive effect. (Dynamic light button need to work with color change button, you can select different color to fluctuate)

**Kindly Remark:**  
 \* Solid color static light as background light can protect your eyes when you watch TV programs.  
 \* Dynamic light especially suitable for parties and bars, the combination of music and lighting brings a wonderful experience.

### 10 FAQ and trouble shooting

**Q1, Cracking or popping sound or Static sound when optical connection:**  
**Answer:** Press the home (or menu) on the TV remote, go to TV setting → audio (sound) → TV speaker → select external speaker (turn off TV speaker), save the setting, then back to audio (sound setting) → select expert setting → digital audio output (or optical output) → select PCM (some TV called SPDIF or optical). Save the setting, then try again. More detail, refer page 8, or your TV manual.

**Q2, Cracking noise or static sound when see a video from Youtube, Netflix, HBO, Amazon Prime or other streaming video APPs:**  
**Answer:** Please disable the Dolby and DTS on your APPs or TVs, if you do not know how to set, please contact the APPs support or us for help.

**Q3, Sound is not synced with the picture.**  
**Answer:** Please press the menu or home button on the TV remote go to the TV setting → sound (audio) → select sound (audio) delay → adjust the delay time to try, this will fix the issue.

**Q4, Why soundbar is very weak?**  
**Answer:** Please kindly note the max volume of this soundbar is very loud, there are several Answers that you can try to fix the problem:  
 1, Please make sure your sound source volume is high, if the sound source is in low volume, you will not get loud sound, so we suggest you adjust the TV and APPs volume to max  
 2, Adjust the soundbar volume to max to test again  
 3, Please kindly use your phone to connect the soundbar through to play the music to test the sound.  
 4, Please unplug and plug the adapter to restart the soundbar to test again.  
 5, Disable the hearing protection setting on your devices such as phone, tablet, TV.

**Q5, Why sound quality is poor?**  
**Answer:** Please kindly note the soundbar we offered is entry-level, for small rooms not for Audiophile, can not be compared to the soundbar priced at \$200 or above. If the sound quality is very poor, you may receive the defective unit, please contact us, we will guide you to update the firmware to fix the issue.

**Q6, May I connect the sound bar to Amazon Echo?**  
**Answer:** Sure, you can connect this soundbar to your Amazon Echo through BT connection, please scan below QR code to find the connect method  
**Kindly Note:** Except the BT, you can also use the aux cable to connect the soundbar to your Amazon echo dot. (Please note BT connection only for music play, the soundbar DOES NOT have the built-in Alexa)

**Q7, Soundbar can not turn on.**  
**Answer:** Please use the attached adapter to connect the speaker to the socket, wait about 3 seconds, the LED display will show "--", press the "POWER" button on the remote to turn on the speaker. If the LED display does not show "--", it means that the adapter is dead, please contact us and we will send a new adapter to you soon.

**Q8, May I connect the soundbar to a headphones?**  
**Answer:** Please note both headphones and soundbar can only receive the audio signal, can not output, so you can not connect the soundbar to headphones to play music.


### 7a Optical

Step 1, Turn off the sound bar and TV, connected the sound bar to the TV through the optical cable. **(Remove the white cover on cable).**

Step 2, Turn on the sound bar, press the "INPUT" on the sound bar remote, then select the input mode "OPT" which is shown on the LED display.

Step 3, Turn on the TV, press the home on the TV remote, go to **TV setting** → **audio(sound)** → **TV speaker** → select **external speaker** or turn off **TV speaker**, save the **setting**, then back to **audio** (sound setting) → select **expert setting** → **digital audio output** (or optical output) → select **PCM** (some TV called **SPDIF** or **optical**). Save the **setting**.

Step 4, Play TV show to test the sound bar.



**Kindly Note:** for optical connection, please change TV audio output to PCM (or SPDIF and optical) and external speaker (refer to page 8), otherwise you will get cracking noise or no sound.

For more information, please follow us:

Web: [www.wohomeshop.com](http://www.wohomeshop.com)  
 Email: [support@wohomeshop.com](mailto:support@wohomeshop.com)

**NOTE:** One year warranty, 45 days money back guarantee, lifetime technical support, 100% satisfaction service, please feel free to contact us for any questions.

**FCC Warning**  
 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
 Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.  
 If this equipment does cause harmful interference to radio or television reception, you can try to correct the interference by one or more of the following measures:  
 --Reorient or relocate the receiving antenna.  
 --Increase the separation between the equipment and receiver.  
 --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 --Consult the dealer or an experienced radio/TV technician for help.  
 The device has been evaluated to meet general RF exposure requirements. The device can be used in portable mode without restriction.