

60MM

# Wisdene

Model: BL006

## Ultra Thin Anti-Lost SmartCard (LOCATE YOUR VALUABLE ITEMS)



### INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

75MM

### Getting Started

- Remove the product from the packaging.
- Please retain all packaging after you have checked and counted all the parts and the contents against the parts list.

### Package Contents

- WiCard
- Instruction Manual

### Key Features

- Smart Finder
- Uses Apple Find My App to locate your device
- Locate from iPhone, iPad, iPod Touch or Mac computer
- Simply attach the device to your keys, wallet, purse and you can start locating it remotely from your App
- Rechargeable battery
- Siri compatible


### Safety Instructions

- Keep the unit away from heat sources, direct sunlight, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This appliance is not a toy.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

### Specifications

- Size: 54x85.6x1.7mm
- Suitable for: Keys, Wallet, Purse or other belongings
- Battery: Lithium Polymer battery
- Standby time: About 6 months (Rechargeable)
- Net weight : 11.7g
- App Name: Find My
- Waterproof level: IPX8

### Description of Parts





### Battery Rechargeable

- When battery is drained, charge it with any wireless charger that meets the Qi standard.
- Smart Finder includes a built-in rechargeable 100MAH Lithium Polymer battery.
- The LED light in red when charging, change to green light when fully charged.

### Instructions for Use



- **Switch on/off the unit**  
**Switch on:** Short press the function button once and you'd hear a ring chime, indicating it is powered on and will be in pairing status.  
**Switch off:** Long press the function button for three seconds, it should beep twice, indicating it is powered off.

### Add your Smart Finder to the Find My App





1. Open "Find My" App on your supported iPhone, iPad, iPod Touch or Mac computer.
2. Allow notifications from the App.

3. Select "Items" at the bottom, then tap "Add Other Item" or tap on "+" icon directly.
4. Select "Other Supported Items"



5. Make sure your Smart Finder is close to your phone. It will pop-up "Searching Items".



6. You will see pop-up "WiCard", then tap "Connect".



7. Follow the pop-up to fill name, and select an emoji, then tap "Continue".



8. When "This Item is Linked to Your Apple ID" pops-up, tap "Agree"



9. Tap "Finish" to finish your Smart Finder set-up.



### Function Introduction

- **Find Items** - Tap "Play Sound" to make your Smart Finder beep when it is nearby.
- **Find your Item's location** - Your Smart Finder's last known location will appear on the map as emoji you choose during set-up, tap "Directions" to navigate to the last known location.

### Notifications

- Enable the "Notify When Found" toggle, when your Smart Finder's location is seen by another "Find My" enabled device, you will receive a notification of its updated location.
- Enable the "Notify When Left Behind" toggle, you will receive a notification when you leave your Smart finder behind and it is no longer in range of your device.

**Note:** "Notify When Found" can only be activated when your Smart Finder is out of range.



### Lost Mode

- When your Smart Finder is lost under "Lost Mode", tap the "Enable" tab, a screen calling Lost Mode will pop up, tap "Continue". You can enter your phone number or email address and tap "Next".
- You may enter a message that will be shared with the person that finds your Smart Finder.
- Tap "Activate" to enable "Lost Mode".

### Note:

- When "Lost Mode" is enabled, "Notification When Found" is automatically enabled.
- When "Lost Mode" is enabled, your Smart Finder is locked and cannot be paired to a new device.

### Rename Item

- Name of the Smart Finder can be renamed.

### Remove Item



- Make sure "Lost Mode" is disabled and click "Remove Item". After selecting the option, the system will pop up "Remove Item?" and click "Remove" to remove the device.
- The Smart Finder is now reset and ready to pair to a new device.

### Share This Item

- Tap "Add Person" to share this item
- Tap "Continue" and select related people to share.
- Tap "Share" and wait for related people to confirm your invitation.

Others also can locate this item. And tracking notification will be muted.

\*Available for iOS 17 above version.



### System Requirements and Compatibility

- Apple ID
- iPhone models with iOS 14.5 or later.
- iPad models with iPadOS 14.5 or later.

### About the Find My App

The Apple Find My network provides an easy, secure way to locate this item using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

### Learn More

- This item can be located by its owner using the Find my app. For more information, follow the instructions below.
- Locate the button the side of the device.
- Press the button twice. You will hear a confirmation sound.
- Tap "Continue On Website" for more information including any Lost Mode message from the owner.

### How to Disable

- Locate the button on the side of the device.
- Long press the function button three seconds until two beeps are heard. This will stop sharing the location of this Smart Finder.

### Factory Reset

- Press the button 4 times rapidly and then hold it a fifth time until you hear a ringing chime.

• A reset operation is required to enable the device to enter the pairing state again (synchronization of Find My also requires simultaneous unbinding) and rebind the new Apple ID account.

### How can I prevent my device from being used for malicious tracking

When someone else's device mixes with your belongings, and tracks it over a period of time, you will be reminded in below two ways:

- If you have an iPhone, iPad, or iPod touch etc Apple device, you will get alerts on your Apple device. This feature is available on iOS or iPadOS 14.5 version or above.
- If someone else's device finds its way into your stuff, your iPhone will notice it is traveling with you and send you an alert. After a while, if you still have not find it, the Smart Finder will start playing a sound to let you know where it is.

### Important tips:

When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended.

- Change the phone's network, such as switching between Wi-Fi and mobile. The first pairing may take a long time, please wait patiently.
- Reset your Smart Finder.
- When "Lost Mode" is enabled, DO NOT REMOVE ITEM in the APP. Your this item will be locked and cannot be paired to a new device.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

### Care and maintenance

Read the following recommendations before using the unit. Following these you will be able to enjoy the product for many years.

- Don't expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the unit.
- Don't expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the unit in fire as it will result in an explosion.
- Don't expose the unit to contact with sharp objects as this will cause scratches and damage.
- Don't let the unit fall down onto the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the unit as it may get damaged if you are not professional.

### FCC Instructions

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

**NOTE:** This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

**NOTE:** This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause

harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2A6W7-BL006