

FINGERPRINT CABINET LOCK

USER MANUAL




Feature

1. Biometric sensor, high sensitive and rapid responsive
2. Max 20 fingerprints to hold for multiple users
3. E-Key for emergency key and management
4. ABS panel with elegant design
5. surface mounted, widely used in drawer, cabinet, wardrobe etc.

Automatic Mode

1. How to add new fingerprints

- Put a finger on sensor, green light and latch retracts, holding, green light and latch comes out, keep holding, green light on, then remove
- Blue light, put a finger on, green light then remove
- Put the finger on, green light then remove; repeat until a long green light for 2 seconds (The fingerprint is registered)
- Blue light, add more new fingerprints




Note

- 1). Make sure add the fingerprint before using. Any finger can unlock in the factory setting
- 2) In order to keep the lock work well, to add no less than 3 fingerprints

2. How to delete fingerprints

- Put any registered on sensor, green light, holding, green light again, keep holding, green light then red light flashed, then remove
- green light for 2 seconds, all the fingerprints deleted



3. How to lock

- Push the door closed, door lock automatically

4. How to unlock

- Put any registered fingerprint on sensor
- Green light, unlocked
- Pull the door open

Other Function

E-Key

1. Insert E-Key
2. Put any finger on sensor, green light flashes twice, unlocked
3. Pull the door open



2. Low battery warning

In case of low battery, to put on the registered fingerprint, green light flashes once, and red light flashes thrice, then a long green light, unlocked. To change the battery immediately after door open

Note: Use 3XAAA alkaline battery, not take carbone battery

3. Outer Power Supply


When low battery, can connect power bank or mobile plug for outer power supply

After unlocked, change the battery immediately




Installation Instructions

1. Put the installation drawing on the door, approx. 45mm between the door frame and center hole (Picture 1), then drill the hole




Picture 1

wire connection




	Door Thickness (mm)	Screw
1	14mm~16mm	ST2.6x10
2	17mm~21mm	ST2.6x14

- 1) Insert connecting wire (See picture 2) into the front panel, then wire goes through the centre hole; Fix the panel by screw ST2.6X10 and washer
- 2) Fix the washer to the door panel with screws ST3 X10
- 3) Insert connection wire (See Picture 2) into lock case, then fix by screw ST3.5X16MM. Make sure the distance is 40MM between the centre of back panel and opening wall



Picture 2

3. Fix the striking plate by screw ST3.5X20 (Make sure latch works well)




Picture 3

COMPONENT



INSTALLATION DRAWING



Follow the drawing to drill the hole

F040产品说明书附加页

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.