



User Manual

Smart Gooseneck Kettle Pro

Contents

Important Safety Instructions	01
Included in the Box	02
Introduction	03
Operation	05
Govee Home App	06
User Servicing Instructions	07
Pour Over Coffee Brewing	08
Recommended Temperatures	08
Troubleshooting	09
Appendix	10
Compliance Information	11

Important Safety Instructions

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all Instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock and injury to persons do not immerse cord, plugs, power base or bottom of the kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock or injuries to persons.
- Do not use outdoors. Household use only.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.

Save these Instructions.

Power Cord & Plug

- A short power-supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
- Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- If a long detachable power-supply cord or extension cord is used:
 - a. The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance;
 - b. This kettle has a 3-prong grounding plug. Any extension cord should be a grounding type 3-wire cord;
 - c. The longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over.

- Never use the cord as a handle or otherwise yank, strain or stretch the power cord. Do not allow the cord to touch hot surfaces.
- Place the kettle near the plug, so that it can be unplugged immediately from power if an emergency occurs.
- Do not operate this kettle with a damaged cord or plug. Discard the kettle or return to an authorized service facility for examination and/or repair.
- Do not cover the cord with throw rugs, runners, or similar coverings. Do not route the cord under furniture or appliances. Arrange the cord away from high traffic areas and where it will not be tripped over.
- If the power cord or the plug is damaged, please contact customer service for repair or similar professionals to avoid danger.

Note: If the electrical circuit is overloaded with other appliances, your kettle may not operate properly. Operate it on a separate electrical circuit.

Risk of Electric Shock & Leakage

- Do not insert any foreign objects in the air inlet or outlet when the kettle is powered on, as this may damage the kettle itself and cause electric shock or fire.
- If any part of the kettle is damaged in operation, contact customer service or professionals for repair or replacement. Do not risk repairing or replacing by yourself.

WARNING: To reduce the risk of electric shock, do not expose the kettle to water or rain.

Included in the Box


Item	Quantity
Gooseneck Kettle	1
Power Base	1
User Manual	1
Quick Start Guide	1

Introduction

The GoveeLife Smart Gooseneck Kettle Pro comes with a precise LED screen. It is your best brewing companion designed to help you customize the temperature to brew your favorite coffee or tea like a professional, achieving the best taste and aroma. Every cup makes your daily life more intelligent.

Part Names

- a. Lid
- b. Steam Vents
- c. Spout
- d. Kettle Body
- e. Handle
- f. Heating Plate
- g. Control Panel
- h. LED Screen
- i. Power Base
- j. Power Cord



Controls

ON/OFF Button

Press to turn the kettle on or off. When powered back on, the kettle will restore to the mode, hold temperature, and DIY set previously.


MODE Button

Press to cycle through **COFFEE**, **BLK/BOIL**, **GREEN**, and **OOLONG**:

- **COFFEE (205°F)**: Sets the kettle to 205°F/ 96°C, the ideal temperature for coffee.
- **BLK/BOIL (212°F)**: Sets the kettle to 212°F/ 100°C, the ideal temperature for black tea or boiled water.
- **GREEN (180°F)**: Sets the kettle to 180°F/ 82°C, the ideal temperature for green tea.
- **OOLONG (195°F)**: Sets the kettle to 195°F/ 91°C, the ideal temperature for oolong tea.

Note:

- The mode set during last use will still be active when the kettle is powered back on.
- The target temperatures of the four modes can be adjusted in Govee Home App and synced to the device buttons.



DIY Button

Press to turn the DIY Mode on or off to adjust the temperature as you like. The default temperature of DIY Mode is 170°F/ 77°C, which can be adjusted via Govee Home App.

Note:

- DIY and MODE cannot operate at the same time.

HOLD Button

Press to turn the HOLD function on or off to maintain or cancel the temperature mode you have chosen.

ON/OFF + MODE

Press and hold the ON/OFF Button and the MODE Button simultaneously for 5 seconds to restore to factory settings.

HOLD + DIY

Schedule/Timer: When the kettle is plugged in and connected to Wi-Fi without any boiling tasks, long pressing the HOLD and DIY Button for 3 seconds will activate the schedule function. The temperature and time will stay the same as set in the recently scheduled task. Adjust the schedule in the app if necessary.

Note:

1. If the Schedule/Timer function is successfully activated, the clock icon on the screen will flash and then remain solid while the target temperature is displayed on the screen.
2. If the Schedule/Timer function is not successfully activated, the clock icon on the screen will flash and then go out. You might need to activate the Schedule/Timer function again.

Functions

Memory Function

The kettle will save its previous settings when powered off. When it is powered back on, the settings will resume.

Smart Function

Connect this kettle to Govee Home App via Wi-Fi or Bluetooth to enjoy DIY modes such as customizing temperatures, keeping warm, setting a delayed start, or setting a countdown.

Boil-Dry Protection


The kettle will automatically switch off its heating element when there is no water left in the kettle. Please allow the kettle to cool for some time before adding water into it.

Operation

Getting Started

A water test is needed when first used to make sure the kettle is working properly.

1. Remove all packaging from the kettle and its accessories.
2. Place the kettle on a dry, level surface.
3. Open the lid, run water into the kettle until it passes the MIN fill line (0.5L) but does not sit higher than the MAX fill line (0.8L), and then close the lid tightly.
4. Plug the power cord into a polarized 120 V AC wall outlet.
5. Press the ON/OFF Button on the control panel to turn on the kettle.
6. When the MODE indicator is flashing, press the MODE Button to switch the kettle to BLK/BOIL (212°F). The indicator will then switch to solid to indicate the BOIL status.
7. The kettle will automatically turn off once it finishes boiling. Let the kettle cool for a little while before pouring out the hot water inside, and then rinse out the kettle thoroughly 2 to 3 times with cold water.



Using Your Kettle

Note:

- It is recommended to use distilled water for perfect pour-over brewing.
 - Make sure there is always some water left in the kettle during use. Otherwise, the kettle will automatically turn off and all the buttons on the control panel will be disabled.
1. Open the lid and run water into the kettle until it reaches but does not sit higher than the MAX fill line.
 2. Close the lid tightly.
 3. Plug the power cord into a polarized 120 V AC wall outlet.
 4. Press the ON/OFF Button on the control panel to turn on the kettle.
 5. Press the MODE Button to cycle through the 4 temperature modes and select your desired temperature, or press the DIY Button to select the temperature set in the DIY Mode. The default DIY temperature is 170°F/ 77°C, which can be adjusted via Govee Home App.
 6. Optionally, press the HOLD Button at any time before the kettle finishes heating. This will start or cancel the HOLD function that maintains the chosen temperature mode for 30 minutes.

Note:

1. The HOLD function works for 30 minutes by default. This time period can be adjusted via the app.
2. If the kettle is taken off its base when the HOLD function is active, the ON/OFF Button will flash red. If the kettle is placed back on the base within 3 minutes, it will continue to work. Otherwise, the kettle will automatically turn off.
3. When the water reaches the selected temperature, the kettle will beep 3 times and stop heating.

For High Altitude Users

Water boils at a lower temperature at high altitude. Therefore, it is recommended to select the preset boiling point to boil water within the corresponding altitude ranges.

Altitude	Preset Boiling Point
3,881–9,255 ft/1,183–2,820 m	COFFEE 205°F
9,256 ft/2,821 m and above	OOLONG 195°F

Smart Alerts

Status	Indicator / LED Screen	Display	Beep
Finished Boiling	ON/OFF	/	3 Times
Kettle is not Properly Placed on the Power Base	LED Screen	"—" and Flashes White	/
Boiling Dry		"—" and Solid White	10 Times

Note:

- The app will send you an alert notification when the kettle finishes boiling or is running out of water.
- The audible beeping alerts can be turned off in the app.

Govee Home App

You can access more features using Govee Home App.

Downloading Govee Home App

To download Govee Home App, scan the QR code or search for “Govee” in the Apple App Store® (iOS) or Google Play Store (Android).



Govee Home App



Note:

- Choose “Allow” to the permissions requested when opening Govee Home App for the first time. These permissions allow the app’s features to function normally and are not used to record personal, private information.
- Due to ongoing updates, Govee Home App may be slightly different than shown in this manual. In case of any differences, always follow the in-app instructions.

Pairing with Govee Home App

1. Turn on your smartphone's Bluetooth.
2. Open Govee Home App, tap the "+" icon in the top right corner and search for "H7175."
3. Tap the device icon and follow the on-screen instructions to complete pairing.

Note:

- Method to turn off Bluetooth and Wi-Fi connection: Press and hold the ON/OFF Button and MODE Button for 5 seconds to restore the device to factory settings. For the next device connection, please make sure to delete the device on the app.
- You can use Govee Home App to connect your kettle to Amazon Alexa or Google Assistant. Follow the in-app instructions to connect to each voice assistant.
- Govee Home App is being continually updated and its features do expand.

User Servicing Instructions

This appliance requires little maintenance from the user as it contains no user serviceable parts. If necessary, any servicing or repairs must be done by qualified personnel.

Cleaning

Please follow the steps to clean the kettle regularly:

1. Unplug the kettle from power and allow it to cool before cleaning.
2. Use a soft, damp cloth to wipe the kettle body and its power base. Make sure that the electric socket on the underside of the kettle is kept dry.
3. Dry all parts after every use.

Note:

- Do not use abrasive cleansers.
- Never immerse the kettle or its power base in water.

Descaling

If scale deposits build up inside the kettle, please follow the steps to descale it. Otherwise, temperature consistency may be affected and boiling times will be longer.


1. Squeeze half a lemon or add half a cup (about 118mL) of distilled vinegar into the kettle.
2. Add 2 cups (about 473mL) of fresh water. Boil the mixture.
3. Let the mixture cool for 15 minutes to loosen the deposits, and pour it out.
4. Use a soft damp cloth, sponge, or brush to clear off any remaining deposits.
5. Rinse thoroughly with fresh water.

Note: To avoid scale deposition, please descale regularly (approximately every 15 uses).

Customizing the Lid Tension

If the lid is too easy or too difficult to remove from the kettle, please follow the steps to adjust the tension.

1. Remove the lid from the kettle.
2. Use a tool to push in or pull out the tab to adjust the tension. If you push in the tab, the lid will have less tension and can easily be closed or taken off. On the contrary, pulling out the lid will have more tension, which means it will be harder to close and take off the lid.
3. Close the lid to check if the adjustment works.
4. Repeat the previous two steps until you find the right tension.



Pour Over Coffee Brewing

1. Measure about 6 ounces/170ml of purified water for each cup you intend to brew.
2. Pour the measured water into the kettle, turn on the kettle, and press the MODE Button to select COFFEE (205°F) to boil the water.
3. Grind two tablespoons of coffee beans for each cup.
4. Rinse the filter cone, the filter, and the serving vessel with hot water to preheat, and assemble them together.

Note: Pour some hot water to wet the filter to remove any paper taste and let it closely fit the cone.

5. Add coffee grounds into the filter.
6. When the water boils, take the kettle off the power base and pour the water into the filter.
7. Stir the coffee grounds just a bit to make sure they're all saturated. A slow and steady pour makes the best extraction from the grounds.

Note: You may need to pour two or three times depending on the grind, the filter size, and the amount of coffee being made.

8. When finished, remove the filter and enjoy your favorite cup of coffee or tea!

Recommended Temperatures

Beverage	Target Temperature
Black Tea/Fruit Tea/Herbal Tea	212°F / 100°C
Coffee	205°F / 96°C
Green Tea	180°F / 82°C
White Tea	170°F / 77°C
Oolong Tea	195°F / 91°C
Cereal	195°F / 91°C
Cocoa	190°F / 88°C
Baby Formula	113°F / 45°C

Troubleshooting

The troubleshooting section below is for solving frequently asked questions. If your problem persists, please contact Customer Support.

For Gooseneck Kettle Pro

Problem	Possible Solution
The kettle cannot be powered on or respond to any button press.	The kettle is not plugged in. Plug it into an outlet.
	Check to see if the power cord is damaged. If so, stop using the kettle and contact Customer Support.
	Plug the kettle into a different outlet.
	The kettle may be malfunctioning. Contact Customer Support.
No beeping sound when the kettle finishes boiling or is running out of water.	Check if the beeping alerts have been turned off in the app. If not, contact Customer Support.
The temperature does not rise when the kettle is working.	The higher the altitude, the lower the boiling point. At high altitudes, water takes longer to boil.
	If the temperature still does not rise, even when the kettle has been working for a while, please contact Customer Support.
The kettle has water and the LED screen displays “—” and stays solid white when the kettle is boiling water.	Stop using the kettle and contact Customer Support.
LED screen displays error code E1, E2.	Unplug the kettle. Make sure the water in the kettle is above the MIN fill line. Wait a few minutes for the power base and kettle to cool down before plugging into power and starting the device again. If the error code persists, please contact Customer Support.
LED screen displays “---” and remains solid white.	The kettle is running out of water or is boiling dry. Allow the kettle to cool down for a while and add enough water to restart.
LED screen displays “---” and flashes white.	Check whether the kettle is properly placed on the power base.

For App & Connectivity

1. Cannot connect to Govee Home App.

- Make sure the Bluetooth of your smartphone is enabled and your smartphone is not connected with other Bluetooth devices.
- Enable the smartphone's Location Services.
- Try connecting with another smartphone.
- Make sure your app is the latest version.
- Make sure you connect to your Wi-Fi router's 2.4GHz network and the network is working correctly.
- Make sure the Wi-Fi password you entered is correct.
- Shorten the distance between the kettle, Wi-Fi router, and the smartphone.
- Make sure your kettle and the Wi-Fi router are located away from appliances that produce electromagnetic radiation (e.g. microwave ovens, refrigerators, etc.).
- If you are using a VPN, try turning it off and then connecting the kettle.
- Disable portal authentication for your Wi-Fi network. If portal authentication is enabled, this kettle will not be able to access your Wi-Fi network, and setup will fail. Portal authentication means that you need to sign in to your Wi-Fi network through a web page before you can use the Internet.

2. Cannot find the device on the Bluetooth Device Nearby page of the app.

- The kettle may be connected with another smartphone. Disconnect it from the other smartphone first.

3. The kettle is offline.

- Make sure the kettle is plugged in and powered on, then refresh "My Devices" in Govee Home App by swiping down on the screen.
- Make sure your router is connected to the internet and your smartphone's network connection is working.
- If the Wi-Fi password has been changed, the kettle will automatically go offline. Try connecting it to the network again.
- Delete the offline kettle from Govee Home App, then add and reconfigure the kettle again in the app.

Appendix

After-Sales Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @Govee  @goveeofficial  @govee.official

 @GoveeOfficial  @GoveeOfficial

Specifications

Model Name	H7175
Power Voltage	AC 120V, 60Hz
Rated Power	1000W
Temperature Range	104°–212°F / 40°–100°C
Capacity	0.8 L / 0.85 QT
Net Weight	2.2 lb/1.0 kg
Dimensions	11.6 × 7.7 × 9.1 in / 29.6 × 19.5 × 23.0 cm

Compliance Information

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- (4) Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Responsible Party (This contact information is only for FCC matters) :

Name: GOVEE MOMENTS (US) TRADING LIMITED

Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: certification@govee.com

Contact information: <https://www.govee.com/support>



FOR INDOOR USE ONLY

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Qianyan Technology LTD is under license.

The trademark GoveeLife has been authorised to Shenzhen Qianyan Technology LTD.
Copyright ©2021 Shenzhen Qianyan Technology LTD. All Rights Reserved.



Govee Home App

For FAQs and more information,
please visit: www.govee.com