



① Screw ② Sensor ③ Valve Stem ④ Nut ⑤ Valve Cap

⚠ Caution:

1. Please make sure to use Siming's valves and accessories to guarantee optimal function.
2. Please follow the instruction of car manufacturer for the safety and correct operation.

⚠ 注意事项:

1. 推荐使用思明的气门嘴搭配思明的传感器。
2. 为确保安全以及正确的使用，请参考说明书的步骤进行安装；

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.



Installation

1. Put down the screw nut;
2. Slide the valve stem through the valve hole of the rim. Tighten the screw-nut with 4.0 Nm with the help of the Torque tool.
3. Assemble the tire, be sure that sensor would not touched with the rim and tire.

Note: Use different way to re-lean according to the different vehicle.

安装说明

1. 将压紧螺母旋下；
2. 将气门嘴从轮毂孔穿过，并用扭矩扳手用4.0Nm的力把压紧螺母旋紧；
3. 安装轮胎，确保传感器不受轮毂与轮胎边缘的挤压；

注意：根据不同的车型学习方式进行学习

Europe:

Siming Europe GMBH
Nordring 6B, 42579 Heiligenhaus
Tel: +49 160 / 75 50 544
Email: d.bettchen@siming-group.eu
Web: www.siming-china.com

China:

Ningbo Siming Automotive Co.,Ltd
360# Qiushi Road, Wangchun Industry park, Ningbo, China
Tel: +86 574-87103699
E-mail: info@siming-china.com
Web: www.siming-china.com