EMERGENCY RADIO

DF-588/DF-588W

Thank you very much for this purchase. Please read this manual carefully and use it correctly. Please be sure to read the "Safety Rules" before using the product. After reading it, please keep this manual properly

User Manual

Contents

- Safety use rules----- Getting to know your Weather Radio-----03 ● How to charge other devices by radio-----06 ● How to charge your Weather Radio------06 How to use FLASHLIGHT, READING LAMP or SOS ALARM etc.----08
- How to use bluetooth speakers-----09 ● How to use radio (am/fm/wb/noaa)-----10 Specification---**Caution** damage to people or damage to objects Kind reminder----
 - In case of thunder when using outdoors, please fold the antenna and evacuate to a safe place. Do not use it in an unstable place or condition.
 - charging cable for charging the body. Otherwise, there is a risk that it will not charge

 - Do not operate or use with wet hands. Do not subject the device to strong impacts
 - it may cause physical discomfort.
 - under the sun for a long time.
 - Do not insert external objects into the ports or

 - water and wipe off the stain with a hard cloth.
 - Do not use if there are any abnormalities such as odor, heat, discoloration, deformation, etc.,
 - during use or storage.

Only for people over the age of children,

- people orobjects in the vicinity, this manual sets out the matters that you are expected to observe. In order to use the Please unplug the USB charging cable if it is product safely, please fully understand the relevant contents. | not used for a long time.
 - disposal instructions of each place.
 - *We will not be responsible for anything caused by the
- Do not use, install or store the antenna in a place near the fire, such as a fireplace. Please be sure to use the configured USB


This symbol indicates that if the content


is ignored, it is expected to cause

- Do not tie up the charging cable or place obiects on it.
- such as drops or collisions. Do not expose your eyes to light. Otherwise,
- Do not place it in a place facing the sun or
- Do not disassemble or modify.
- connectors of the product.
- Do not drop it in water, immerse it in water, or leave it in the rain for a long time.
- Do not wipe the machine body with thinner
- gasoline or alcohol. *Please put a little neutral cleaning solution in the


Getting to know your Weather Radio please do not put it in a place where young children can reach.

- Please do not use or store the device in a state where it is covered with oil, etc. When disposing of it, please follow the waste
- *The LED in the product cannot be replaced. Please be















- Please do not charge with the power on.
 - viththe external machine
- Long Press: Automatically search for stations In Bluetooth Mode Short Press: next sona In FM/AM Mode
- short press: next frequency long press: search for next station 4.Volume Up
- M/Kev: Switch Mode BT/FM/AM/WB/NOAA **@EQ:** Audio switching (Bluetooth mode) 0 Standard; 1 Rock; 2 Pop; 3 Classic; 4 Jazz; 5 Country;
- In Bluetooth Mode Short Press: previous song

• Power: ON / OFF (long press) / Mute

Long Press: Disconnect bluetooth

Short Press: Switch between saved stations

Short Press: Pause/Playback

2.Pause/Plavback

In Bluetooth Mode

In FM/AM Mode

- In FM/AM Mode short press: last frequency long press: search for previous station
- Volume Down: Flashlight button • Solar panel
- (back: secondary light) ①.Thermometer
- Lanvard hole
- SOS button (button side): alarm tone (long press) 1/4" screw hole (button side) **(!**).USB-C charging socket
- Reset button







. Press and hold the power button to turn off the power.

- Plug in the USB charging cable at the output port Plug in the USB charging cable at the output port and connect to an external machine.
- The cable for charging is not provided. Please use the cable that comes



- The output of this product is 1.5A. Please do not use it if the device being charged does not support 1.5A. Damage or accidents to this product or rechargeable product
- caused by the use of unsupported equipment are not warranted Please check with the manufacturer of the charged device to see if it is supported. The battery life of the recharged device may be shortened due to different specifications of the recharged device
- This product is not guaranteed to charge all external devices. The charging speed may be very slow or almost impossible due to the specification of the device and cable being charged. Due to the specification of the charged device and cable, it may
- only charge up to 90~99%. Do not charge external devices at the same time as charging the unit.

e-C) charging cable

- . Press and hold the power button to turn off the power. Please do not charge with the power on
- . Open the port cover Insert the included USB (Type-C) charging cable into the input port

to connect the USB adapter you have on hand or the charging cable included with the USB port of your computer, and plug the other side of it into the input port of the machine. The charging light on the screen flashes and jumps when charging. When

harging is complete, the charging light will be fully on


supply USB port

Input port Connect output port Supply USB por

1.Unplug the USB charging cable to close the port cover

- Do not use a USB charging cable that is not included for charging When using the device for the first time, please fully charge it When charging with a USB hub, it may not charge properly. Be sure to use the USB adapter or the USB port on your computer to charge

- not chargeor generate electricity with the power on Pull out the handle
- and gradually increase the rotation speed. The charging light wi ight up red when the handle is rotated. Make the handle rotate 30-150 times per minute to charge, and rotate for 30 minutes to charge the device with a power of 200MAH.




- FLASHLIGHT ----an environment where a stable power supply is available.
- EADING LAMP -

The use of hand-cranked power charging

- . Press and hold the power button to turn off the power. Please do
- Rotate the handle clockwise, please rotate slowly at the beginning

Pack up the handle.

SPRING BUCKLE -----



Press the - button, the volume will decrease.

READING LAMP or SOS ALARM etc.

Press the button, the high beam will be on, and press again the light will be off



Open the solar panel ress the light button **9** to adjust the brightness of different lights



.



SOS ALARM -----

Press and hold the SOS button at the bottom of the body. The alarm will sound, and the SOS light will flash red and blue. 2.Press the SOS button again, and the alarm will stop.

Install the spring buckle on the hanging buckle.



The volume can be adjusted from V-00 to V-27. V-00 is silenced.

Press (1) "Power button" to enter the mute mode, and then press again

to release the mute mode.

olume control sound effects. 0 Standard; 1 Rock; 2 Pop; 3 Classic; 4 Jazz; 5 Country; • Press the + button, the volume will increase.

Please reset the device, when it freezes or crashes, can't be able to charge FM/AM Mode ----no function can be used after charging for it has battery protection measures. After reset, the device can be reactivated and used. Press the M button, and the FM/AM of the radio will be switched



Reset

Insert the reset hole by tool needle and press it, the device can be reset at once.

Station search by manual operation cannot be saved.

When "BT" is flashing, turn on the Bluetooth of your phone, search for "DF-588/DF-588W", click it and connect. When the device is connected. to the next channel.

Pause/playback -----

"BT" will not blink.

Short press "2"to pause or play

- Switch to the previous song Press "<" to play the previous song Long press" (2)" the device will be disconnected from
- other devices and in the state of standby connection. At this time, "BT" will keep flashing.

■ In Bluetooth mode, press the " ⑥ EQ" button to switch 6 different music

How to use radio (am/fm/wb/noaa) Please orient the unit to the direction where it can be heard

Automatic channel search Press and hold the automatically search the

radio's station. Press and hold the ② automatically start frequency search from the low, select and save the receivabl channels. When the first receivable channel is retrieved, the frequency will stop once, and "P01" will be displayed. When the second channel is retrieved, the frequency will stop again. and "PO2" will be displayed. In this way, the recention will con automatically until all the channels are received.

ow to switch saved channels ● Press ❷ ❷ ,the frequency value of Screen will change to "P00 (00 is the received channel number)", and then it will change

ow to change the frequency

Press the > button, and the radio frequency will rise one by one

●long press of the " >/< " button will automatically retrieve the ne EQ ---- station, but will not automatically save it.

 When playing FM Extend the antenna and adjust the antenna to the direction where it can be heard most clearly.

PLEASE NOTE: WB and NOAA functionality only exists in the DF-588W device and is only available in the US

Press the ⑤ M button to switch to WB mode.

How to change channels Pressing ">" will switch to the next channel.

When "WB" is displayed, Long press the ⑤ "M" button again and



weather and natural disaster information from the National Weather ervice, eliminating the need to find a station yourself manually. When the weather service is not broadcasting information, the device will not play any information.

his device complies with Part 15 of the FCC

conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital

Receiving FM:76~108MHz(Supports wide FM) frequency AM:522~1629Khz specifications IPX5 Accessory USB (Type-C) Charging cable, spring buckle

Input: USB (Type-C); Output: USB (Type-A)

Bluetooth version 5.0, compatible with Bluetooth V5.0+BR+EDR+BLE

Light source used Main light: LED (daylight color) 1W

Sub light: LED (daylight color) 0.2W

Brightness Main light: 120lm ; Sub light: 40lr

Charging time Approx. 4 hours (when using USE

Charging time Speaker 5Hurs; Radio 15Hour

USB output DC 5V 2.0A

Material ABS、TPU

measuring cloth

* Metal parts may rust.

Rated power 10W

Power Supply Rechargeable (DC3.7V Li-polymer battery 4000mAh)

or the improvement of products, specifications and appearance may be changed without prior notice

Please assist in battery recycling when disposing of then

When this product is wet, wipe off the moisture with a soft

Do not wipe the body with thinner gasoline or alcohol.

greatly shortened and may not be recharged

Please disconnect the power for storage

The battery life may be greatly shortened

Do not store in a humid environment.

• When this product is stained, please put a little neutral detergent in

water and wipe it off with hard cloth, and dry it in the back shade

Oue to the characteristics of the battery, the battery life may be

 product, Lithium polymer batteries are used in the product. For efficient use of resources, please follow the waste disposal instructions of each local government whe disposing of the product.

other antenna or transmitter The device has been evaluated to meet general RF

Rules. ?Operation is subject to the following two

device, pursuant to Part 15 of the FCC Rules. ?These limits are designed to provide reasonable protection against harmful interference in a residential installation. ?This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on,

> --Reorient or relocate the receiving antenna. -- Increase the separation between the equipment

> > circuit different from that to which the receiver

the user is encouraged to try to correct the interference by one or more of the following

--Connect the equipment into an outlet on a

-Consult the dealer or an experienced radio/TV technician for help NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any

harmful interference to radio communications.

will not occur in a particular installation.

However, there is no quarantee that interference

exposure requirement.