

MY KRONOZ

Smart Watch DESIGNED IN SWITZERLAND



ZeSport²

- USER GUIDE -

TABLE OF CONTENTS

GET STARTED

- 1. Product overview 03
- 2. Charging 04
- 3. Basic touch operations 05
- 4. Shortcuts 06

PAIRING

- 5. System requirements 07
- 6. Set up 08
- 7. Firmware update 09

ACTIVITY TRACKING & SPORT MODES

- 8. Sport modes 10
- 9. Sensors 12
- 10. Heart rate 13
- 11. Activity tracking 14
- 12. Sleep monitoring 16
- 13. Stopwatch 16
- 14. Timer 17

CONNECTED FEATURES

- 15. Notifications 17
- 16. SMS 18
- 17. Incoming calls 19
- 18. Reminder 20
- 19. Weather forecasts 21
- 20. Camera remote 21
- 21. Music control 22
- 22. Find my phone 22
- 23. Anti-lost alert 22

CLOCK


- 24. Customize your watch 22
- 25. Menu style 23
- 26. Alarm 23
- 27. Settings 24

MAINTENANCE

- 28. Product care 25
- 29. Replace the watchband 26
- 30. Tech specs 26

Warnings / Safety Instructions / Regulatory Notice 27

1. PRODUCT OVERVIEW



I UPPER BUTTON

- Press to light up the screen.
- Return to home page from any menu.
- Put the device in standby mode.
- Press & hold to reset the device.

I LOWER BUTTON

- Press to light up the screen.
- Go one step back in the menu structure.
- Press & hold to Power ON/OFF.

I SMART CROWN


- Turn the crown to navigate through the main menu.
- Press the crown to confirm.
- Turn the crown to adjust digital settings (alarm, timer, reminder,...)



To get the most accurate data we recommend wearing ZeSport² on your non dominant hand and not too loose. Take ZeSport² outside to an open area and stand still for a while to acquire a GPS signal.

2. CHARGING


We recommend you to initially charge your ZeSport² for about 90 minutes before using it for the first time.



ZESPORT²



CHARGER



CABLE

1. Position the back of your ZeSport² on the charging dock.
2. Plug the USB cable into the charger.
3. Plug the large end of the USB cable into a USB power source.
4. A battery indicator will fill in to indicate charging is in progress and turn to solid green when it's fully charged.
5. Unplug the cable after ZeSport² is charged.



When the battery level gets low, a low battery indicator will appear on the watch screen.



3. BASIC TOUCHSCREEN OPERATIONS



Watchface



SWIPE LEFT from the Watchface



SWIPE RIGHT from the Watchface



Main menu



Notifications



SWIPE UP from the Watchface



1. Shortcuts



2. Weather



3. Calendar



SWIPE DOWN from the Watchface



1. Activity



2. Sport modes




3. Heart rate



4. Barometer

4. SHORTCUTS

Swipe down from the main watch face to access ZeSport² shortcuts



5. SYSTEM REQUIREMENTS

It is required to install ZeSport² mobile app on your smartphone to properly set up and use your watch.



– iOS –

iOS 8+ devices with Bluetooth 4.0 BLE

iPhone 4s, 5, 5c, 5s, 6, 6s, 6s plus, 7, 7 plus, 8, 8 plus & X



– ANDROID –

**Selected Android 5.0+ devices that support
Bluetooth 4.0 BLE**



Visit www.mykronoz.com to get the latest compatibility list.



ZeSport² will sync the notifications of SMS, emails, social media, calendar events, and personal life reminders once the ZeSport² app has been successfully installed on your smartphone.

6. SET UP

When turning on your ZeSport² for the first time, you'll be prompted to download the ZeSport² mobile app on your smartphone in order to proceed to its initial set up.





HOW TO SET UP YOUR ZESPORT² :

- Ensure that Bluetooth is enabled on your smartphone.
- Download the ZeSport² mobile app from the App store or the Google play store.
- Open the ZeSport² mobile app on your smartphone, sign up if you are a new member or log in with your existing account. After entering your personal information, follow the on-screen instructions.
- Make sure ZeSport² is nearby and select it in the list of devices.
- Scan the QR code displays on your watch to pair your device with your smartphone.
- When ZeSport² is successfully paired, you will be notified on both devices.

7. FIRMWARE UPDATE



MyKronoz will provide regular firmware updates which you will need to install in order to access our latest upgrades and features for your watch. With ZeSport², all these updates need to be done by OTA (Over The Air) and through the mobile app. Updates are performed over the air using the mobile app. Before updating, make sure your phone and your watch have more than 30% battery.



IN ORDER TO UPDATE YOUR WATCH:

- Connect your ZeSport² to the mobile app.
- If a new update is available you will be prompted from the home screen.
- You must accept it in order to start the updating process.




During all the update process you must keep your watch near your smartphone and your application must be open. Avoid using your phone during the update process.

8. SPORT MODES



I START AN ACTIVITY

Your ZeSport² can be used for indoor, outdoor and fitness activities. When you start an activity, you will be prompted to activate GPS and heart rate monitoring depending on the activity you select. When you stop an activity, your watch returns to normal mode.



- Press and hold the lower button to enter the Sport modes or access it through your watch menu.
- Select an activity among the available activities (walking, cycling, swimming, trail running, indoor running, outdoor running & hiking).
- Follow the on-screen instructions and enter additional information if necessary.
- If your activity requires GPS, make sure to go outside and wait a few seconds/minutes until the watch acquires satellite signals.
- Press Play to start the timer.

The watch does not track your activity data until you start the timer.

I PAUSE/STOP/SAVE AN ACTIVITY

TO PAUSE AN ACTIVITY:

- From the Sport interface, press the bottom button.
- Tap on Pause.
- Press Pause to continue exercising or click on the Record icon to save/delete your activity.

TO SAVE AN ACTIVITY:

- From the Sport interface, press the bottom button.
- Tap on Record.
- Select Save.

TO DISCARD AN ACTIVITY:

- From the Sport interface, press the bottom button.
- Tap on Record.
- Select Discard.

DELETE AN ACTIVITY

To erase a stored activity:

- From the watch history activity menu, select and long press a stored activity.
- Click on the Delete icon.

VIEW YOUR HISTORY

To view your recorded workout session:

- Access the Sport menu.
- Swipe left.
- Select one of the stored activities on the list.

You can also view additional details by using the ZeSport² Mobile App

- Go to the History tab.
- Select a recorded activity.

Your ZeSport² saves the overall multisport summary of your activity, overall steps, distance, pace, calories burned, elevation and other data. Your watch allows you to view all your activities in chronological order. Thus, you can compare different activity sessions for an activity.

I INDOOR ACTIVITIES

The ZeSport² can be used for indoor sports activities, such as indoor running, swimming or stationary cycling. In this case, GPS is automatically disabled for indoor activities. When you walk or run with GPS off, speed, distance travelled and other activity data are calculated using the 6-axis accelerometer built into the device.

TIP: Positioning your hands on the handrails of the treadmill reduces the accuracy significantly. When indoor cycling with GPS switched off, speed and distance are not available.

I OUTDOOR ACTIVITIES

For outdoor activities such as running, trail running or cycling, GPS is turned on. Make sure that your device has access to satellite signals when you enable GPS for the first time.


I SWIMMING

The ZeSport² is intended for surface swimming.

Before starting an indoor swimming activity, make sure to select your pool size (pool length).

Note: Free or underwater diving is not recommended and void the warranty. The device cannot record your pulse while swimming.

9. SENSORS



I ALTIMETER & BAROMETER

Thanks to its altimeter and barometer, the ZeSport² continuously collects Altitude and pressure data.

The altimeter displays your approximate altitude based on pressure changes.

The barometer displays environmental pressure data based on the fixed altitude at which the altimeter was most recently calibrated.

I 3 AXIS MAGNETOMETER

The ZeSport² is equipped with a 3-axis magnetometer (compass) build-in an automatic calibration. Based on your activity, the 3-axis magnetometer features and appearance change whether GPS is enabled and whether you are navigating to a destination.

10. HEART RATE



I WEAR THE DEVICE

- Make sure to wear your device above your wrist bone.
- To track your pulse, go to the HR menu of your ZeSport². Tap on the Heart icon.
- Go to the main interface of the heart rate menu to get more detailed data (Average heart rate, last HR tracking, lowest and highest HR level).

Note: In order to obtain relevant and accurate data, please attach your watch securely around your wrist without overtightening the strap.



Your watch should not move on your wrist, when running or exercising.

I TRACK YOUR PULSE

Equipped with an optical heart rate sensor, ZeSport² continuously measures your heart rate frequency throughout the day.

TO MEASURE YOUR HEART RATE



- Securely attach your ZeSport² around your wrist.
- Go to the heart rate menu of your watch.
- Touch the screen or press the crown to start measuring your heart rate.



It will take about 10 seconds to get the results displayed on your watch screen.

TO SET YOUR HEART RATE ALERT

ZeSport² can also alert you when your heart rate is going above or below preset limits. You can customize those limits in the device Settings > Activity > Heart rate > Max HR/Min HR/Auto tracking.



I HR TIPS

If your heart rate data does not seem to be reliable or it is not visible, please follow these steps:

- Clean your arm before putting your device on.
- Avoid applying cream or lotions on the area where you are wearing your device.
- Wear the watch around the wrist, just above the bone. Tighten the watch to your wrist.
- While exercising, wear a silicone band.

11. ACTIVITY TRACKING



I DEFINE YOUR PROFILE

Make sure to edit and update your gender, birthday, weight and height. The ZeSport² relies on this information to evaluate and calculate accurate activity data.

I ACTIVITY TRACKING


The activity tracking feature tracks your daily activity, daily step counts, distance traveled, active minutes and calories burned. Your watch has a built-in 6-axis accelerometer that allows you to track your daily activity based on your movements. This, together with your profile information, allows your watch to calculate your steps, walking distance, minutes of activity and calories burned. In order to get the most accurate results we recommend you to wear your watch on your left wrist if you're right handed and on your right one if you are left handed.



Overall activity

Steps

Distance



Active minutes


Calories

The number of steps taken, the distance covered and other activity data are visible on most watch dials. You can find your data in real time in the activity menu of your watch. To access this menu, from the main screen, slide your finger up. Slide your finger to the left to view each step, distance, active minutes and calories burned.


I SYNC YOUR DAILY ACTIVITY

To synchronize your data manually, simply go to the activity page of the ZeSport² application and slide your finger down. Note that automatic synchronization occurs each time you open or connect to the ZeSport² application.

On the main application screen, you can view your daily activity in real-time over your set goals and get a detailed report in the mobile app.



TIPS: A goal alert appears for your daily steps goal, distance traveled goal, calories burned goal and active minutes goal. This alert appears on your watch and also in the App. The activity tracker resets at midnight and ZeSport² has the ability to store up to 10 days of your activity data. Then, you will have to synchronize your ZeSport² with your mobile app in order to avoid a loss of data.




I SET UP YOUR DAILY ACTIVITY GOAL

You can set your daily goals from the mobile app or in the activity section of the watch **Settings > Activity > Goals**.

We recommend you set ambitious but realistic goals in order to keep a healthy daily activity. You can obviously raise your goals over time to increase your performance. On average it is recommended to have at least 30 minutes of physical activity per day and walk 10000 steps.

I SHARE YOUR ACTIVITY

Use the sharing function to publish your daily activity or special workouts on your preferred social networks.




1. Press on the top right icon to start sharing your activity data with your friends and family.
2. You can choose an image (by sliding left and right) or take a picture that you want to share.
3. When it's done, select the top right button "next".
4. Select your preferred network to share your daily activity report.

12. SLEEP MONITORING



ZeSport² can detect your micro-movements during your sleep and deduce the quality of sleep, the time taken to fall asleep, how many times you woke up in the night, the hours of light sleep and deep sleep, etc.



You can find all data related to your sleep on the **ZeSport² App**. Go to the **Dashboard home page** and click on the **Sleep** band. You can also view data from your last night on your ZeSport². Go to the **Sleep menu** of your device.


Start and stop the sleep mode:

- Press the sleep app icon from the ZeSport² main menu.
- Press Start to enable sleep monitoring.
- Press End to stop sleep monitoring.

13. STOPWATCH



HOW TO USE THE STOPWATCH



- Open the stopwatch app from the App menu.
- Start the stopwatch by pressing the play icon.
- Track individual lap performance by pressing the blue icon while measuring is on.
- Stop counting by pressing the pause button.

To view the full lap-by-lap report, press the lap counter at the top of the screen. Make sure to stop the stopwatch first. To delete the report, press the cross.

14. TIMER



I TO USE THE TIMER



- Open the timer app from the App menu.
- Adjust the timer duration by using the digital crown and start the timer by pressing the green icon. Stop it by clicking on the same icon.
- Press the back arrow to reset the timer to 0.
- At the end of the countdown, your watch will alert you with a sound or/and vibration.

15. NOTIFICATIONS



Before enabling notifications, make sure that the ZeSport² device is well paired with your smartphone.

I MANAGING YOUR NOTIFICATIONS

You can use your smartphone to handle notifications that appear on your ZeSport².

I SETTING UP NOTIFICATIONS FOR IOS USERS

If you are using an iOS device, go to the Settings of your iOS device:


- Tap «**Notification center**»
- Select which type of notifications you wish to receive on ZeSport²
- Enable «**Show in Notification Center**» to receive the notification on ZeSport²

I SETTING UP NOTIFICATIONS FOR ANDROID USERS

If you are using an Android device, access the ZeSport² App settings and click on **Notifications**. Then, select the items to display on the watch.

I VIEWING YOUR NOTIFICATIONS

Each notification will appear over your selected watch face with its dedicated icon to identify the item. Some notifications may be identified with a generic icon.



- To read your notifications, simply touch the screen on the notification area and it will open instantly.
- To access to the notifications list, from the homepage, swipe left. Use the crown or your finger to navigate and click on a notification to open it.
- To delete all your notifications, long press the screen and confirm.
- To delete one notification, select it, swipe left and confirm.

16. SMS



With ZeSport², you can receive and read your SMS straight from your wrist.



- Quick reply (only available for Android users): ZeSport² allows you to reply using preset short answers directly from your watch. You can also create your own preset answers using the mobile app.
- To delete all your SMS notifications, go to the SMS list and long press the screen.
- To erase a SMS, select the message and slide your finger to the left.

17. INCOMING CALLS




When receiving a call, a notification will appear on your ZeSport². You can accept or reject it straight from your wrist. The phone call will occur on your smartphone, not on your watch.



Android users can also reply to an incoming call by sending a short preset text message from their watch (not available for iOS users).

18. REMINDER



You can set and manage reminders directly with the ZeSport² mobile app. You can create up to 10 reminders and select the type, time and schedule for them. For each reminder, you can decide the type of alert you want to receive (ringtone, vibration or both). A single tap on your ZeSport² helps dismiss the reminder. If not dismissed, the same alert will repeat after two minutes.



TO SET A REMINDER FROM THE WATCH

- Open the App menu.
- Click on Reminder.
- Tap on Add.
- Set up your preferred reminder type.
- Choose the date (repeat) and time of the reminder.
- Select the type of alert.

To confirm your selection/settings, press the crown

To modify a reminder, tap on it from the reminder list

To delete a reminder, select and long press a reminder. Confirm the deletion.


TO SET A REMINDER FROM THE APP

- Open the ZeSport² mobile app.
- Click on the reminder tab.
- Set up your preferred reminder type.
- Choose the date and time of the reminder.
- Select the type of alert.

19. WEATHER FORECASTS



Your MyKronoz device gives you access to the weather forecast (over 3 days) for your desired location. By default, the watch displays the weather forecast for Geneva.



If you wish to change the location, simply go to the Settings menu of the application > **Select Advanced Settings** > Click on **Weather**

Manual mode allows you to type your location directly:

- Go to the Settings menu of your App
- Click on Advanced settings
- Enable Manual mode
- Type and select your city

Auto mode allows you to have the weather forecast according to your GPS location. In this case, you will need to enable GPS on your smartphone to take advantage of this feature.

- Go to the Settings menu of your App
- Click on «**Advanced settings**»
- Enable Auto mode


Be aware that data synchronization will be done throughout the day according to your positioning.

Good to know: From the weather settings, select your preferred temperature units. The information displayed in your watch can vary according to location, smartphone settings and phone networks.

20. CAMERA REMOTE



ZeSport² can be used as a remote control to take pictures from your smartphone. This feature is useful when you want to take a group photo or when you want to take a selfie.



HOW TO USE ZESPORT² AS A CAMERA REMOTE


- Open the camera on your smartphone.
- Go into the camera menu of your watch.
- Then, tap the screen to start the countdown and take photos.

All the pictures that you take with your ZeSport² are stored in the gallery of your phone.

21. MUSIC CONTROL



With ZeSport², you can take control of your favorite music player on your Smartphone. On your ZeSport², you can see information about the track currently playing, like artist and track name. If the app you're using does not broadcast track information, it won't appear on your ZeSport² (iOS only).



HOW TO CONTROL MUSIC

- First launch the music from the player on your phone.
- Go into the Music app on your ZeSport².
- Play, pause & skip tracks.

The Volume can be adjusted using the digital crown.

22. FIND MY PHONE



If you misplace your phone, the Find my phone function will make your phone ring or vibrate so you can easily find it. To enjoy this feature, ensure that your phone and watch are within range (10m).



TO ENABLE THIS FEATURE


- From the watch shortcuts, tap on the Find my phone widget.
- Click again to disable it.

You can also enable this feature by going in the App menu of your watch. Click on Find my phone.

23. ANTI-LOST ALERT



This alert notifies you with a vibration or a sound (depending on your watch settings) when your ZeSport² is going out of range (BT range 10m) from your phone. Note that you can turn this function off by disabling the Anti-lost alert in your application's notification menu (Anti-lost alert is OFF by default).



24. CUSTOMIZE YOUR WATCH FACE



I TO CHANGE THE WATCH FACE FROM THE DEVICE

- Long press the current dial on your watch.
- Slide your finger from right to left on the screen to scroll through the different watch faces.
- Select your favorite watch face by tapping on it.

I TO CHANGE THE WATCH FACE FROM THE APP

- Go to the settings tab of the mobile app.
- Click on watch face.
- Select your preferred watch face and click on save.

I TO CHANGE THE WATCH FACE FROM THE APP

- Go to the settings tab of the mobile app.
- Click on watch face.
- Select your preferred watch face and click on save.

25. MENU STYLE

HOW TO CHANGE THE MENU STYLE OF YOUR WATCH:

Choose your favorite menu style by going into the settings menu of your watch:

- Click on Display menu and Select Menu
- Select the menu style of your choice



26. ALARM



HOW TO SET AN ALARM FROM THE WATCH

- Open the Alarm menu.
- Tap on Add.
- Set the alarm time by using the crown.
- Select the type of alert.
- Select the alarm day (or repeat).

To confirm your selection/settings, press the crown.

To modify a reminder, tap on it and modify it.

To delete a reminder, select and long press the reminder. Confirm the deletion.

HOW TO SET AN ALARM FROM THE APP

- Open the ZeSport² mobile app.
- Click on the reminder tab and select wake up.
- Select the custom repeat or the alarm date/time.
- Select the type of alert.
- Click on save.



GENERAL

Language: set the language displayed on the device.

Units: select metric or imperial units.

Bluetooth: enable or disable it.

Regulatory: watch certification.

Watch Information: view the firmware version & device serial number.



ACTIVITY

Heart rate: set your minimum and maximum heart rate frequency.

Goals: set your goals.



DISPLAY

Wrist flick: enable or disable it.

Brightness: change the screen brightness

Left hand mode : enable or disable it.

Screen time out: set the standby mode.

Menu: select a menu style.



SOUND

Do not disturb : set a time frame when you don't want to be disturbed.

Sound/Vibration: set the vibration/sound mode.

Snooze: adjust the snooze time.



TIME

Date format: change date format.

Time format: change time format.



RESET

Restore your watch to its default settings.

28. PRODUCT CARE



To keep your watch in the best condition, please clean your strap and charging area regularly, especially after a sports session or heavy perspiration. Rinse the bracelet only with clear water and dry it with a dry cloth before attaching it around your wrist.

To remove any stains, use a little detergent and rub with a slightly damp cloth or toothbrush. For stubborn tasks, do not hesitate to use an eraser.

If you have a light-coloured bracelet, avoid contact with dark coloured clothing.

To obtain accurate data and for better comfort, please do not over tighten the wristband. If you activate heart rate monitoring, we advise you to wear your watch higher on your wrist (2 finger widths above your wrist bone).

Rubbing and prolonged wearing of the wristband may irritate the skin, so give your wrist a break by removing the band for one hour after prolonged wearing.

Sweat or moisture residues can corrode the charging contacts, especially during charging.

Wipe your watch with a slightly damp cloth. Do not hesitate to use a mild detergent. Let the device dry before wearing it on your wrist.

29. REPLACE THE WATCH BAND

ZeSport² uses standard 22mm interchangeable watch bands, in order to make it easy for you to perfectly match your watch and your style.

1. Push the spring bar inward to release the strap from the watch case.
2. Push the spring bar inward while aligning it with the holes on either side of the watch case.
3. Release the spring bar to secure the strap.
4. Verify that the strap is correctly fastened by gently tugging on the strap.



30. TECH SPECS

Dimensions:	54.9 x 48 x 14.39 mm
Weight:	74 gr
Material:	Silicone
Watch band size:	22 mm
Connectivity	Bluetooth 4.2 BLE
Battery type:	Li-ion 460 mAh
Battery life:	Up to 4 days (watch mode) GPS mode : 7 - 8 hours
Charging time:	1 - 2 hours
Memory :	ROM: 4MB+128MB / RAM: 4MB
Display type:	TFT SPI Color touchscreen
Display size and resolution:	1.3 inches / 240*240 pixels
Sensors:	6-axis A+G-sensor, optical HR sensor, altimeter, barometer, magnetometer
Operating temperature:	-10°C to + 55°C
Water resistance:	IP68 / 3 ATM
Free Android and iOS app	
Accessories included:	Magnetic charging station
International warranty:	1 year

What's in the box: Charger dock, ZeSport², Get started guide.

WARNING

■ Connecting the charging cable improperly may cause serious damage to the device. Any damage caused by misuse is not covered by the warranty. Unplug the cable after ZeSport² is fully charged.

■ ZeSport² unit and charging dock contain strong magnets that may interfere with pacemakers, credit cards, watches and other magnet-sensitive objects. If you use a pacemaker or any other electronic medical device, please consult your physician before wearing or handling ZeSport².

■ This product is not a medical device and should not be used to diagnose or treat any medical condition.

■ This product is in compliance with the IP rating IP68. IP68 indicates that the product is resistant against dust ingress and immersion in water with a depth of more than 1 meter.

■ ZeSport² is water resistant up to 30 meters (3 ATM). ZeSport² is resistant to water splashes, rain, submersion and showering. ZeTime can be used for shallow water activities like swimming (down to 5m deep) but should not be exposed to water at high pressure, such as ocean waves or a waterfall. ZeSport² should not be used for scuba diving and water skiing. Do not expose your ZeSport² to soapy water, perfume, detergents, lotions, sunscreen, and high velocity water. please note that all bands are not appropriate for water use. for example, leather band.

ABOUT THIS MANUAL

The features of ZeSport² and the contents of the user manual are subject to change. To get the latest instructions on how to use this product, please refer to the online user manual available on www.mykronoz.com

SUPPORT

If you have any question or require assistance regarding our product, please visit www.mykronoz.com/support/ submit a request at <https://support.mykronoz.com/hc/en-us/requests/new>

SAFETY INSTRUCTIONS

Before using the device, read these instructions carefully.

BATTERY

- ZeSport² has built-in batteries. Do not disassemble the battery on your own. KRONOZ LLC is not responsible for any damage or personal injury caused by the removal of the battery or any component.
- Do not expose your product to extremely high or low temperatures. Excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion. Do not expose the battery in the sun, excessive smoke or dust. Charge the battery in a cool, ventilated room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (do not rub the eye) or seek medical help.
- Do not short-circuit. Short-circuiting can occur when a metallic object, such as coins, causes direct connection of positive and negative terminals of the battery. Short-circuiting may damage the battery.
- Do not use batteries that have been damaged or have been exhausted.
- Keep the batteries out of children's reach and in a safe place to prevent danger.
- Do not place the batteries in the water. Do not expose your product to water at high pressure, such as ocean waves or waterfall. Do not use your product in a sauna or steam room.
- Do not dispose of batteries in fire as they may cause explosion. Dispose of used batteries in accordance with your local regulations (such as recycling). Do not dispose as household waste.
- Use only the USB cable supplied to charge this battery. Do not charge for more than 24 hours.
- Do not attempt to repair or maintain the watch by yourself, service and maintenance should be performed by authorized technicians.

CAUTION

- This device has a recording function. Please be sure to comply with the relevant laws and regulations on the use of these features. In accordance with relevant regulations, without permissions any personal characteristic sound recording being copied and disseminated may be seen as an invasion of privacy. Inappropriate use of photography, video and photo, audio recording function records could violate the copyright owner's right. For this, the user must assume full responsibility. KRONOZ LLC is not responsible for any damage caused by improper use of the device.
- This device is not waterproof. Do not immerse the device in water or any other liquids.

REGULARY NOTICE



USA - FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTIONS

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC NOTICE

This equipment complies within the limits of a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protections against radio and TV interference in residential areas. However, even during normal operation, this equipment may cause TV or radio interference. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one or more of the following corrective measures:

- Reposition the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC EXPOSURE - RF EXPOSURE STATEMENTS

This equipment complies with FCC radiation exposure requirement set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

ISED EXPOSURE - RF EXPOSURE STATEMENTS

This device complies with the ISED RSS-102 RF exposure requirement set forth for an uncontrolled environment and are safe for intended operation as described in this manual.

Cet appareil est conforme aux exigences d'exposition RF de l'ISED RSS-102 définies pour un environnement non contrôlé et est sûr pour le fonctionnement prévu comme décrit dans ce manuel.

FCC ID: 2AA7D-ZSP2

CANADA - INDUSTRY CANADA (IC) STATEMENT

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions :

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme à la norme CNR d'Industrie Canada applicable aux appareils radio exempts de licence. Son utilisation est soumise aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un fonctionnement indésirable du dispositif.

IC: 12131A-ZSP2

EUROPEAN UNION CE DIRECTIVE



Declaration of conformity with regard to the EU Directive 2014/53/EC.

Kronoz LLC hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive 2014/53/EC. The complete declaration of conformity is available on request via our customer service: support@mykronoz.com

Déclaration de conformité à l'égard de la directive européenne 2014/53/EC
Kronoz LLC déclare que cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive R&TTE 2014/53/EC. La déclaration de conformité complète est disponible sur demande auprès de notre service client: support@mykronoz.com

- (1) 使用30 分鐘請休息10 分鐘。
- (2) 未滿2歲幼兒不看螢幕，2歲以上每天看螢幕不要超過1 小時。

依據低功率電波輻射性電機管理辦法

第十二條

※經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

※低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

-前項合法通信，指依電信法規定作業之無線電通信。

-低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

ACCESS TO THE REQUIRED INFORMATION ON THE E-LABEL

Users can access the E-Label screen on ZeSport² by going to Settings > General > Regulatory. No special access codes or permissions are required to go through the above steps beyond entering a user-defined password to protect against unauthorized access to the device. Additional regulatory information are in « Regulatory notices » of this document. The information is stored on the device, no special accessories or supplemental plug-ins (e.g., a SIM/USIM card) are required to access the information.

DISPOSAL AND RECYCLING INFORMATION



After the implementation of the European Directive 2012/19/EU in the national legal system, the following applies : electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic device at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

©2018 Kronoz LLC, all rights reserved. Kronoz LLC,
Avenue Louis-Casai 18 - 1209 Geneva - Switzerland
All brands or product names are or may be trademarks of their respective owners. Pictures and specifications are not contractual. Les marques citées sont des marques déposées par leur fabricant respectif. Photos et caractéristiques non contractuelles.
Designed in Switzerland - Made in China



MORE THAN TIME

JOIN US @ MYKRONOZ



www.mykronoz.com