

# Taita M 3 in 1


## Foldable Wireless Charging Station

Quick start guide



### **How to charge wirelessly with Taita M**

- Plug the supplied USB-C to USB-C cable into Taita M, then connect it to the power adapter.
- Place your smart device Taita M. The “-” mark indicates the center of each charging coil.
- When using the power adapter, the maximum wireless charging output for smartphones is 15W Max, the earphone is 5W and the Apple watch is 2.5W. For maximum charging performance, please connect the USB-C charging cable to the USB-C of the 27W or above power adaptor.



## **Foreign Object Detection Troubleshooting**

1. Remove any metal objects such as coins or keys between your device and Taita M.
2. Unplug the UCB-C cable from Taita M then plug it again.
3. If the problem still persists, please contact [supoort@moshi.com](mailto:supoort@moshi.com).

## **FCC Statement**

Please take attention that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 18 of FCC Rules.

## **FCC Caution**

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## **CE Statement**

Herby, Aveoe Inc. declares that the radio equipment type Taita M 3 in 1 foldable wireless charging station is in compliance with Directive 2013/53/EU.

## **FCC Warning Statement:**

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## **FCC Radiation Exposure Statement**

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.