


Email

The Email application allows you to access an external POP3 or IMAP email account provider such as Yahoo or Gmail.

Note: Before setting up your email, please ensure that you are connected to Wi-Fi. If you do not already know your email settings (POP3, IMAP, etc) you can obtain them from your email provider.

1. Tap the Email app.
2. An email setting guide to help you get your account set up.
3. Enter your email account address and password.
4. Tap the next button, choose your email type: POP3 or IMAP.
5. Tap next button to check the email settings.
6. Enter the account name and the email sender's (your) name, tap finish.
7. If the mailbox is available, it will enter into your inbox.





Delete an email account

You can delete the set POP3 or IMAP email account from your Device.

1. Tap email.
2. Enter your inbox.
3. Touch the menu icon.
4. Tap setting.
5. Select the account you wish to remove.
6. A menu list will appear, select delete account.
7. Tap OK to delete.

Sending email


1. Tap Email to display your mail box.
2. Tap the inbox, it will refresh the new emails automatically;
tap it to read new email.
3. Touch the  button at the top of screen.
4. Input the receiver's email address in the receiver column.
5. Input subject and email content.
6. Tap to add attachment, touch menu icon, a menu will pop up.


7. Tap “add attachment”.
8. Select the attachment you want to send (pictures, videos).
9. Tap send button  to send the email.

Browser

When you select the browser icon, your browser will open. You can tap the browser bar to bring up the virtual keyboard and input the web address you would like to view. The Browser will open to the last page you visited. If you have not opened the browser yet, it will go to your homepage.

Set the homepage:

1. Tap the browser icon 
2. Tap the menu icon on the top right corner.
3. Tap the setting menu.
4. Tap General.
5. Tap Set homepage.




Visit webpage


1. Touch browser icon
2. Input the website you want to search on the keyboard.
3. Tap finish to go to the website.


Bookmark Management

Setting webpage bookmark

1. Go to any webpage.
2. Tap  and select "OK" to add this website to bookmark.

Opening a bookmark

1. Tap , and it will show bookmark list in the browser.
2. Tap the bookmark you want to open that webpage



SYSTEM SETTINGS

Voice and Display


Sound and volume setting

1. Tap the setting icon.
2. Tap “Sound”.
3. Tap volume to adjust the volume for music and video.
4. Or press “VOL +” or “VOL – Button” to adjust the volume.

Display Settings

Adjust the brightness of your screen

1. Tap the setting icon.
2. Tap display → Tap brightness, a slide bar will open. Slide this bar to the right to increase brightness, and to the left to decrease brightness
3. Tap OK.



Adjust screen standby time

1. Tap the setting icon.
2. Tap display → Tap “Sleep”, select the amount of idle time you want to pass before the device enters standby mode to conserve power.


Setting a screen lock

NOTE- If you set a password, PIN, or Pattern, and later forget this item, you will be LOCKED OUT of your device. For security purposes, we can NOT recover a lost password, PIN, or Pattern for you.

You can set a password, PIN, or pattern to secure your device from unauthorized access and protect your privacy.

Note: anytime the device enters standby mode (pressing the power button briefly or due to idle time) you must enter your password, PIN, or pattern to unlock it, if you have one set.

1. Tap the setting icon.
2. Tap Security → Screen lock → Then chose the screen lock type you want.



SD CARD AND INTERNAL STORAGE

View SD Card and Storage Available Space

1. Tap the setting icon.
2. Tap storage.
3. View the available space on the SD card.
4. View internal storage space.

Safely remove the SD card


Please follow this procedure when removing the SD card to prevent damage to your SD card and files

1. Tap the setting icon.
2. Tap storage.
3. Tap remove SD card.
4. Pull out the SD card.

Date and Time


Manually adjust the date, time and time zone

1. Tap the setting icon.
2. Scroll the screen down, and tap date and time.
3. Tap time zone, and choose your zone in the list. scroll down to view more zone information.
4. Tap choose date formats, and tap the date formats in MID.



Setting the Display Language

1. Tap the setting icon.
 2. Tap language & input.
 3. Tap language, and select the language you want.
- There are 60 languages to choose from.



ABOUT THE TABLET

Installing Applications

Installation

While the main method of loading applications involves using an app store, if you have an individual APK file, you can use that to install the app.

Save the APK file to your device. We recommend saving APK files to the Downloads folder to find them easily.

1. Tap file manager; choose the application you wish to install.
2. Tap “Install”.
3. Follow the installation instructions listed on the screen.

Uninstalling an Application

Tap the settings icon.

1. Tap Application.
2. Select the application you want to uninstall, tap uninstall.
3. Tap OK to finish uninstalling the app.

Troubleshooting

- 1. It takes a long time to power up when I power on for the first time.**

The first time you power the device on, or after updating the device, it may take as long as 3 minutes to power on as it initializes files. Subsequent power sequences should take less than a minute

2. Sometimes, the device feels warm to the touch.

When charging, or after a long period of use, it is common for the device to feel slightly warm. This is normal as the battery charges or discharges and is not a cause for concern.

3. My device will not connect to Wi-Fi.

- Ensure that you are in an area with a strong Wi-Fi signal.
- Please make sure the password you are using is correct.

4. Cannot surf the Internet

- Please make sure the distance between the device and the wireless router is within 50 yards.
- Please re-connect the WI-FI.

5. Sometimes, the device runs slowly.

- The more apps you have open and running, the slower the device will run. You can enter your application setting to disable or “kill” applications to free up processor and memory resources. In addition, there are many “Task Killer” applications which can do this

TECHNICAL SPECIFICATIONS

Display	7.85" TN 1024x768 capacitive touch panel
CPU	Quad Core processor
Storage	16GB
RAM	1GB
Bluetooth Version	4.0
Wi-Fi Bands	802.11b/g/n
Battery	3400mAh
microSD Support	Up to 32GB expandable
Front Camera Resolution	0.3MP
Rear Camera Resolution	2MP
Dimensions	201 x 135.8 x 10.2mm
Weight	352g

Android, Google, Google Play and other marks are trademarks of Google Inc.

If at any point, you have questions about your tablet or experience an issue with your tablet, please feel free to contact our technicians at mssupport@machspeed.com or by phone at 844.400.8746.

WARRANTY

1. MACH SPEED products carry a one year from date of purchase warranty. This warranty is nontransferable.
2. Mach-Speed Technologies warrants to the original registered end-user purchaser that Mach Speed products will be free from defects in materials and workmanship for one year from the date of new purchase. During the warranty period, and upon proof of purchase the product will be repaired or replaced (with the same or a similar model, which may be a refurbished model) at Mach Speed Technologies option, without charge for either parts or labor. This warranty shall not apply if the product is modified, tampered with, misused, physically damaged, or subjected to abnormal working conditions (including, but not limited to, electrical, fire, and water damage)

THIS WARRANTY DOES NOT GUARANTEE YOU UNINTERRUPTED SERVICE. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER.

To obtain service under this warranty, you must contact our Technical department at 844.400.8746 to obtain an RMA number. Mach Speed Technologies will only replace or repair product that is sent to us with an authorized RMA number.

Discrepancy & Shipping Damage:

1. For wrong items, missing items, shipping damage, or other discrepancy; customer should report to RMA department on the day in which the items were received. Any claims after one business day of receipt will not be honored.

2. For any shipping damage, customer must file a claim with their carrier immediately. All items are shipped insured, thus must be reported for coverage.
3. Customer is responsible for paying any freight charge caused by refused shipment or unclaimed goods.
4. Mach Speed Technologies will make every reasonable effort to deliver on time however; Mach Speed Technologies will not be liable for late or lost shipments.

Consequential Damages and Limitations:

1. Mach Speed Technologies shall not be liable for any failure to perform or delay in performing any of its obligations when such failure or delay is due to circumstances beyond its reasonable control, including, without limitation, any act of God, war, strike, riot, fire, flood, earthquake, lock-out, late or non-delivery by suppliers, shortage or unavailability of materials, components or transportation facilities, or any act, refusal to act, regulation, order or intervention of any governmental authority.
2. Under no circumstances shall Mach Speed Technologies be liable for any special, indirect, incidental or consequential damages of any kind or nature whatsoever, including, without limitation; lost goodwill, lost resale profits, loss of data or software, work stoppage or impairment of other goods, and whether arising out of breach of any express or implied warranty, breach of contract, tort (including negligence), strict product liability or otherwise, even if advised of the possibility of such damage or if such damage could have been reasonably foreseen.

Federal Communications Commission (FCC) Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.