


### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

#### PRODUCT DESCRIPTION

The AC Smart Connector is a wireless device which provides electrical connectivity between the light fixture (load) and 120V/277V AC line power and provides on/off power control and dimming signals to the load. The information that tells the connector to power on/off/dim the fixture is acquired via wireless signals that originate from a building automation system or from room controls, based on environmental conditions and/or predetermined programs.



#### **KEY FEATURES**

FCC and IC approved External fixture mounting Small form factor Integrated Wire Antenna RoHS compliant

#### PRODUCT CONTENTS

The following items are included inside the package:

Qty	Description
1	LCE20A-1000 20A Luminaire
	Controller

Audacy®, Smart Connector® and Smart Switch® are registered trademarks of IDEAL INDUSTRIES.

All other trademarks are the property of their respective owners.

ND xxxx-x 03/2017

Users Manual – LCE20A-1000 – 20Amp Luminaire Controller 0-10V Dimming



### LCE20A-1000 – 20Amp Luminaire Controller 0-10V Dimming

# IDEAL Model LCE20A-1000 20Amp Luminaire Controller Installation Instructions

WARNING: This is a current rated device. Use in applications involving amperage beyond its rating can be dangerous and cause electrical fires.

Wiring must comply with all applicable electrical codes. Turn off power before removing or installing connector.

### **TERMINOLOGY**

LINE(Black): Smart Connector power feed to be connected to premise wiring LOAD(Red): Power output from Smart Connector to ballast AC power input Neutral(White): Incoming Neutral from premise wiring and outgoing ballast neutral.

DIM (Purple/Grey): 0-10 VDC dimming control output from Smart Connector to ballast dimming input

#### **CONNECTING THE WIRES**

#### **Input Power**

The smart connector LINE(Black) and NEUTRAL(White) wires are 18 AWG solid copper conductors.

- 1. Strip wires to 1/2".
- 2. Connect Smart Connector Line Input to premise line power feed with appropriate sized wirenut or push-in connector.
- 3. Connect Smart Connector Neutral Input to premise neutral feed with appropriately sized wirenut or push-in connector..
- 4. For feed-through (i.e., "daisy-chain") installations, connect the LINE hot feed-through conductor into the wirenut in step 2. Also, connect the NEUTRAL feet-through conductor connected without re-installing the wires. into the wirenut in step 3.



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

#### LOAD

The LOAD(red) and Neutral(White) wire are 18 AWG solid copper conductors.

- 1. Strip wires to 1/2".
- 2. Connect Smart Connector LOAD wire to the ballast hot line with appropriate sized wirenut or push-in connector if necessary.
- 3. Connect Smart Connector NEUTRAL Output to the ballast neutral with appropriately sized wirenut or push-in connector if necessary.
- 4. For feed-through (i.e., "daisy-chain") installations, connect the LOAD hot feed-through conductor into the wirenut in step 2. Also, connect the NEUTRAL Output feed-through conductor into the wirenut in step 3.

#### **DIM Connector**

The DIM wires are 18 AWG solid copper conductors.

- 1. Strip wires to 1/2".
- 2. Connect positive/(+)/purple DIM wire from Smart Connector to positive/(+)/purple wire from dimming ballast with appropriate sized wirenut or push-in connector if necessary.
- 3. Connect negative/(-)/grey DIM wire from Smart Connector to negative/(-)/grey wire from dimming ballast with appropriate sized wirenut or push-in connector if necessary.




Figure 1 – Typical Installation

ND xxxx-x 03/2017

Users Manual – LCE20A-1000 – 20Amp Luminaire Controller 0-10V Dimming



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

### **PROGRAMMING**

Refer to the Audacy™ system configuration manual to associate smart connectors to other devices and to set up operating parameters for the Audacy™ lighting control system


#### **SPECIFICATIONS**


Description
915 MHz External Antenna
FCC Part 15 and Industry Canada
Contains FCC ID: 2AAMXLCE20A1000
Contains IC: 11250A-LCE20A1000
UL916
IP65
300 ft. indoors line of sight to an Audacy Gateway or Smart Connector
0-10VDC (10%-100%) 100mA Sinking
20A
50,000
120VAC/277VAC
-40°C to 70°C
Indoor/Outdoor
10.4oz/ 295 grams
1 yr



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

### **MECHANICAL DIMENSIONS**





<sup>\*</sup>Dimensions in inches



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

### **SUPPORT**

Technical support for IDEAL INDUSTRIES products can be initiated through the following

methods:

Website: <a href="http://www.idealindustries.com/support/">http://www.idealindustries.com/support/</a>

Telephone: +1 800-435-0705

Email: <u>contactus@idealindustries.com</u>



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

#### **COMPLIANCE STATEMENTS**

This device is intended for commercial and industrial applications.

Changes or modifications not expressly approved by IDEAL could void the user's authority to operate the equipment. Use and maintain device only as specified in this manual.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

#### WARNING!

#### **FCC and IC Radiation Exposure Statement:**

This equipment complies with FCC's and IC's RF radiation exposure limits set forth for an uncontrolled environment under the following conditions:

- 1. This equipment should be installed and operated such that a minimum separation distance of 20cm is maintained between the radiator (antenna) & user's/nearby person's body at all times.
- 2. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit

ND xxxx-x 03/2017 Users Manual – LCE20A-1000 – 20Amp Luminaire Controller 0-10V Dimming



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



### LCE20A-1000 - 20Amp Luminaire Controller 0-10V Dimming

#### **IMPORTANT NOTICE**

Information furnished by IDEAL INDUSTRIES, INC. is believed to be accurate and reliable. No license, express or implied, to any intellectual property rights is granted by this document. No responsibility is assumed by IDEAL INDUSTRIES, INC. for its use, nor for any infringements of patents or other rights of third parties that may result from its use. IDEAL INDUSTRIES, INC. assumes no liability for misuse of this product. Specifications are subject to change without notice.

No license is granted by implication or otherwise under any patent or patent rights of IDEAL INDUSTRIES, INC. Trademarks and registered trademarks are the property of their respective owners.

IDEAL INDUSTRIES, INC. PRODUCTS (INCLUDING HARDWARE AND/OR SOFTWARE) ARE NOT DESIGNED OR INTENDED TO BE FAIL-SAFE, FAULT TOLERANT OR FOR USE IN ANY APPLICATION THAT COULD LEAD TO DEATH, PERSONAL INJURY OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE (INDIVIDUALLY AND COLLECTIVELY, "CRITICAL APPLICATIONS"), SUCH AS LIFE-SUPPORT OR SAFETY DEVICES OR SYSTEMS, CLASS III MEDICAL DEVICES, NUCLEAR FACILITIES, APPLICATIONS THAT AFFECT CONTROL OF A VEHICLE OR AIRCRAFT, APPLICATIONS RELATED TO THE DEPLOYMENT OF AIRBAGS, OR ANY OTHER CRITICAL APPLICATIONS. CUSTOMER AGREES, PRIOR TO USING OR DISTRIBUTING ANY SYSTEMS THAT INCORPORATE IDEAL INDUSTRIES, INC. PRODUCTS, TO THOROUGHLY TEST THE SAME FOR SAFETY PURPOSES. CUSTOMER ASSUMES THE SOLE RISK AND LIABILITY OF ANY USE OF IDEAL INDUSTRIES, INC. PRODUCTS IN CRITICAL APPLICATIONS, SUBJECT ONLY TO APPLICABLE LAWS AND REGULATIONS GOVERNING LIMITATIONS ON PRODUCT LIABILITY.



### LCE20A-1000 – 20Amp Luminaire Controller 0-10V Dimming

#### **WARRANTY**

THIS LIMITED WARRANTY applies solely to standard transmitters manufactured by or on behalf of IDEAL. Subject to the limitations herein, IDEAL warrants that transmitters, when delivered by IDEAL or its authorized distributor, for one (1) year following the delivery date, will be free from defects in material and workmanship and will substantially conform to IDEAL publicly available specifications for such products in effect at the time of delivery. This limited warranty excludes: (i) engineering samples (which are provided "AS-IS" without warranty); (ii) bare circuit boards (iii) development products (such as boards and cables); (iv) design defects or errors known as "errata"; (v) transmitters procured through unauthorized third parties; and (vi) transmitters that have been subject to misuse, mishandling, accident, alteration, neglect, unauthorized repair or installation. Furthermore, this limited warranty shall not apply to the use of covered products in an application or environment that is not within IDEAL specifications or in the event of any act, error, neglect or default of Customer. If such IDEAL products fail to conform to the warranty above, the exclusive remedy of Customer and the sole liability of IDEAL shall be, at the option of IDEAL, to replace or repair the affected products, or to refund to Customer the price of the affected products. The availability of replacement products is subject to product discontinuance policies at IDEAL. Customer may not return products without first obtaining a customer return material authorization (RMA) number from IDEAL. THE WARRANTIES SET FORTH HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. IDEAL DISCLAIMS ALL OTHER WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT, AND ANY WARRANTY THAT MAY ARISE FROM COURSE OF DEALING, COURSE OF PERFORMANCE, OR USAGE OF TRADE. IF IDEAL CANNOT LAWFULLY DISCLAIM IMPLIED WARRANTIES UNDER THIS LIMITED PRODUCT WARRANTY, ALL SUCH IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD (AS DEFINED ABOVE). YOUR SOLE REMEDY WITH RESPECT TO ANY BREACH OF THE LIMITED PRODUCT WARRANTY SHALL BE THE REPAIR OR REPLACEMENT OF THE DEVICE AS SPECIFIED IN THE LIMITED PRODUCT WARRANTY. IDEAL IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH A SYSTEM CONTAINING IDEAL TRANSMITTERS. Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusions or limitations on the duration of implied warranties or conditions, so the above limitations or exclusions may not apply to you. This limited product warranty gives you specific legal rights, and you may also have other legal rights which vary from state to state.

ND xxxx-x 03/2017

Users Manual – LCE20A-1000 – 20Amp Luminaire Controller 0-10V Dimming