


spherical
bluetooth®
speaker



VIBETM
SOUND

Operation Manual VSAU780

FEATURES



1. On/Off Power Button
2. Battery Cover. Rotate clock-wise to open, counter clock-wise to close (Requires 3 AAA batteries, not-included)
3. Non-slip base

SAFETY

- Please read the operation manual carefully and follow all instructions.
- Store this manual for future reference.
- To avoid any damage or malfunction of the device, do not drop the device.
- Keep this device away from humidity, water and liquids. If the device is exposed to water, moisture and other liquids, do not use it to avoid electrical shock, explosion, damage to the device or yourself.
- Keep away from children.
- Keep away from heat, direct sunlight or open flame. This may cause explosion, degrade the performance and/or reduce battery life.
- Do not modify, repair or disassemble the device. Doing so will void warranty.
- Do not place heavy objects on top of this device.
- Do not use during lightning storms.
- The battery used in this device may present a risk of fire or chemical burn if mistreated.

FEATURES

The Spherical Bluetooth Speaker is compatible with all wireless Bluetooth devices such as iPhone, iPad, Samsung smartphones, tablets and other Bluetooth devices. It is a portable, wireless, and hands-free. Just place it anywhere in a room and enjoy pristine streaming audio from your phone, computer, or other Bluetooth devices. Bring music, movies, and all your mobile audio vibrantly to life—all in the palm of your hand.

PAIRING

1. Phone

- Power on the unit with the on/off button, a small beep from your speaker will notify you it is on, and indicator light will flash.
- Turn on the Bluetooth function in your phone, and search Bluetooth devices. Your phone will find the device named "VSAU-780." Select it, and the indicator light will flash quickly, notifying it is searching for your device.

2. Tablet

- Please refer to the above phone connection directions.

3. Laptop/Notebook/Netbook/PC

- As the Bluetooth version for laptop/ notebook computer /PC varies, the connection methods are different as well. If you cannot connect with the unit for play on first use, you may need to install a new version of the Bluetooth driver in your laptop. Please refer to the instructions of your PC or laptop for details.

PLAY MODE

Audio - play from the Bluetooth-connected device
Play - Use the on/off button, to play your music or play/pause your music directly from your device.
Volume Adjustment - Adjust from device directly

POWERING YOUR SPHERICAL BLUETOOTH SPEAKER

1. Grip battery cover and rotate clock-wise to open, and place 3 AAA batteries

SPECIFICATIONS

Bluetooth: V2.1 + EDR
Bluetooth Range Of: **10m**
Supported Profiles: A2Dp, AVRCP
Bluetooth MCU: CW6633 + APM030
Output Power Class: Class 2
Power: 3 AAA batteries required (not included)
S/N Ratio: $\geq 70\text{d}$
Frequency: 2.4GHz ~ 2.48GHz
Speaker Unit: 50mm, 2W (4 Ω)

TROUBLESHOOTING

If you cannot pair your device:

1. Check to see if the Bluetooth is under searching status. If not, turn on your speaker.
2. If no sound, check to see if the volume of music is turned off.
3. Make sure Bluetooth is enabled on your device.
4. Make sure the speaker and your device are within operating distance.
5. Check if the batteries need to be replaced

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARRANTY

The condition of this warranty and our responsibilities under this warranty are as follows:

- * Supplier's warranty is non-transferable. And this warranty is limited to the original purchaser only.
- * You must be able to prove the date of original purchase of the unit with a dated receipt.
- * The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- * The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.
- * Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- * A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
- * Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.
- * This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations.

We offer a warranty on our products in accordance with the following conditions:

1) Vibe™ products are covered by a 12 month warranty. We will resolve damages or defects on Vibe™ products free of charge within 12 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 12 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.

2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. Vibe™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.

4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.

5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.

6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business.

Asserting a warranty claim:

1) To make use of the warranty service for hardware issues, you must contact the Vibe™ Service Center by e-mail at service@dglusa.com

2) Vibe™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Vibe™.

IMPORTANT: Vibe™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Vibe™ Service Center specifies otherwise.

2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.

3) You must enclose a copy of the sales slip as proof of purchase.

4) Once Hype™ has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

Service outside of warranty Vibe™ can refuse any service claim made that is not covered by the warranty. If Vibe™ agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. Vibe™ will not accept any packages that have not first been approved by Vibe™ by means of an RMA (Return Material Authorization).