



SIMPLE GUIDE TO SIMPLE HOME

**GUIDE SIMPLE POUR
SIMPLE HOME**

**GUÍA SIMPLE PARA
SIMPLE HOME**



**POWERED BY
XTREME®**

855-999-8041
WWW.GOSIMPLEHOME.COM

SMART PLUG

(MODEL: MA-1025-B)

Box Contents:

- 1) Smart Controlled Wall Plug
- 2) QR code hangtag (needed for setup)
- 3) User manual

AND ENERGY MONITOR- E-PLUG

GETTING TO KNOW YOUR DEVICE

Product Features:

- Remotely turn devices on and off via App from anywhere in the world
- Set weekly schedules to have devices turn off when you are away
- Monitor the amount of energy being used by connected devices

- Includes a manual power button with light indicator
- All of your products controlled by the Simple Home App


System Requirements:

- 1) Wi-Fi Router with a strong internet connection
- 2) Android mobile device version 4.0 or greater/ Apple iOS 8 or greater

Simple Guide for All Simple Home Products

STEP 1

- **DOWNLOAD THE SIMPLE HOME APP ONTO YOUR MOBILE DEVICE.**
- **ONCE DOWNLOADED, OPEN THE APP AND CREATE AN ACCOUNT**
 - After your account has been created, it will prompt you to check your email to verify the account. Please allow up to five minutes for an email confirmation.
 - If you do not receive an email by then, please check your spam mail before you resend another verification email.
- **AFTER RECEIVING YOUR VERIFICATION EMAIL, PLEASE FOLLOW THE CONFIRMATION LINK**
 - This will ensure that your account has been setup successfully.



STEP 2


- **PLUG IN YOUR DEVICE**

- **CONNECT YOUR MOBILE DEVICE TO YOUR PRIMARY WIFI NETWORK.**

- (Device may be already connected) While you're in your Wifi settings, check to see if your Simple Home device shows up in your list of Wifi Networks. If it does show up **don't click on it yet!** Move on to next step.




Plug in Device



Android WiFi



Apple WiFi



Log in

- **GO BACK TO THE SIMPLE HOME APP TO SIGN IN**


- You will see a basic preview of the app. To skip, swipe to the left until you exit and end up on the home screen (See Below).



Menu Icon




Device Icon



Connection Icons



Product Grouping



Home Screen

- You should see four greyed out pictures of devices that are not yet activated.

STEP 3

- **PRESS THE ADD BUTTON [+]** TO ADD YOUR DEVICE

- **SCAN YOUR QR CODE LOCATED ON THE HANGTAG INSIDE THE BOX**

- **ENTER YOUR WIFI NETWORK** (if it has not automatically filled it in for you already)

- **ENTER NETWORK PASSWORD**

- **ENTER DEVICE NAME** (Location based names like Garage, Basement, and Attic work great!)

- **CLICK THE CHECK MARK AT THE TOP RIGHT CORNER TO BEGIN PAIRING**


- **IPHONE USERS**, go to your WiFi network's list and select "EPLUG" from your Wifi List.

- Please wait for it to successfully connect. **Once connected, return to your Simple Home App.** Final WiFi binding of your product may take two to five minutes. Then once it connects, the app should direct you back to the home screen.

- If the app does not refresh after installation is complete, please shut down the app and restart your device.

- **ANDROID USERS**, stay on the "add device" screen and wait until your device automatically connects.

- The connection from your primary Wifi network to your device's network will happen automatically, so patiently wait.
- Android users will see a text notification at the bottom of this screen, making them aware of the connection process. If you do not get this message, follow the steps for Iphone users.



• **TO CONNECT OTHER DEVICES**

- Follow steps 1-3 to connect your other devices.

Features of the Wall Plug in the Simple Home App:

- Once you are logged into your app and setup is complete, press the plug icon in the app's home screen. You are then going to see all the plugs you have connected. (Figure 1)
- To turn your plug on/off press the green button on the plugs' tab to turn the device off and press the red button to turn the light back on.
- If you press on the tab itself, the next screen will be the on/off switch with four icons down at the bottom of the screen. (Figure 2)
- Schedule Icon: Allows you to add schedules (time slot) of when you want to turn on/off your plug.(Figure 3)




Figure 1



Figure 2




Figure 3



- Settings Icon: You can name your device. (Figure 4)
- Favorites Icon: Can select item to appear on the "Favorites List" for easy access. (Figure 5)
- Trash Icon: Allows you to delete the Simple Home product from your device. (Figure 6)




Figure 4




Figure 5



Figure 6



Trouble Shooting:

The reset button is on the front of the device. When the device disconnects, the indicator is a slow blinking white light. Next log out of your app and restart your phone. Press and hold the reset button for 8 seconds and the device should appear on the WiFi Network List. Make sure you click the device on the network's list to reestablish its settings. Once you have turned your phone on again, log back into the app and make sure everything is working properly. If you are still having trouble please call: 855-999-8041



FAQ:

Q: How do I add a new device into the app?

A: On the "All Devices" screen press the + sign at the bottom.

Q: How do I locate the QR code to set up my device?

A: Located on a hangtag inside the box and on the actual product

Q: What are 'Groups'?

A: Groups are a way for you to group items together.

Examples of groups could be; Upstairs, Outside, Kitchen, Playroom, Bedroom, Vacation Home . . .

Q: Can I combine devices from my different homes in one app?

A: Yes! If you are putting devices in different geographical locations then you can access them all within the Simple Home App without switching between locations. Here is a good place to use groups to separate the different locations, like Home and Vacation Home.

Q: What are 'Favorites'?

A: Favorites are where you can have the devices you use the most show up. To add a device to a favorite, simply press the little star on the device screen.

Q: How to see more options and settings for the plugs?

A: Press the 3 little dots in a circle on the bottom right corner of the wall plug bar.

Q: What are 'Actions'?

A: Actions are our way of saying "If this happens then that happens." An example would be: If the motion detector detects motion, then the LED should turn on.

Q: What are 'Schedules'?

A: Schedules is where you can view and make schedules for your wall plugs and LED's to turn on and off.

Q: What does it mean when LED on items blink?

A: If the button is blinking white slowly your device is disconnected. When the light blinks quickly, your device is connecting to WiFi. When it is fully connected the light will stay on.

Q: How do I get more help?

A: We are always here to help! Email us at simplehome@xtremecables.com or call our customer service at 855-999-8041

FCC WARNING

□ □

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***RF warning:**

The device has been evaluated to meet general RF exposure requirement.

The distance between user and products should be no less than 20cm

**SIMPLEHOME**TM
AUTOMATED CONTROL




XTREME[®]

855-999-8041 | www.GoSimpleHome.com

**If you have any questions about this product contact the manufacturer for support, do not return to retailer.
si vous avez des questions sur ce produit, contactez le fabricant pour le support, ne retournez pas au détaillant.
Si usted tiene alguna pregunta acerca de este producto, comuníquese con el fabricante para obtener ayuda, no regrese al minorista.**

*Message and Data rates may apply / Le taux des messages et des données peuvent être applicable

*Pueden aplicar cargos por mensajes y datos



Control your home anytime, anywhere!



DOWNLOAD/TÉLÉCHARGER/DESCARGAR
"SIMPLE HOME"
APP STORE/ PLAY STORE

