

Use and Care Guide

Smart Plug(BLE)

1 Safety information

WARNING:

- For indoor use only. Do not use in wet locations.
- The total current limit of the device is 15 A. Do not exceed this value!
- If a direct short is created on the output, the Smart Plug will be damaged and no longer function.
- Do not disassemble the product, or make repairs yourself. You run the risk of electric shock and voiding the limited warranty. If you need service, please contact us.
 - Do not connect after each other (DE: Nicht hintereinander stecken)
 - To disconnect voltage pull the plug (DE: Spannungsfrei nur bei gezogenem Stecker)
 - Do not position the equipment so that it is difficult to operate the disconnecting device.
- The equipment shall be connected to a MAINS socket outlet with a protective earthing connection.
-



Electrical and electronic equipment that is no longer usable and defective or used batteries must be separated from other waste and recycled in an environmentally friendly manner (European Directive on waste electrical and electronic equipment).

To dispose of electrical and electronic equipment or batteries, use your country-specific return and collection systems.

2 Package Contents


Smart Plug *1

Quick start guide*1

3 Product Description

The plug turns your electrical appliances smart by enabling you to control them through the smart home APP on your phone at or away from home. It also enables you to automatically switch appliances on and off according to a programmable timer and measure the energy consumption.

LED Indicator: Under normal working state, Green—on, Red—off.

Icon	Status	Behavior
	Slow Breathing Green	Plug initiated, is ready to start plug network configuration
	Quick Blinking Green	Connecting to the network or disconnected from the network
	Solid Green	Connected to the network and plug is turned on
	Red	The Smart plug is Switched off

Specification

Input	120V~,60Hz,15A
Output	120V~,60Hz,15A, 1800 W(Resistive),1/2 HP
Operation Frequent Range	BLE, 2400-2483.5MHz
Maximum RF Output Power	6dBm
Operating temperature	0°C-40 °C
Certification	UL, FCC

4 Installation and Operation

Step 1. Download and install the App

Get the Arnoo APP in Apple store or Google Play

Step 2. Register and login

Open the app, and it will take you through creating an account and login to the home screen.

Step3. Add the Plug

- A Turn on the Bluetooth of your smartphone
- B Connect the smart plug to a grounded wall socket, back to the app to start plug set up. From the home screen press the "+" symbol to add plug, follow the in-app instruction to complete setup.

5 Function

5.1 Remote Control: Turn your electronic device on and off from anywhere using the mobile app.

5.2 Schedule: Set specific times for your device to turn on/off as setting connected lighting turn on at 19:00 every Monday. Or like setting lights to come on at dusk or turn off at sunrise.

6 Trouble shooting

1. Q: What devices can I control with the Smart Plug?

A: You can control lights, fans, humidifiers, portable heaters, and any small appliances in accordance with the Smart Plug' s specifications.

2. Q: What can i do, if Arnoo app cannot searched the Smart Plug.

A: Make sure your smartphone' s Bluetooth is turned on then Press and hold the power key 5s to reset your plug. Try to add process again.

3. Q: How to factory reset the smart plug.

A: Press and hold the power key 5s until the Led indicator blinks green slowly.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC 20cm RF

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

Cet équipement est conforme aux limites d' exposition aux rayonnements de la IC établies pour un environnement non contrôlé. Cet équipement doit être installé et fonctionner à au moins 20 cm de distance d' un radiateur ou de votre corps.



For more information, Welcome visit: www.leedarson.com.

Mail to: iot@leedarson.com

LEEDARSON LIGHTING CO., LTD.

XINGDA RD, XINGTAI INDUSTRIAL ZONE, CHANGTAI COUNTY, ZHANGZHOU,FUJIAN,
363900, CHINA