







Important Safety Instructions

Read and follow all the safety instructions:

- · This device is for indoor use only.
- This device should not be exposed to dripping or splashing water.
- · Do not install near any heat sources.
- · Do not clean this device with liquid.
- · Do not use this device in wet or damp areas.
- Do not place any sources of danger on this device (e.g. liquid filled objects, lighted candles)
- · This device should only be installed by adults. Children should not install this device.
- · Keep children away from Smart Plug and the power outlet.
- RISK OF ELECTRIC SHOCK: USE IN DRY LOCATIONS ONLY. Do not install this device with wet hands.

Notice



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

FCC Statement

FCC ID: 2AB7K-T1201

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



















Specifications

Model	T1201	
Rated Input	AC 120 V, 60 Hz, 15 A	
Rated Output	AC 120 V, 60 Hz, 15 A, Max. 1800 W	
Dimensions	63.5 X 63.5 X 55 mm / 2.5 X 2.5 X 2.2 in	
Weight	95 g / 0.21 lbs	















Owner's Manual

Smart Plug

At a Glance



LED Indicator:

- Indicates the on/off status of Smart Plug.
- Indicates the network connection status.

Power Button:

- · Press to turn Smart Plug on or off.
- Press and hold for 5 seconds to reset the Wi-Fi connection.

	LED	Status	Indicates
	LED Indicator	Flashing amber and blue	Your smartphone is ready to connect to Smart Plug.
		Rapidly flashing blue	Smart Plug is connecting to a Wi-Fi network.
		Solid blue	Smart Plug is connected to a Wi-Fi network.


What You Need for Wi-Fi Setup



- Your Smart Plug
- A device you want to control
- A smartphone or tablet
- A wireless router

Using Your Smart Plug

- 1 Plug Smart Plug into a power outlet.
- 2 Plug a device into Smart Plug.



3 Control the plugged-in device with the EufyHome app or voice control through Amazon Alexa.



- Devices controlled by an electronic or infrared remote control are not supported.
- To wirelessly control your device, make sure the device is turned on.
- There are three ways to turn the connected device on or off: 1) press the Power Button on Smart Plug; 2) use the EufyHome app; 3) control the device with your voice using Amazon Alexa.

Downloading the EufyHome App

What you need:

- A Wi-Fi router supporting the 2.4 GHz and 802.11 b/g/n bands; the 5 GHz band is not supported;
- A smartphone or tablet connected to a Wi-Fi network;
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).







GUFY
For FAQs and more information, please visit

www.eufylife.com

Download the EufyHome app from the App Store (iOS devices) or Google Play (Android devices).

T1201 51005000584 V01

>2


Connecting to a Wi-Fi Network

- 1 In the EufyHome app, tap the "+" icon on the top right to add "Smart Plua" to your EufyHome account.
- 2 Follow the on-screen instructions to complete Wi-Fi



The instructions in this manual are for your reference only. The app will be updated from time to time. Always follow the instructions in the app to complete Wi-Fi setup.

Controlling Your Plugged-in Devices with the EufyHome App



Controlling Your Plugged-in Devices with Amazon Alexa (Optional)

What you need:

- · Your Smart Plug connected to a Wi-Fi network;
- · An Alexa-enabled device (sold separately) such as Eufy Genie, Amazon Echo, Amazon Echo Dot and Amazon Tap:
- An existing Amazon account:
- The Alexa app installed on your smart device.
- 1 Open the Alexa app and select "Skills" from the 🗏 menu in the top left corner of the homepage.
- 2 On the Skills screen, search for "EufyHome".
- 3 Once you have found the "EufyHome" skill, tap **Enable**.
- 4 Login with your EufyHome account to authorize Alexa to access your account.
- 5 Discover new smart devices via the "Smart Home" menu in the Alexa app or Alexa voice control.
 - ➤ Once the device is connected, you can control the plugged-in device with your voice.
- 6 Say simple commands to Alexa. (Note: You can modify the name of a device in the EufyHome app.)

Alexa, turn on my lamp.

Alexa, turn off my lamp.

- The Amazon Alexa service is currently available in English only. More languages may be available later with the update of the service.

Troubleshooting

1. Cannot connect to your Wi-Fi network.

- · Check whether you have entered the correct Wi-Fi password.
- Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.
- · If the LED Indicator is solid blue, indicating Smart Plug is connected to a Wi-Fi network, refresh or restart the EufyHome app and try again.
- · If you still have trouble, press and hold the Power Button for 5 seconds to reset the Wi-Fi connection.

2. How to reset the Wi-Fi connection.

- Press and hold the Power Button for 5 seconds to reset the Wi-Fi connection. The LFD Indicator will start flashing and alternate between amber and blue, indicating Smart Plug is ready for Wi-Fi setup.
- 3. No response when using the devices with the EufvHome app.
- Check whether Smart Plug is powered on.
- · Check whether there are any Internet problems. If necessary, reset your Wi-Fi router and try again.
- If your smart device uses a 3G or 4G mobile network. check whether the network signal is abnormal. Try again when the signal becomes stable.
- · If you still have trouble, reset the Wi-Fi connection and restart the Wi-Fi setup.
- 4. Cannot control the connected devices with Alexa voice control.
- Check whether there are any Internet connection problems
- · Check whether you have installed the Alexa app onto your smart device and enabled the "EufyHome" Skill in the Alexa app. For details, refer to the Controlling Your Plugged-in Devices with Amazon Alexa (Optional) section of this manual.
- Check whether you are using the proper commands when talking to Alexa. When making your request, first say the wake word "Alexa".
- Repeat your question. Speak naturally and clearly to Alexa in English.

· Check whether you have modified the name of Smart Plug in the EufyHome app. If yes, you need to rediscover the device through the Alexa app or Alexa voice control.

5. What should you do if Smart Plug automatically turns off?

• Smart Plug only supports devices whose power is no more than 1800W. Unplug the connected device and check whether the power exceeds 1800W.

Customer Service

- 18-month limited warranty
- Lifetime technical support
- support@eufvlife.com
- +1 (800) 988 7973 (US) Mon-Fri 9:00 17:00 (PT) +44 (0) 1604 936200 (UK) Mon-Fri 6:00 - 11:00 (GMT)
- +49 (0) 69 9579 7960 (DE) Mon-Fri 6:00 11:00 +81 03 4455 7823 (JP) 月 - 金 9:00-17:00
- +86 400 0550 036 (中国) Mon-Fri 9:00 17:30
- n @EufyOfficial 👽 @EufyOfficial
- @EufyOfficial @EufyOfficial