



orbic[®]
TAB10R
4G[™]

**QUICK
START
GUIDE**

Table Of Contents

Getting Started.....	3
Orbic TAB10R 4G Overview	4
Installing a SIM card.....	5
Charging the Battery.....	6
Powering ON/OFF.....	7
Google™ Account	8
Using On-Screen Gestures.....	9
Lock and Unlock the Device.....	10
Camera.....	11
Google™ Play Store.....	13
Installing Apps.....	13
Uninstalling Apps.....	14
Improving Accessibility.....	15
Connecting to Wi-Fi.....	15
FCC Statement.....	16
FCC Warning.....	18
Support and More.....	19

Getting Started

Thank you for choosing the Orbic TAB10R 4G.

This guide helps you to get started with your Orbic TAB10R 4G for the first time.

The TAB10R 4G has built-in 4G capabilities, that can be utilized to connect to the internet anywhere and anytime.



Orbic TAB10R 4G Overview



NOTE: The screen images and icons here are for reference only since the software constantly evolves.

The TAB10R 4G is bundled with a stylus; a digital pen tool that is used for navigating, drawing pictures, and taking notes.


The Orbic TAB10R Kickstand (sold separately) is compatible for use with the Orbic TAB10R 4G.

Installing a SIM Card

Pop out and swivel the rubber cap that is protecting the SIM slot, insert the SIM tool in the SIM pin hole to release the tray (as shown in the figure below). Place the SIM card in the slot with the gold contacts facing down, close the tray and replace the rubber cover. Your Orbic TAB10R 4G is now ready to be used.

The SIM tray also has a slot for microSD card that can be inserted following the steps mentioned above.

NOTE: The microSD card is sold separately.



Charging the Battery



Before using Orbic TAB10R 4G, Orbic recommends to fully charge the battery (100%).

1. Pop out and swivel the rubber protective cap. Insert the smaller end (USB Type-C) into the device and the larger end (USB Type-A) into the charger adapter.
2. The adapter shall be installed near the Orbic TAB10R 4G and shall be easily accessible.

Warning! Use only approved chargers with your Orbic TAB10R 4G. Incompatible chargers that are tampered with may damage the Orbic TAB10R 4G and void the warranty.

Powering ON/OFF



To turn ON,

- Press and hold the **Power/Lock** key.


To turn OFF,

- Press and hold the **Power/Lock** key and follow the prompts.


Google™ Account

Orbic TAB10R 4G uses your Google account to fully utilize its Android features, including Gmail, Google Cloud Storage, and the Google Play Store. When you turn ON your device for the first time, set up a connection with your existing Google account, or create a new Google account.

To Sign in to your Google Account

1. Tap **Home Key** ● > **Google Folder** > **Gmail** .
2. Sign in to your account by entering the email address and password.

To Create a New Account

1. Tap **Home Key** ●, swipe up for **Apps** > **Settings**  > **Passwords & accounts**.
2. Tap + **Add account**.
3. Enter the email address and password.
4. Follow the prompts to setup your email account.

Google™, Google Play, Android™ are trademarks of Google™ LLC.

Using On-Screen Gestures

Use the on-screen gestures to move around the screen; open menus, select items, zoom in or out on web pages, and more.

- **Tap** - To open an app, select a menu item, press an on-screen button, or to enter a character using the keyboard on the screen, tap it with your finger.
- **Touch and Hold** - Touch and hold an item or the screen for more than 2 seconds to access available options.
- **Drag** - To move an item, touch and hold it and drag it to the target position.
- **Double Tap** - Double-tap on a web page or image to zoom in. Double-tap again to return.
- **Swipe** - Swipe to the left or right on the screen to scroll left or right. Swipe upwards or downwards to scroll through a web page or a list of items.
- **Spread and Pinch** - Spread two fingers apart on a web page, map, or image to zoom in on a part. Pinch to zoom out.

Lock and Unlock the Device

To Lock the Screen

- Press the **Power/Lock** key. This action prevents the accidental keypress.



To Unlock the Screen

- Press the **Power/Lock** key and swipe up on the screen.



Camera



Taking photos

1. From the Home screen, tap .
2. Aim the camera at the subject using the tablet's main display screen as a viewfinder.
3. Pinch the screen to zoom out or pinch open to zoom in.
4. Before taking a photo, you can tap on the screen icons to access various camera options and settings, if required.
5. Tap  to capture a photo.

NOTE: You can also use the volume keys to capture a photo.



Recording videos

1. From the Home screen, tap .
2. Tap **Video** on the screen to switch to the video mode.
3. Aim the camera at the subject using the tablet's main display screen as a viewfinder.
4. Pinch the screen to zoom out or pinch open to zoom in.
5. Tap the  button to start recording the video.

Google™ Play Store

Find and download your favorite apps, movies and TV shows, music, books, magazines, and games.

Installing the Apps

Your device comes preloaded with several applications, and you can download many more from the Play Store.

NOTE: The Play Store is an application that comes preinstalled on Android™ devices.

To install applications from the Play Store

1. Search or browse for applications.
2. Select the desired app, download, and install.
3. Follow the on-screen instructions to complete the installation.
4. You can also uninstall, update, and manage your downloaded apps.

Uninstalling the Apps

1. Touch and hold the app icon that you want to uninstall.
2. Tap App info, then select **Uninstall** and follow the prompts to uninstall the app.
3. Tap **OK** to confirm or **Cancel** to stop the uninstallation.

NOTE: Some of the preloaded apps on the device cannot be uninstalled.

Improving Accessibility

Accessibility options are special features that make using the Orbic TAB10R 4G easier for people who are physically handicapped.

To set accessibility options

1. Tap **Home key** ● > swipe up for **Apps** > **Settings** ⚙️ > **Accessibility**.
2. Tap a category and set the desired options.

Connecting to Wi-Fi

1. Tap **Home key** ● > swipe up for **Apps** > **Settings** ⚙️ > **Network and internet** > **Wi-Fi**.
Make sure the Wi-Fi is turned ON.
2. Select a displayed network or tap **Add network**.
3. Enter the network SSID and other required information.
4. Tap **Save**.

FCC Statement

This device with **FCC ID: 2ABGH-RC10RLT** complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off. In that case, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC SAR Warning

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions (0mm) accepted by the FCC, with the device transmitting at its highest certified power level in all tested frequency bands.

FOR COUNTRY-CODE SELECTION USAGE (WLAN DEVICES)

NOTE: The country code selection is for non-U.S. models and is not available to all U.S. models. Per FCC regulation, all Wi-Fi products marketed in the U.S. must be fixed to U.S. operation channels only.

Support and More



For how to use, or more tips and tricks on getting the most out of your new Orbic TAB10R 4G, check out the guides and more information at -

orbic.us



Customer service

Call 1 877 872 4555



Product Safety and Warranty Information

For full details, visit

orbic.us



V5

 orbic[®]
TAB10R_{4G} 

**PRODUCT
SAFETY &
WARRANTY
INFORMATION**

IMPORTANT SAFETY INFORMATION

Keep the device away from dust, water, damp areas, precipitation, and humidity. Dust, water, liquids, precipitation, and humidity may cause overheating, electrical leakage, and/or device failure. The device, battery, charger, and AC adapter are not waterproof. Keep them away from liquid, fuels, and chemicals. If the device gets wet, do not place the device in an oven, microwave, or dryer, as this will damage the device and could cause a fire or explosion.

Only use the battery and charger approved by the manufacturer. Using other brands may cause battery leakage, overheating, explosion or even fire. Do not use the device where it might cause danger. Do NOT text and drive.

BATTERY USE

Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling and, particularly, from the continued use of damaged batteries.

- Do not disassemble, open, crush, bend, deform, puncture, or shred the battery.
- Do not modify, remanufacture, attempt to insert foreign objects into the battery; immerse or expose to water or other liquids, expose to fire, explosion, or other hazards.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or another hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or another hazard.
- Only authorized service providers shall replace battery. (If the battery is non user replaceable).
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the device or battery. If the device or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Do not replace an embedded battery pack. Improper replacement may present a risk of fire, explosion, leakage or other hazard. Contact the manufacturer for replacement instructions.

- The device recognizes the battery via battery part number.
- The maximum operating temperature range is 0° to 45° (while charging is 40° only).

NOTE:

The battery shall only be serviced by the manufacturer.

CAUTION:

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries in accordance with local regulations.

CLEANING AND MAINTENANCE

The device, the battery and the charger are not waterproof. Do not use them in places with high humidity like a bathroom. Avoid spilling any liquids on the device, battery or charger. Use a soft cloth to clean the device, the battery, and the charger. Do not use alcohol, diluted liquid, or benzene to clean the device.

DISPOSAL OF PRODUCT AND BATTERIES

Follow local regulations regarding disposal of mobile devices and batteries. In some areas, the disposal of these items in household or business trash may be prohibited. Please follow your local regulations and recycle device if required batteries must be recycled or disposed of properly.

FCC SAR WARNING

This model device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government:

The exposure standard for wireless mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons regardless of age and health.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on: FCC ID: 2ABGH-RC10RLT or at <http://www.orbic.us/>

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 0mm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the device at the ear, position the handset a minimum of 0mm from your body when the device is switched on.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE 1:

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To view device FCC ID on a device, look at the label in the battery compartment, for devices without a battery door there is an E-label information available by selecting: Settings > About device.

NOTE 2:

Orbic or the manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to the device. Such modifications could void the user's authority to operate the equipment.

Data transmission is always initiated by software, which is then passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the end of the packet. Therefore, the transmitter will be on only while one of the aforementioned packets is being transmitted. In other words, this device automatically discontinues transmission in case of either absence of information to transmit or operational failure.

ORBIC LIMITED WARRANTY

WHO THIS WARRANTY COVERS

This 12 month limited warranty extends only to the original purchaser of this device within the United States. This warranty is not transferable. This warranty is conditioned upon the proper use of the device.

WHAT THIS WARRANTY COVERS

Orbic offers you a limited warranty that extends for the first twelve (12) month period to the original purchaser from the date of original purchase with proof of purchase. Without valid proof of purchase, Orbic offers a limited warranty extending fifteen (15) months from date of manufacture, which is coded on the device label ("Warranty Period").

Should the device, inbox accessories or any part during normal consumer usage and conditions be proven defective in material or workmanship that results in device failure, such defect(s) will be repaired or replaced (with new or rebuilt parts) at Orbic's discretion, without charge for parts or labor directly related to the defect.

WHAT THIS WARRANTY DOES NOT COVER

1. Warranty claims outside of the device warranty Period.
2. Damage or defects caused by using the device other than in the normal course.
3. Defects or damages resulting from accidental, misuse, abnormal use, abnormal conditions, improper storage, unauthorized modifications, unauthorized repair, improper installation, or other acts which are not the fault of Orbic.
4. Defects or damage resulting from excessive force or use of a metallic object when pressing the touch screen.
5. device with altered, defaced or removed serial number.
6. Damage resulting from use of accessories not approved by Orbic.
7. Damage from exposure to moisture, humidity, excessive temperature or extreme environment.
8. Liquid damage due to not properly sealed/locked accessories, ports and or battery latches of water resistance devices.
9. All surfaces and externally exposed parts that are scratched or damaged due to normal customer use.
10. All software, including operating system software, third-party software, applications, and all other software of any kind.
11. Damage caused by ordinary wear and tear of the device.
12. Customer abuse or other physical abuse or mistreatment of device as evidenced by:
 - a. Missing required faceplate;
 - b. Damaged LCD or Lens (e.g., the device is either broken, cracked, smashed, bleeding, etc.);
 - c. IMEI is unreadable electronically or due to missing or altered serial number, IMEI and/or reliance data label so as to affect readability;
 - d. Missing keys on keypad beyond normal wear and tear;
 - e. Unapproved device modification;
 - f. Visible device surface physical damage resulting in device being smashed, chewed, gouged, burned or melted;
 - g. Liquid damage as evidenced by submission in liquid or any other evidence of liquid ingress, including corrosion of any of the connections and noticeable excessive residue.

WHAT ARE THE LIMITS OF ORBIC'S LIABILITY

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF ORBIC'S RESPONSIBILITIES AND THE EXCLUSIVE REMEDY REGARDING THE DEVICE. ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL ORBIC BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE DEVICE OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS, OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE DEVICE. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

ORBIC MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE DEVICE, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE DEVICE DISTRIBUTED BY ORBIC OR OTHERWISE. RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD- PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT.

Nothing in the device instructions or information shall be construed to create an express warranty of any kind with respect to the device. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of Orbic regarding the device or this Limited Warranty.

This Limited Warranty gives you specific legal rights and you may also have other rights that vary from state to state.

WHAT ARE THE PROCEDURES FOR RESOLVING DISPUTES

ALL DISPUTES WITH ORBIC ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE DEVICE SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY. Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's devices or claim and, specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of New York, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty. This arbitration provision also applies to claims against Orbic's employees, representatives and affiliates if any such claim arises from the device's sale, condition or performance.

HOW TO GET WARRANTY SERVICE

To obtain warranty service, please call the following telephone number from anywhere in the continental United States: **1-877-872-4555**.