

Quirky®



PIVOT POWER® SMART

control power to anything from anywhere

Relocatable Power Tap

OVERVIEW

Part of the Quirky® collection of smart products, Pivot Power® Smart is a flexible, app-enabled power strip.

Smart outlets allow you to turn anything that's plugged in on or off from anywhere using your mobile device.

FEATURES


- 1 Four adjustable AC outlets
- 2 Independently control two smart outlets from your mobile device
- 3 Program and schedule when you want the two smart outlets to turn on and off
- 4 Instantly connects to your mobile device over any 2.4GHz Wi-Fi® network or better
- 5 Works with Amazon Alexa and Google Home

WHAT'S INCLUDED (IN THE BOX)

- 1 Pivot Power Smart
- 2 Quick Start Card
- 3 Instruction Manual

REQUIRED FOR USE (NOT INCLUDED IN BOX)

- 4 Wi-Fi®
- 5 Mobile device
- 6 Pivot Power® Smart app



GETTING STARTED

- 1 Download and install the Pivot Power® Smart app on your mobile device as outlined in the Quick Start Card. The app will enable a Wi-Fi® connection between your mobile device and Pivot Power Smart.
- 2 Plug Pivot Power Smart into a grounded wall outlet and press the power button to turn it ON. When the power strip is ON, the indicator light will glow. DO NOT plug devices into any of the outlets at this time.

When the power strip is ON, the two regular outlets are always ON. The two smart outlets are defaulted to ON, but can be controlled with the Pivot Power® Smart app.

- 3 Open the Pivot Power® Smart app. Follow the app's instructions to connect to your Pivot Power Smart.

Your mobile device connects by sending light pulses into a sensor on your Pivot Power Smart. It is best to do this in a dimly lit environment.

- 4 Once you've connected, you can plug devices into Pivot Power Smart

Note: DO NOT OVERLOAD the power strip. ONLY connect the device to a grounded outlet. DO NOT connect to an ungrounded outlet. DO NOT extend or daisy chain with other power strips or adapters.

USING PIVOT POWER SMART

You can use Pivot Power Smart to:

- 1 Adjust and rotate each outlet to fit designated areas and/or large plugs and power adapters.
- 2 Turn ALL outlets ON or OFF using the main power button.

- 3 Control both smart outlets:

By manually turning each outlet's switch ON/OFF from your Pivot Power® Smart app or using the buttons on the side of the power strip.

By creating a power ON/OFF timer via the Pivot Power® Smart app. Use it to set notifications for Wi-Fi® or power status.

Note: LEDs next to each smart outlet indicate whether that outlet is ON or OFF. Troubleshooting



ON/OFF button for each outlet located on the side of the power strip.

If the Wi-Fi® connection has been lost, any scheduled timers may not execute depending on the outage time. Reconnect the Wi-Fi® network.

If the Pivot Power® Smart app has lost control of the smart outlets, it may be that Pivot Power Smart has lost its connection to the Wi-Fi® network. Try turning the power strip OFF then ON again to restore its connection.

If you experience a power outage, power will cease to ALL outlets and the Pivot Power® Smart app connection will be lost. When power is restored, check the main power button to ensure the power strip is ON to regain connection.

If you can't control the smart outlets from a different mobile device, ensure you are using the same account information within the app.

If you do not get push notifications on your mobile device from the Pivot Power® Smart app as you have specified in the app, please check that notifications are turned on for Pivot Power® Smart app in your mobile device's notification settings.

Questions? For service and support or tutorials, email us at cs@viatek.com or call 1-888-784-2835.

IMPORTANT SAFETY INSTRUCTIONS / WARNINGS



CAUTION

To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.

WARNING

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

WARNING

Timer could turn-on unexpectedly without the user being present. To Reduce the Hazardous Condition - unplug the appliance that is plugged into the receptacle(s) controlled by the timer before servicing.

CAUTION

This unit must be connected to an outlet with a protective grounded connection.

CAUTION

To completely disconnect this product from power, disconnect the plug from the wall outlet. The plug is used to completely disconnect the power supply to the unit and must be within easy access to the user.

CAUTION

To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

IMPORTANT SAFETY INSTRUCTIONS

- 1 Read Instructions**— All safety and operating instructions should be read before operating the device.
- 2 Heed Warnings**— All warnings on the device and in the operating instructions should be adhered to.
- 3 Follow Instructions**— All operating and safety instructions should be followed.
- 4 Water & Moisture**— The device should never be used in, on or near water for risk of electric shock.
- 5 Ventilation**— The device should always be located in such a way that it maintains proper ventilation.
- 6 Heat**— Never locate the device near heat sources such as radiators, floor registers, stoves or other heat-generating devices.
- 7 Grounding**— DESIGNED FOR INDOOR USE ONLY! The device should ONLY be connected to a grounded outlet. DO NOT connect product to an ungrounded outlet.
- 8 CAUTION:** Risk of Electric Shock. Do not plug into other Relocatable Power Taps.
- 9 Power Cord Protection**— Power cables should be routed so they are not likely to be stepped on or crushed by items placed on them or against them. Special attention should be paid to areas where the plug enters a socket and where the cord exits the device.
- 10 Cleaning**— Clean product with a damp soft cloth. DO NOT submerge Pivot Power Smart in water.
- 11 Periods Of Non-Use**— Make sure to unplug Pivot Power Smart when it is not expected to be used for several months.
- 12 Dangerous Entry**— Care should be taken that no foreign objects or liquids fall or are spilled on or inside the device.
- 13 Damage Requiring Service**— The device should be serviced by licensed technicians when:
 - The internal electronic components have been damaged.
 - Objects have fallen or liquid spilled inside of the device.
 - The device has been exposed to moisture.
 - The device does not appear to be operating properly or exhibits a marked change in performance.
 - The device has been dropped or becomes damaged.
- 14 Service**— The device should always be serviced by licensed technicians. Only replacement parts specified by the manufacturer should be used. The use of unauthorized substitutions may result in fire, shock, or other hazards.
- 15 When servicing:** Unplug any appliance that is plugged into the power strip before servicing.
- 16 Caution-** Do not install this device if there is not at least 10 meters (30 feet) or more of wire between the electrical outlet and the electrical service panel.
- 17 Pivot Power Smart** features an internal protection that will disconnect the surge protective component but will maintain power to the load - now unprotected. If this situation is undesirable for the application, follow the manufacturer's instructions for replacing this device.
- 18 Wi-Fi®** controlled receptacles are not to be used with heater type devices (irons, space heaters, coffee makers), medical equipment and other types of devices that could pose a safety concern if the receptacle inadvertently turns ON or OFF.
- 19 High power devices** such as air conditioners, refrigerators and power tools should not be plugged into a surge protected power strip like Pivot Power Smart. Such devices are a common

source of surges when they are turned on and off. Exposing the surge protector to additional surge events will accelerate wear and tear on the surge protection feature and degrade its performance.

A NOTE ABOUT RECYCLING:

This product and its packaging materials are recyclable. Please dispose of any materials in accordance with the local recycling regulations. When discarding the unit, comply with local rules or regulations. This product and the supplied accessories constitute the applicable product according to the WEEE directive.

MODIFICATIONS DISCLAIMER WARNING!!!

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Note: *The manufacturer is not responsible for any Radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.*

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Viatek could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF EXPOSURE STATEMENT

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the product and your body. Use only the supplied antenna.

ORIGINAL PURCHASE PRODUCT WARRANTY

Viatek Consumer Products Group, Inc. ("Viatek") warrants to the original purchaser ("Purchaser") of this Quirky product, for the period of one (1) year following the date on which Purchaser purchases the product, that the product shall be free of defects in design, assembly, material, or workmanship.

Viatek will repair or replace, at its option, any defective product free of charge.

In order to qualify for this warranty, the Purchaser must provide the defective product and a copy of the original receipt of purchase, to Viatek for inspection.

The receipt of purchase must indicate the product purchased, price paid, date of purchase, and name of merchant.

Alternatively, at the Purchaser's election, but subject to Viatek's approval, the Purchaser may obtain replacement parts from Viatek, free of charge. To obtain replacements parts, the Purchaser must provide the product serial number to Viatek in connection with any request for replacement parts.

To request service under this warranty, contact Viatek at 1-888-784-2835 or cs@viatek.com, and a Viatek representative will provide instruction on how to proceed.

This warranty shall be null and void if Viatek determines that the product has been improperly installed, altered or tampered with any way. This warranty does not protect against normal-use wear and tear or damage due to abuse.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF VIATEK. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY. IN NO EVENT SHALL VIATEK BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT OR CONSEQUENTIAL DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY QUIRKY PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some jurisdictions do not allow exclusions or limitations on implied warranties or incidental, consequential or other damages, so the above exclusions and limitations may not apply to you.

COPYRIGHT NOTICE

Copyright 2017 Viatek Consumer Products Group, Incorporated

No part of this manual may be reproduced or modified without written consent from Viatek Consumer Products Group, Inc.

Viatek Consumer Products Group, Inc. is not liable or responsible for any operational, or technical errors or omissions made in this manual.

Viatek Consumer Products Group, Inc. is a licensed distributor of Quirky® Pivot Power® products.

QUIRKY® and PIVOT POWER® are registered trademarks of Q Holdings LLC. Used under license.

Wi-Fi® is a registered trademark of the Wi-Fi Alliance.

HOW TO OBTAIN SERVICE



Need help? We are available.

weekdays: 9AM - 6PM EST

weekends: 12PM - 6PM EST

Email: cs@viatek.com

Call: 1-888-784-2835



- Page 1: The image which appears on the front of the comprehensive manual is no longer representative of what the product will look like; it will NOT have a button on the area where the outlets are.
- Page 2: The three images which appear (on packaging, inset and main image) are no longer representative of what the product will look like; it will NOT have a button on the area where the outlets are.
- #4 in features: it only connects of WiFi of certain speeds; not ALL WiFi
- #6 under "required for use" - change "Quirky App" to Pivot Power Smart App"
- "Connects over Any 5.4 GHz" - isn't it 2.4 GHz?
- Page 3: change all references of "Quirky App" to "Pivot Power Smart App"
- Page 5: change "it's" to "its"
- Page 6 : The image which appears is no longer representative of what the product will look like; it will NOT have a button on the area where the outlets are.