




Your Global Local Net

Website: www.glocalme.com
 Phone Number : +852 8191 2660
 E-mail : support@ucloudlink.com
 Facebook : GlocalMe
 Twitter : @GlocalMeOnline
 WeChat : GlocalMe
 Address : Flat A-8, 9/F delya industrial 7 shekpai tau road tuen mun new territories, HongKong

GlocalMe G1 Quick Start


Product outline



1. Network status indicator
2. Signal strength indicator
3. Ethernet interface
4. Factory reset: Press 5 to 10 seconds to reset
5. Battery indicator
6. Battery check
7. Power off
- Charge mobile phone
- Switch on Wi-Fi Hotspot

Indicator light	Flashing pattern	GlocalMe service status
1 S	●●●●●●●● (Steady Dark)	Powered off
	●●●●●●●● (Flashing White)	Connecting
	●●●●●●●● (Solid White)	Connected
2	●●●●●●●● (Flashing Dark)	Limited speed or Low credit
	●●●●●●●● (Solid White)	Strongest signal
	●●●●●●●● (Breathing light)	Good Signal
Signal Strength	●●●●●●●● (Steady Dark)	No Signal

Product outline



8. Wi-Fi indicator
9. Charging indicator:
Blue: Charging Dark: Full
10. Micro USB connector: Charge G1.
11. USB connector: Charge mobile Phone.

Wi-Fi Indicator light status

Wi-Fi	Red quick flash	Powered on
	Red slow flash	Starting Wi-Fi
	Blue slow flash	Connecting
	Stable blue light	Connected

How to use

1 Download GlocalMe App

- 1 Download GlocalMe App
- 2 Register GlocalMe Account
- 3 Top up
- 4 Activate Device
- 5 Switch on GlocalMe Wi-Fi



Scan to get App for Android & IOS

You can use GlocalMe App to register, top up, buy data package, check data rates, check your traffic history and so on. You can also go to website: www.glocalme.com to download GlocalMe App.

2 Register GlocalMe Account

3 Top Up



You can use GlocalMe App or visit www.glocalme.com to register.



Top up with PayPal, credit card or GlocalMe voucher.

4 Activate Device

5 Switch on GlocalMe Wi-Fi



You can input the IMEI number to activate your device or scan the QR code on the back of G1.



1. Turn the button to Wi-Fi position.
2. Wait until Wi-Fi indicator light is stably blue to connect to the internet.

Connect to GlocalMe Wi-Fi

ETCOM	Wi-Fi	1
GlocalMe_****	Wi-Fi	1
TP-LINK_FC0794	Wi-Fi	1

Select the access point GlocalMe_****
 Wi-Fi password is on the back of GlocalMe G1.

Note:
 Now you are using "Pay As You Go".
 Check the rate of your located country in GlocalMe app or www.glocalme.com.
 For long-term usage, You can buy data package.

LAN to Wi-Fi



1. Connect GlocalMe G1 to internet through ethernet cable.
2. Turn the button to Wi-Fi position.
3. When the Wi-Fi indicator is stably purple, you can connect to GlocalMe Wi-Fi.

Note: This will not cost your credit in your account.

Product specifications

- HSPA/HSDPA/UMTS: 2100/1900/900/850 MHz
- GPRS/EDGE/GSM: 1900/1800/900/850 MHz
- HSPA data service of up to 5.76 Mbps
- HSDPA data service of up to 7.2 Mbps
- Wi-Fi 802.11b/g/n: 150Mbps
- Ethernet port
- Standard USB 2.0 interface
- Standard Micro USB interface
- Battery Capacity: 6000mAh
- Input: DC 5V-1A.
- Output: DC 5V-1A

FAQ

1. How long does it take to make GlocalMe G1 fully charged?
About 8 hours from 0% to 100%.
 2. How long could my GlocalMe G1 keep working?
Over 10 hours. In order to save the battery, when the hotspot is not in use, it is recommended to turn it off.
 3. How can I change Wi-Fi SSID and password?
Connect to GlocalMe Wi-Fi, and access 192.168.169.1, Password: admin.
 4. If I forget the Wi-Fi password I changed, what should I do?
You can reset GlocalMe G1 to recover the factory password (on the back of G1).
 5. If I lost my device, what should I do?
You should login your account, and deactivate your device. You can keep your balance in your account.
 6. How many devices can connect to GlocalMe G1?
Up to 5 Wi-Fi enabled devices.
 7. How to check my data traffic history?
Please login your account to check it in GlocalMe App or www.glocalme.com.
 8. When I use "LAN to Wi-Fi", will it cost my credit in my account?
No, it costs no credit if you use "LAN to Wi-Fi".
 9. How long does G1 take to connect to the internet?
Usually, it takes 1-2 minutes. But it may take up to 10 minutes for the first visit in a country.
 10. What should I do when the G1 cannot be switched on (I'm sure it's still with power)?
Try to charge G1, and restart after five minutes.
- For more information, please log on www.glocalme.com.



1. Do not charge tablets.
2. Do not charge any device when the Wi-Fi is working.
3. Keep away from water.
4. Due to heat dissipation, please do not keep G1 in bag for a long time when using.

Warning

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0 cm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 --Reorient or relocate the receiving antenna.
 --Increase the separation between the equipment and receiver.
 --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 --Consult the dealer or an experienced radio/TV technician for help.