

T-Mobile

P10000066

CJB1L60ALAAA

T-Mobile

Welcome

Start Guide





alcatel 7



TABLE OF CONTENTS

Device Overview	1	EMAIL	21
Service Activation.....	3	Messaging	21
Support	4	Web Browser	23
Account Information	4	Bluetooth®	24
SIM Card	5	Help Protect Your Device	24
Battery.....	6	Accessories	25
Power.....	7	Software updates.....	26
Home Screen.....	8	Firmware Versions.....	26
Applications	10	ADDITIONAL INFORMATION	27
Calls.....	12	Device security.....	28
Voicemail	17	12 MONTH LIMITED WARRANTY	29
CloserTV™	17	Recycling Information.....	29
Accessing Files	18	Safety and Use.....	30
Data Sharing.....	19	Privacy	35
Volume & ringtone.....	20	Safety tips.....	43
Contacts.....	20		

DEVICE OVERVIEW



SERVICE ACTIVATION

If you are a new T-Mobile® customer and your service has not yet been activated, simply call Customer Care at 1-800-937-8997 and a T-Mobile Activation representative will assist you.

You will need the following information when activating service:

- Your name, phone number, home and billing address
- Your Service Agreement and the agent code on your Agreement

Note: For business and government accounts, please provide the organization's name, address, and taxID number.

- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see www.t-mobile.com for latest plan information)
- Your IMEI number are located on the box barcode label

Service or use is your agreement to T-Mobile's Terms and Conditions. T-Mobile requires Arbitration of Disputes unless, for new customers, you opt-out within 30-days, or for existing customers, you previously opted-out. For details, see T-Mobile's Terms and Conditions at www.T-Mobile.com/terms-conditions.

SUPPORT

This guide provides you with information you need to get started.

For more information and additional support, please visit <http://www.t-mobile.com/support> where you can:

- Register at my.t-mobile.com
- Check your usage, pay your bill
- Upgrade your device, and change your rate plan.
- Review your device's User Manual.
- View the latest troubleshooting instructions in the Support Forums or ask a question of your own.

ACCOUNT INFORMATION

Be sure to access your account at My.T-Mobile.com to check your minutes, pay your bill, upgrade your phone, change your rate plan, and contact customer service.

You can also access this account information from your phone from the T-Mobile app.

- Touch  from the Home screen.

SIM CARD

The SIM (Subscriber Identity Module) card identifies your device to the wireless network. You can't make or receive phone calls without a properly installed SIM card unless it's an emergency call (911).

You don't need to power off your device before inserting or removing the SIM card.

Note: Your phone only supports NANO SIM cards. Do not attempt to insert other SIM types like mini and micro cards to avoid damage to your device.

Insert/Remove the NanoSIM and MicroSD Cards

1. Use a SIM pin to open the slot.



2. Insert/Remove the SIM card and MicroSD card.



Note: MicroSD Cards are sold separately

BATTERY

To optimize battery performance, be sure to fully charge your device before using it for the first time.

Charging the device

1. Insert the small end of the charging cable into the charge port as shown.





2. Connect charger to power outlet

Note: Please use the cable that came with your device.
Using other cables may damage the charging port or reduce battery performance.

Optimize Battery Life

To optimize battery life, adjust your screen brightness and display timeout.

1. Adjusting brightness level: Lowering your screen brightness level can optimize your battery level. To adjust the brightness level, from the Home screen, touch  > Settings > Display > Brightness level. To lower the brightness level, move the wheel to the left.
2. Power Saving Mode: Power Saving mode minimizes battery usage to extend battery life. To turn on your Power Saving mode, from the Home screen, touch  > Settings > Battery. Then turn on the Standby intelligent power saving and the Battery saver.

POWER

Power on your device

Hold down the Power key until the device powers on. Unlock your device by using Swipe, PIN, Password or pattern if necessary and the Home screen will be displayed.


If you do not know your PIN code or forget it, contact your network operator.

Power off your device

Hold down the Power key until options appear and select Power off.

HOME SCREEN

You can bring all the items (applications, shortcuts, folders and widgets) you love or use most frequently to your Home screen for quick access. Touch the Home key to get instant access to the Home screen.



Home screen is provided in an extended format to allow more space for adding applications, shortcuts etc. Slide all Home screens horizontally left and right to get a complete view of the Home screens. The white circles at the lower part of the screen indicate which screen you are viewing.

Status Bar

The Status bar appears at the top of your Home screen. You will find icons indicating your device' s status and new notification alerts appear in the Status bar.



Icon	Status
	Bluetooth [®] active
	Wi-Fi active
	Network (full signal)
	Network (roaming)
	4G LTE data service
	3G data service
	Airplane mode
	Alarm set

	Battery (charging)
	Battery (fully charged)
	New message

APPLICATIONS

App List

Press the Application icon  from the idle screen to access the App list.



Add/Remove Application

1. Add: You can touch and hold a folder, an application, or a widget to activate the Move mode and drag the item to any Home screen you prefer.
2. Reposition: Touch and hold the item to be repositioned to activate the Move mode, drag the item to the desired position and then release.

You can move items both on the Home screen and the Favorite tray. Hold the icon on the left or right edge of the screen to drag the item to another Home screen.

3. Remove: Touch and hold the item to be removed to activate the Move mode, drag the item up to the top of the icon, and release after the item turns red.
4. Create folders: To improve the organization of items (shortcuts or applications) on the Home screen, you can create a folder by stacking one app on top of another. To rename a folder, open it and touch the folder's title bar to input the new name.
5. Wallpaper customization:

You can change your wallpaper in two different ways:

1. Touch and hold an empty area on the Home


screen and then select WALLPAPERS from bottom options. Slide left and right to view and select one Wallpaper image options, select Set wallpaper on top left bar and then select Home screen to set image as Home screen. You can set different wallpapers for Lock screen and Home screen.




2. Change your wallpaper by going to Settings > Display > Wallpaper.


CALLS


Placing a call

You can easily place a call using Call from the Home screen.






Enter the desired number from the keyboard directly and touch  to place the call or select a contact from  or  by sliding or touching tabs, then to make the call.

The number you entered can be saved to Contacts by touching Create new contact or Add to a contact. If you make a mistake, you can delete the incorrect digits by touching .

To hang up a call, touch .




When you receive a call:

- Slide up the  or touch ANSWER to answer.
- Slide down the  or touch DISMISS to reject;
- Touch the icon  to reject the call by sending a preset message.

To mute the ringtone volume of an incoming call, press the Volume Up/Down Key.

Note: For your convenience, your phone features a unique Reversible UI functionality that can accept calls even in the upside down position.

International call

To dial an international call, long press to enter "+", then enter the international country prefix followed by the full phone number and touch .

Wi-Fi Calling

Wi-Fi Calling can improve your coverage by allowing you to make phone calls over a Wi-Fi network (when a Wi-Fi network is available).



To use Wi-Fi Calling, please use the SIM card shipped with your device. A different SIM card may not work with the Wi-Fi Calling feature.

Important!



You must also have a 9-1-1 emergency address registered with your account. Log into your account at <http://www.t-mobile.com/>. Go to your profile, click Line Settings and select to edit your E911 Address. Check periodically to ensure your address is always up to date.

- Corporate accounts may require administrator assistance for 9-1-1 Address registration.


To enable/disable Wi-Fi Calling

1. From the home screen, touch  >  Settings > Calls > Wi-Fi calling.
2. Touch Enable Wi-Fi Calling to activate/deactivate the feature.

To change the connection preference for Wi-Fi Calling

1. Touch  >  > Settings > Calls.
2. Touch Wi-Fi Calling > Connection preferences.
3. Touch the desired Wi-Fi Calling preference.

Emergency call

If your phone has network coverage, dial the emergency number and touch  to make an emergency call. This works even without a SIM card and without typing the PIN code.




Although all phones are equipped with 9-1-1 emergency calling, this phone may or may not

permit its location to be approximated during a 9-1-1 call. Be prepared to report your location when dialing 911*.

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped, or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a mobile phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions, and Privacy Policy for additional service restrictions and details.

VOICEMAIL


Set Up Voicemail

1. Press and hold  to call voicemail.
2. From the Home screen, touch  > Visual Voicemail  to set up.

T-Mobile Name ID

T-Mobile Name ID identifies callers, displaying Name, City and State even if the caller is not in your contacts list. It is an optional add-on feature that can be purchased directly from your phone for an additional monthly charge.


A one time 30 day trial is included with the phone.




1. Touch  from the Home screen.
2. Choose an on-screen option.


CLOSER TV™

This function can universally access to both live TV and Over The Top¹ content, fully control both mobile and TV screens, and seamlessly swap between live TV channels and OTT content:

1 OTT: The delivery of film and TV content via the Internet, without requiring users to subscribe to a traditional cable or satellite pay-TV service.

From the home screen, touch  CloserTV™

- Touch  search the video you want to watch.
- Touch  to search content by voice.
- Touch  to control the TV content.

Note: you need to set the Remote control by touching the Set up  following the instructions before using it for the first time.



ACCESSING FILES

To access media files and photos saved on your device or to transfer files from your device' s SD card (sold separately) to your computer, follow these steps:

To connect device to PC

1. Use the USB cable that came with your device to connect the device to a USB port on your computer. You will receive a notification that the USB is connected.
2. If you use MTP or PTP, your phone will be automatically connected. Note: Before using MTP, make sure that the driver (Windows Media Player 11 or higher version) has been installed.

To locate data you have transferred or downloaded in your microSD card/internal storage:

- Touch  to open the applications list.
- Touch Files .

All data you have downloaded is stored in the Files. Here you can view media files (videos, photos, music and others), rename files, install applications into your device, etc.

DATA SHARING

You can share your device' s mobile data connection with a single computer via USB cable (USB tethering) or with up to eight devices at once by turning your device into a portable Wi-Fi hotspot.

To turn on USB tethering or Wi-Fi Hotspot:

1. Touch Settings > Network & Internet > Hotspot & tethering.
2. Touch the switch of USB tethering to activate this function.
3. Touch Wi-Fi Hotspot then touch the switch to activate this function.



Note: These functions may incur additional network charges from your network operator. Extra fees may also be charged in roaming areas.

VOLUME & RINGTONE

Adjust In-call Volume




While on a call, press the Volume Up/Down Key to adjust volume.

Adjust Ringtone and Volume



1. From the Home screen, press Application icon  and select Settings icon  and then select Sound.
2. Position the slider to adjust volume for Media,, Alarm, or Notification separately.
3. Touch Advanced to get more settings.

CONTACTS

Create a New Contact



1. From the Home screen, touch Application icon  and select Contacts icon .
2. Touch  to create a new contact.
3. Enter contact' s name and other contact information.
4. When finished, touch SAVE to Save.

Make a Call from Contact List

1. From the Home screen, touch  Contacts icon.
2. Touch a contact to view details, then touch  to call.

EMAIL





Set Up Email Accounts

- From the Home screen, touch  > Email  icon. An email wizard will guide you through the steps to set up an email account.
- Enter the email address and password of the account you want to set up.
- If the account you entered is not provided by your service provider in the device, you can touch MANUAL SETUP after entering the email address, select an account type and enter password of your email, then correctly fill in server and port in both Incoming server settings and Outgoing server settings interfaces. Finally touch FINISH to complete setup.

MESSAGING

Use the messaging feature to send and receive text (SMS) and multimedia (MMS) messages.

Create and Send a Message

1. From the Home screen, touch  > Messaging icon  to enter.
2. Touch  to write text messages.
3. Enter the phone number of the recipient in the bar at the top of the page or touch  to add recipients.
4. Press the Type message bar to enter the text of the message.

5. Press the icon  to send text messages.




An SMS message of more than 160 characters will be charged as several SMS. A counter will be on the right of the text box to remind you how many characters are allowed to be entered in one message.

Note: Specific letters (accented) will also increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

Send a Multimedia Message

MMS enables you to send video clips, images, animations, slides and sounds to other compatible mobiles and e-mail addresses.


An SMS will be converted to MMS automatically when media files (image, video, audio, etc.) are attached or subject or email addresses are added.

To send a multimedia message, enter the recipient's phone number in the To bar and touch the Type message bar to enter the text of the message. Touch the icon  to attach a picture, video, audio and so on.

When finished, touch  to send the multimedia message.

Note: Data must be turned on to successfully send MMS messages.

WEB BROWSER

From the Home screen, touch  > Chrome  .
A web browser with which you can surf the Internet.



Your bookmarks, browsing history, and settings across all devices with the browser installed can be synchronised with your Google account.



BLUETOOTH®


Your device comes with Bluetooth connectivity, a wireless technology that enables a data connection between your device and a Bluetooth headset or other Bluetooth device (sold separately).

Connect to Bluetooth

1. From the Home screen, touch icon  > Settings icon  > Connected devices.
2. Touch the switch of Bluetooth to activate this function.
4. The device will automatically search for device.
5. Select the desired Bluetooth device to pair with your device.

HELP PROTECT YOUR DEVICE

To help prevent others from using your device without your permission, activate the following security options:

From the Home screen, touch  Settings > Security & location > Device security

1. Screen lock

- None: Touch to disable screen unlock security.
- Swipe: Touch to enable slide unlock mode.
- Pattern: Touch to draw a pattern to unlock screen.
- PIN: Touch to setup a numeric PIN to unlock screen.


- Password: Touch to setup a password to unlock screen.

2. Fingerprint:

- Touch and follow the instruction to set up fingerprint scanner to unlock your device.
- Use this function you need to turn the switch on, go to Settings > Security & location > Screen lock
- Turn the Fingerprint switch on.

Face recognition

You can use Face recognition to unlock your device.

From the Home screen, touch  > Settings > Face recognition and following the instruction to set up face recognition.

When you select turn on the face recognition later, you can go back to Face recognition again to turn it on.

ACCESSORIES


Whether you want a charger, or a fashionable headphone, T-Mobile is the shop for all your phone accessories.

To purchase accessories for your phone, please visit T-Mobile.com, call 1.800.204.2449, or visit your nearest T-Mobile store.

Accessories selection subject to change and may vary by location.

SOFTWARE UPDATES

To access Software Updates, follow these steps:

1. Connect your device to a Wi-Fi network and make sure it has a strong data connection
2. Ensure your battery is fully charged before starting the software update. Your device's current battery level can be found on your device under Settings > Battery
3. Touch the Application icon  from the Home screen then select Settings > System > About phone > System updates
4. Touch Check for update and the device will search for the latest software
5. If software update is available, click on Download update. Once the software is downloaded, touch Install update > Install
6. Now your device has the latest version of the software

FIRMWARE VERSIONS

This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device, it will not function.

T-Mobile's legal disclaimers need to follow this page and here is the language to be included:

ADDITIONAL INFORMATION

Use of some content or features may require qualifying service, or access to a Wi-Fi connection.

Smartphone Mobile HotSpot: Qualifying service required. Plan data allotment applies. Roaming and on-network data allotments differ; see your selected service for details. Use of connected devices subject to T-Mobile Terms and Conditions.

Wi-Fi: Device will not transition between Wi-Fi and the cellular network. Devices using wireless connections may be vulnerable to unauthorized attempts to access data and software stored on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices subject to T-Mobile's Terms and Conditions.

Wi-Fi Calling: Wi-Fi connection required; may decrement plan minutes. Most devices will not transition between Wi-Fi and the cellular network. See your selected service for details.

Devices and screen images are simulated. Coverage not available in some areas. See Terms and Conditions (including arbitration provision) at T-Mobile.com, for rate plan information, charges for

features and services, and restrictions and details, including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling.

T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. The Visual Voicemail icon is a trademark of T-Mobile USA, Inc.

DEVICE SECURITY

T-Mobile encourages customers to take appropriate measures to secure their devices and invites them to take advantage of the features available on this device to help secure it from theft and/or other unauthorized access and use. This device has a locking function (e.g., Security PINs) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts. For additional information, visit: <http://www.tmobile.com/devicesecurity> and <http://www.t-mobile.com/Company/PrivacyResources.aspx>.

12 MONTH LIMITED WARRANTY

For Warranty information and support, please visit <https://us.alcatelmobile.com/warranty/>. You can also call Alcatel [US] Customer Support at 1-855-368-0829 to request a hard copy of the warranty.

RECYCLING INFORMATION

For more information on Electronic Recycling:

- 1) Visit Alcatel Electronic Recycling Program website at <https://us.alcatelmobile.com/accessibility-compliance/electronic-recycling-program/>, or
- 2) Call Alcatel US Customer Support at 1-855-368-0829.

Battery Recycling (USA & Canada):

Alcatel partners with Call2Recycle® to offer a safe and convenient battery recycling program. For more information on our Battery Recycling Program, please visit the USA and Canada website at <https://us.alcatelmobile.com/accessibility-compliance/battery-recycling/> and <https://ca.alcatelmobile.com/accessibility-compliance/battery-recycling/>.



SAFETY AND USE

We recommend that you read this chapter carefully before using your mobile device. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein. Devices using wireless connections may be vulnerable to unauthorized

attempts to access data on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices subject to T-Mobile's Terms and Conditions.

Traffic Safety

Given that studies show that using a mobile device while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile device when the vehicle is not parked. Check the laws and regulations on the use of wireless mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

When driving, do not use your mobile device and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your mobile device emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- Do not place your mobile device on top of the dashboard or within an airbag deployment area,
- Check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from mobile device RF energy.

Conditions of Use

You are advised to switch off the mobile device from time to time to optimize its performance.

Remember to abide by local authority rules of mobile device use on aircrafts.

Operational Warnings: Obey all posted signs when using mobile devices in public areas.

- Turn off your mobile device in any location where posted notices instruct you to do so. In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.
- Switch the mobile device off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile devices can interfere with other electrical or electronic devices, or equipment using radio frequency.
- Switch the mobile device off when you are near

gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere.

- When the mobile device is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker or insulin pump. In particular when using the mobile device you should hold it against the ear on the opposite side to the device, if any.

Note: Using your device in landscape mode with polarized sunglasses on may cut light from the screen. Take your polarized sunglasses off or use your device in portrait orientation to continue use.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your healthcare provider.

It is recommended to have proper supervision while small children use your mobile device.

Do not attempt to disassemble your phone. If you disassemble your phone, the warranty will not apply.

Always handle your mobile device with care and keep it in a clean and dust-free place.

Do not allow your mobile device to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer's recommended

operating temperature range is 0°C (32°F) to +50°C (122°F)

Note: The max value depends on the device condition, materials around it and the housing paint and texture.

Over 50°C (122°F) the legibility of the mobile device's display may be impaired, though this is temporary and not serious.

Do not open or attempt to paint or repair your mobile device.

Do not drop, throw or try to bend your mobile device.

Do not use the mobile device if the screen is damaged, cracked or broken to avoid any injury.

Use only batteries, battery chargers, and accessories which are recommended by TCL Communications Ltd. and its affiliates and are compatible with your mobile device model. TCL Communications Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Your mobile device should not be disposed in municipal waste. Please check local regulations for disposal of electronic products.

Remember to make back-up copies or keep a written record of all important information stored in your mobile device.

Some people may suffer epileptic seizures or

blackouts when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your mobile device. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the mobile devices. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Play at the farthest distance possible from the screen.

When you play games on your mobile device, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems, such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders:

- Take a minimum of a 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

PRIVACY

Please note that you must respect the laws and regulations of your jurisdiction or other jurisdiction(s) where you will use your mobile device regarding taking photographs and recording sounds with your mobile device. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy.

It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your mobile device (including the operator) disclaim any liability which may result from the improper use of the mobile device.

Battery and Accessories

Following air regulation, if the battery of your product is not charged, please charge first.

Before removing the battery from your device, make sure that the device is switched off.

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C.
- Do not disassemble or open crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard

Products that have the below symbol must be taken to collection points at the end of their life:



- Municipal waste disposal centers with specific bins for these items of equipment.
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

In non-European Union jurisdictions:

Items of equipment with this symbol are not be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at <http://www.recyclewirelessphones.com>

CAUTION: IF BATTERY IS REPLACED BY AN INCORRECT TYPE, DEVICE MIGHT EXPLODE. DISPOSE USED BATTERIES ACCORDING TO THE INSTRUCTION.

Chargers

Home A.C./ Travel chargers will operate within the temperature range of: **0°C (32°F) to 45°C (113°F)**.

The chargers designed for your mobile device meet with the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

The charger shall be installed near the device and shall be easily accessible.

Travel charger: **100-240V, 50/60Hz, 0.6A**

Output: **5V, 2A/9V, 1.67A**

Radio Waves

THIS MOBILE DEVICE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your mobile device is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Industry Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the mobile device transmitting at its highest certified power level in all tested frequency bands.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF

exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of HYPERLINK "<http://www.fcc.gov/oet/ea/fccid>" www.fcc.gov/oet/ea/fccid after searching on **FCC ID:2ACCJBT09**.

Although the SAR is determined at the highest certified power level, the actual SAR level of the mobile device while operating can be well below the maximum value. This is because the mobile device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the mobile device. Before a mobile device model is available for sale to the public, compliance with national regulations and standards must be shown. The highest SAR value for this model mobile phone when tested is 1.03 W/Kg for use at the ear and **1.18 W/Kg** for use close to the body.

While there may be differences between the SAR levels of various mobile devices and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the device has been tested when positioned a minimum of **10 mm** from the body without any metal parts in the vicinity of the device or when properly used with an appropriate accessory and worn on the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Additional

information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site: <http://www.phonefacts.net>

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of mobile devices. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile devices away from the head and body. (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

For other devices, they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Your mobile device is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it. As mobile devices offer a range of functions, they can be used in positions

other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the mobile device at least **10 mm** away from the body.

Licenses



MicroSD Logo is a trademark.



The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communications Ltd. and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

Alcatel 6062W

Bluetooth® Declaration ID D037883



The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

The 5150-5350 MHz band is restricted to indoor use only for the following countries:

BE	BG	CZ	DK	DE	EE	IE
LT	LU	HU	MT	NL	AT	PL
EL	ES	FR	H	IT	CY	LV
PT	R	SI	SK	FI	SE	U
N	IS	LI	C	T		

You have purchased a product which uses the open source (<http://opensource.org/>) programs mtd, msdosfs, netfilter/iptables and initrd in object code and other open source programs licensed under the GNU General Public License and Apache License. We will provide you with a complete copy of the corresponding source codes upon request within a period of three years from the distribution of the product by TCL Communications Ltd. You may download the source codes from <http://sourceforge.net/projects/alcatel/files/>. The provision of the source code is free of charge from Internet.

SAFETY TIPS

Consider Device Compatibility

If you have a pacemaker, check with your doctor to make sure it's safe for you to use a phone. In some cases, cellular radio frequencies can disrupt the performance of other electronic equipment. If you have questions about the interaction between your phone and any other piece of electronic equipment, ask the equipment manufacturer.