

Smart LED Bulb

INTRODUCTION

Technical parameters

Power	RGB: <7.5W
Lumen	CW: 500-550 LM
Voltage	AC 100V~AC264V
Color Temperature	WW: 2700K~3200K CW: 6000K~6500K

How to use

It is very easy to use the smart bulb.

1. Search "Gtlighting" in App Store, download and install for ISO; Scan our QR code to visit our web, then download and install "COLORFUL LIGHT Bluetooth" for Android;
2. Power on your bulb.
3. Then turn on the bluetooth function on your phone.
4. Open the app and it connects automatically. You can even control multiple bulbs at the same time or turn your bulbs on and off if your outlet is located at an inaccessible place and many other things.
5. This is our company's QRcode for Android:



Notice: Connects to device with bluetooth 4.0 and above

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body