


# Users Manual



## Specifications:

Bluetooth / Name	V5.0 / 18796
Speaker Spec.	52x 52mm, 40hm, 3W
Frequency Response	50Hz—20KHz
Transmission Range	Max 10 meter
Frequency	2.402GHz—2.48GHz
Input power	Input DC5V 1A

## Operation Description:

1. The power switch, in bluetooth mode, paired automatically when select bluetooth name “18796”.
2. The USB interface
3. Insert interface TF card
4. The charge Mirco USB interface, in radio mode, insert data line.
5. Press short last song/long press to reduce volume.
6. Mode: switch between BT/TF card/FM/Aux-in
7. Short Press: Pause/Play/Answer the phone; long press: hang up / after matching, recall the last number to call/auto search and save FM radio
8. Press short next song / long press to increase the volume.

## FCC Part 15 C Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.