




Stealth Reader MIU Users Guide



Copyright 2020 Zenner USA
Rev 18



NOTICES.....	3
Patents	3
Copying	3
FCC/IC Compliance.....	3
Introduction.....	5
Quick Tour	5
Pre-Installation.....	5
Supplies/Equipment	5
Installation.....	5
Considerations.....	5
Procedure	6
Connecting to the Register.....	6
Connection Techniques	10
Splicing Techniques	10
Mounting.....	11
Pit Mounting	11
Proper/ Improper Pit Mounting.....	11
Configuration	12
LED Behavior	13
Shipping and Handling.....	14
Specifications.....	14

NOTICES

Patents

This product contains Stealth Reader Technologies that are licensed by the manufacturer and are protected by US Patents including: 7782804, 7996534, 8126488, 8351409, 8428558, 8428630. The furnishing of this document and/or purchasing of the associated products does not give you any license to or ownership of such patents.

Copying

No part of this manual or associated hardware or software products may be reproduced in any form or by any means including, without limitation, electronic or mechanical such as photocopying or recording, or by any information storage and retrieval systems without the express written consent of Zenner USA. Specifications are subject to change without notice.

FCC/IC Compliance

FCC ID: 2ACOA-WM2E

FCC ID: 2ACOA-WM2F

FCC ID: 2ACOA-WM3

IC ID: 26631-WM3

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- This device may not cause interference; and
- This device must accept any interference, including interference that may cause undesired operation of the device."

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- l'appareil ne doit pas produire de brouillage, et
- l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Attention: les changements ou modifications non expressément approuvés par le fabricant peuvent annuler le droit de l'utilisateur à utiliser l'équipement.

To comply with FCC/IC RF exposure requirements, the device and the antenna for this device must be installed to ensure a minimum separation distance of 20 cm or more from a person's body. Other operating configurations should be avoided.

Pour se conformer aux exigences d'exposition RF FCC/IC, l'antenne utilisée pour cette radio doit être correctement installée et entretenue. Elle doit respecter une distance minimum de 20 cm de l'utilisateur et ne doit pas être installée à proximité ou utilisée conjointement avec tout autre antenne ou émetteur. N'utilisez pas votre radio si vous ne respectez pas la distance spécifiée.

Introduction

Stealth Reader networks are used for remote monitoring of commercial, industrial, and municipal equipment such as automatic utility metering. Hundreds of thousands of devices are currently being monitored by Stealth Reader networks.

The Stealth Reader MIU is the next-generation of MeshPlus water MIUs. The Stealth Reader extends the feature set of the MeshPlus WM1 and is fully compatible with MeshPlus WM1 products. The Stealth Reader offers WM1 backward compatibility with extended wireless range and extended battery life. The Stealth Reader is based on the proven WM1 design with over 500,000 MIUs deployed; added features include increased reliability, and improved wireless performance.

Quick Tour

The Stealth Reader is powered by two replaceable lithium-thionyl chloride (LiSOCl₂) batteries. The Stealth Reader electronics are permanently encased in a urethane potting compound to protect them from water and chemicals. The end cap is secured by a single screw to secure the batteries, electronics and cabling. The Stealth Reader interface cable includes 8 colored wires for connecting to a wide variety of water meter registers. Stealth Readers can also be ordered with a 3-wire Nicor cable for encoders wired with Nicor cables. The Stealth Reader enclosure supports mounting in a variety of environments including pole, wall, and pit mounts.

Pre-Installation

Supplies/Equipment

In order to install the Stealth Reader properly the following Equipment is needed:

- The Stealth Reader
- Wire-end Connectors
- Lid Lock (for pit mounting) or Wall/Pole mount
- Stealth Handheld

In order to install the Stealth Reader and prevent water damage these materials are needed:

- UY Gel Cap Connectors
- 3M E9-Y Crimping tool
- Burial Pod (pit installs, not necessary for indoor installs)

Installation

This section covers the installation of the Stealth Reader and the mounting process.

Considerations

1. Signal distance depends on the location of the Stealth Reader's antenna. When the Stealth Reader's antenna is higher the signal is generally stronger. The use of a Riser plate will increase the height.
2. Different materials used for the Pit Lid or Vault will affect the transmission range. A plastic lid allows a longer range compared to a cast iron lid.
3. The installation usually takes 10 minutes if the meter pit lid can accept the Lid Lock Assembly, but it will depend on the location and mounting. Make sure there is enough space between the box lid and the ground for the Stealth Reader to fit. If there isn't enough space for the Stealth Reader to fit properly, remove some dirt from the area. Do not over-tighten lid locks!

Procedure

Connecting to the Register

The Stealth Reader is wired directly to the meter. The following table matches the type of Register and the wires that need to be connected for each type. Follow the instructions in the Connection Techniques Section at the end of the chart. If the wiring is not per the chart, the Stealth Reader will not work properly with the meter. Some Registers will have screw terminals. The screws will be labeled with either the word or the starting letter of the colors, for example “R, G, B, etc.”.

Stealth Reader MIU to Register Wiring

Brand	Model	Register Type	SR Wires	Register Wires
Zenner	ETR / ETRU	Encoded	Red	Red
			Green	Green
			Black	Black
ABB/Kent	Scancoder	Encoded Type 2	Red	Green
			Green	Red
			Black	Black
Hersey	Translator	Encoded Type 16	Red	Red
			Green	Green/White
			Black	Black
Master Meter	Dialog	Encoded	Red	Green
			Green	Green
			Black	Red
Metron	ProLink	Encoded	Brown	Red
			White	Green
			Black	Black
Neptune	T-8	Encoded	Red	1 Post
			Green	2 Post
			Black	3 Post

Brand	Model	Register Type	SR Wires	Register Wires
Neptune	AUTO	Encoded Type 15	Red	Black
			Green	Red
			Black	Green
Rockwell	ECR 3 Wire	Encoded	Red	Red
			Green	Green
			Black	Black
Rockwell	ECR 2 Wire	Encoded	Red	Red
			Green	Red
			Black	Black
Rockwell	Touchread 3 Wire	Encoded Type 1	Red	Red
			Green	Green
			Black	Black
Rockwell	Touchread 2 Wire	Encoded	Red	Red
			Green	Green
			Black	Black
Schlumberger	ARB V	Encoded Type 9 (4 digits), 10 (5 digits), and 11 (6 digits)	Red	Black
			Green	Red
			Black	Green
Schlumberger	ARB VI	Encoded Type 15	Red	Black
			Green	Red
			Black	Green
Schlumberger	AUTO	Encoded Type 15	Red	Black
			Green	Red
			Black	Green
Sensus	SR II 3 Wire	Encoded	Red	Red
			Green	Green
			Black	Black

Brand	Model	Register Type	SR Wires	Register Wires
Sensus	SR II	Encoded	Red	Red
	2 Wire		Green	Red
Invensys	AMR System	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Neptune	E-coder	Encoded	Red	Black
		Type 13 or 15	Green	Red
			Black	Green
Badger	ADE	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Metron	Spectrum 22	Encoded	Red	Red
			Green	Green
			Black	Black
AMCO	InVision	Encoded	Red	Green
		Type 3, 14, or 17	Green	Red
			Black	Black
Invensys/Sensus	ICE	Encoded	Red	Red
		Type 3 or 17	Green	Green
			Black	Black
Actaris	Cyble Coder	Encoded	Red	Red
		Type 3 or 17	Green	Green
			Black	Black

Brand	Model	Register Type	SR Wires	Register Wires
Master Meter	BL	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Master Meter	Octave	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Metron	Hawkeye OER	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Sensus	IPERL	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Elster	EVO Q4	Encoded	Red	White
		Type 3	Green	Red
			Black	Black
Hersey	MVR 650	Encoded	Red	Red
			Green	White
			Black	Green
Hendey	HPM ETR	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black
Master Meter	AccuLinx	Encoded	Red	Red
		Type 3	Green	Green
			Black	Black

Connection Techniques

When connecting the Stealth Reader to the Register please use the following procedure:

1. Check the chart above for the proper wiring for the brand and model of register.
2. Connect the wires using UY gel cap connectors. If the wires are stripped, cut off the stripped ends. Wires must have un-stripped ends in order to use the gel cap connectors. Use the Gel Cap Crimping tool to secure the gel cap connectors.
3. The connections for encoded registers will be tested during Stealth Reader installation, however pulse register connections cannot be tested so it is important to be sure the wires are connected correctly before inserting in the burial pods.

If the wires are installed incorrectly and need to be repaired, use the following steps:

1. Cut off the wires where they enter the UY gel caps.
2. Repeat procedures 2-3 from the section above.

There are some registers that use screw terminals instead of wires; each screw terminal has a letter next to it indicating the equivalent wire color it represents. Use the model and brand of register to find the proper wiring in the chart above then follow these installation steps:

1. Examine the wiring chart above to identify the proper wire to screw-terminal connections.
2. Wrap the correct wire around the screw terminal clockwise.
3. Tighten the screw while also making sure the wire stays in place. In doing this if the wires are wrapped around the correct way, it will tighten itself when the screw is being tightened.
4. Repeat steps 2 and 3 for each screw terminal

Splicing Techniques

This method ensures wire connections are completely water proof.

Water Pit Splice Method using burial pods

- Make sure that the gel caps are completely in the grease.
- Seal the burial pod

Water Pit Splice Method for Direct Register Connections

- Strip the outer cable shield back 4 inches.
- Strip the insulation from the used wires $\frac{3}{4}$ of an inch.
- Cut off excess wire and direct connect to the water register according to the wire connections chart per register type.



Figure 1 - A correct wire splicing using UY gel cap connectors.



Figure 2 - A correct insertion of the splice in the burial pod.

Mounting

The Stealth Reader supports several mounting options including pit, wall, and pole mounting.

Pit Mounting

1. Gather the mounting materials as shown in the picture below.



1= Screw Top,

2=Nut,

3=Riser,

4=Stealth Reader

2. If the Riser (3) is used, place the Screw Top (1) through the Riser from the indented side of the Riser. Place the Screw Top through the hole in the pit lid. If there is no Riser, place the Screw Top directly through the hole in the pit lid. The threaded portion of the Screw Top should be pointing down (into the pit).
3. Use the Nut (2) to secure the Screw top onto the Pit Lid. Tighten the Nut until it can't be tightened further, but do **not** over-tighten it.
4. Install the Stealth Reader top (opposite the wire) and place it Screw top. Turn the Stealth Reader until a click is heard, the click indicates that the Stealth Reader is locked into the Screw Top.
5. Carefully cover the pit with the pit lid (that now has the Stealth Reader attached) and make sure the lid closes completely without putting weight on the Stealth Reader. **Never** let the weight of the Lid be supported by the Stealth Reader or the Stealth Reader or wiring can be damaged.
6. Pick up all trash in and around the pit.
7. Secure the Lid.

Proper/ Improper Pit Mounting

With Pit Mounting, the Stealth Reader should be upright and the lid should be able to close and seal securely. The picture to the right shows an **INCORRECT** installation of a Stealth Reader. The Reader is sitting too high and the lid can't close properly. To fix this problem remove dirt from beneath the reader until the lid can close properly without putting any weight on the Stealth Reader. If a Stealth Reader has been improperly installed, it should be checked for damage and proper operation before being returned to service; if the case, mounting hardware, or wiring is damaged, the Stealth Reader should be replaced.





Configuration

Stealth Reader installations are performed using a Stealth Handheld. The Stealth Handheld guides installers through the installation process, records the details of each installation, and tests and configures installed Stealth Readers.

Stealth Handheld may be used as stand-alone tools allowing Stealth Readers to be installed as needed (e.g. for demonstration purposes or to serve as repeaters). Stealth Handhelds are also fully integrated with the Stealth Reader Web workorder management system allowing installations to be planned and assigned to installers or install teams.

Whether performing as-needed installations or work-order assigned installations, the process is similar and is described in the SR Handheld Users Guide.

LED Behavior

When the Stealth Reader is activated, two LED indicators provide visual status information. With a few exceptions, the Red LED generally provides status information regarding the connection between the Stealth Reader and the water register; the Green LED provides status information regarding the communication link between the Stealth Reader and the Fixed Wireless Network.

The following chart identifies the status information a Stealth Reader may provide:

Red Light	Green Light	Status	Action
Fast Blink	Off	No application firmware installed	Return for service
Off	Fast Blink	Date and Time not set	Proceed with installation, check Stealth Reader battery and alarm status at end of installation.
Slow Blink	Active	No register detected	Check register wiring/connections
Fast Blink	Active	<ul style="list-style-type: none"> • Encoded register: error reading register • Pulse register: fewer than 5 pulses received 	<ul style="list-style-type: none"> • Encoder: check wiring/connections • Pulse: may be OK, if possible advance register to generate several pulses
On	Active	<ul style="list-style-type: none"> • Encoded register: read OK • Pulse register received 5 or more pulses 	See below for actions based on Green LED
Active	Slow Blink	Searching for fixed network	May be OK, but if persists may require installation of a repeater or additional Stealth Readers nearby. Neighbor swiping is recommended.
Active	Fast Blink	Found fixed network, waiting to register/re-register.	May be OK, if persists may require installation of a repeater or additional Stealth Readers nearby. Neighbor swiping is recommended.
Active	On	Fixed network found and successfully registered.	See above for actions based on Red LED
On	On	Fixed network found and successfully registered Water register found and connected	No action, install successful!
Note: Active above means slow blink, fast blink, or steady on, just not off.			
On	Off	Status for one second indicates detected magnet activation	No action

Shipping and Handling

Stealth Readers contain Lithium batteries which are hazardous and have transportation restrictions. Check with your carrier before shipping.

Specifications

Environment:

- Do not exceed the temperature range of -40C to +85C.

Battery: 2 Wuhan Voltec ER34615-TW2 LiSOCl₂ Batteries

Battery Life: 10+ years