

® RadioShack®

6001432
USER'S GUIDE

AGE 12+



DOMINATOR 2.0

BLADE GUARD DRONE



Contents

Features	3
Package Contents	3
Specifications	3
Fly Safely	3
Charge the Drone	4
Lithium Battery Notes	4
Install Batteries in the Remote Control.....	4
Battery Notes	5
About Expert/ Easy Modes (Ex/Ez)	5
Pairing.....	5
Remote Control Overview.....	6
Fly Your Drone	8
Trim Your Drone.....	8
Land Your Drone.....	8
Perform Stunts	8
Replace Damaged Propellers	9
Troubleshooting.....	9
Drone does not respond.....	9
Drone difficult to control.....	9
Drone swerves or moves erratically before taking off.....	10
FCC Information	10
Limited Warranty.....	10

CHOKING HAZARD! Small parts. Not for children under 3 years.

We hope you enjoy your Dominator 2.0 Blade Guard Drone from RadioShack. Congratulations! No FAA Registration is required for this drone. Please read this user's guide before setting up and using your drone.

Features

- 6-axis super stabilizing control system
- 360° flip stunt mode
- Easy (**Ez**) and Expert (**Ex**) play modes
- Detachable blade guards to create two looks



**Blade guards
detached**

Package Contents

- Drone with detachable propeller guards
- Remote Control
- Spare Propellers with screw (4)
- USB Charging Cable
- User's Guide

Specifications

Power

Drone.....built-in 3.7V, 390mAh lithium polymer battery

Remote Control..... 4 × AAA batteries

Control Distance 100 ft. (30m)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.


Fly Safely

- Do not fly the drone near or at other people or animals.
- Do not fly your drone where emergency responders are working, or emergency aircraft are operating.
- When flying outdoors, keep the drone away from power lines, trees, weeds, and water.
- Do not fly your drone over private property where you are not welcomed.
- When flying indoors, keep the drone away from walls, air conditioning, air vents, fans, breakable objects, and other obstacles.
- Keep eyes, hands, hair, and loose clothing away from moving propellers.
- Adult supervision is recommended at all times.

RoHS Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.

Charge the Drone

1. Make sure the drone is turned off.
2. Connect the included USB charging cable to the drone's **CHG** jack and a USB power source. The USB connector LED lights red during charging, and turns off when charging is complete.



A full charge takes about 55-60 minutes, and provides up to 5 minutes of flight time.

3. After charging, unplug the charging cable.

CAUTION

- Use only the included USB charging cable to charge the drone's battery. Other cables may damage the drone.
- Always let the drone battery cool before recharging.


Lithium Battery Notes

Your drone uses a built-in lithium polymer battery for power. Follow the instructions for charging.

- **Do not charge longer than recommended. Unplug the charging cable when the drone is charged.**
- Do not puncture or crush. Do not disassemble.
- Do not dispose of lithium batteries in the trash.
- If the electrolyte in the cells should get on your skin, thoroughly wash with soap and water. If in the eyes, rinse thoroughly with cool water. Immediately seek medical attention.
- Do not attempt to charge or operate damaged toys.

Install Batteries in the Remote Control

1. Make sure the remote control is turned off.
2. Use a screwdriver to open the twin battery compartments. Then insert four AAA batteries (not included), matching the polarities (+ and -) marked inside. Replace the cover.



Note: If the remote control's LED flashes during use, the batteries are low and should be replaced.

Battery Notes

- Dispose of old batteries promptly and properly. Do not burn or bury them. Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- Remove batteries during longer storage periods. Batteries can leak chemicals that can damage electronic parts.

About Expert/ Easy Fly Modes (Ex/Ez)

This drone is designed with 2 play modes:

Ex (Expert) for advanced pilots to fly at a higher speed and perform stunts.



Ez (Easy) for beginners and new drone owners. This operates at a slower speed to help you focus on basic navigation and develop a feel of the throttle's sensitivity. By default, in Ez mode, the stunt and speed options are disabled to prevent them from being accidentally activated.


- When pairing and flying for the first time, we recommend you use **Ez** for test flights and honing your takeoff, steering and landing skills.

Pairing

1. Turn on the drone. The drone's LEDs flash.
2. Place the drone on level ground.
3. Turn on the remote control to **Ez** or **Ex**. The remote control's LED flashes.
4. Move the throttle all the way up and then down to pair the remote control with the drone. The drone's propellers remain still during pairing. When paired, the LEDs on both the remote control and drone light steadily.

Note: If pairing fails, turn off the drone and remote control and repeat the steps above, or change locations to avoid electrical interference.


Remote Control Overview



Left ◀ / Right ▶ Slide
Trim



Steering



Ex/ OFF/ Ez
Expert/ Off/ Easy mode

Fly Your Drone

1. After pairing, with the drone on the ground, move the throttle forward to ascend. To avoid ground air turbulence, fly the drone at least 1 ft. (30cm) off the ground.

For advanced users: Hold the remote control with one hand, resting your thumb on the throttle. Throw the drone about 9 ft. (3m) away from you, and move the throttle forward to fly. The drone adjusts itself automatically and flies smoothly.

2. For speed options, pair and fly in **Ex** mode. Push the steering control in to switch between high speed (double beep) and low speed (single beep).

IMPORTANT: If your drone crashes upside down, pull the throttle all the way down. Wait till the propellers have stopped still before you handle the drone.

Trim Your Drone

Move the throttle forward and see how the drone reacts.



Reverse/ Forward Movement Trim: If the drone tends to move forward, press ◀; if it tends to move backward, press ▶.



Left/Right Slide Trim: If the drone tends to slide right, press ◀; if it tends to slide left, press ▶.

Note: The remote control beeps when you press a trim control, but stops beeping when you reach maximum trim adjustment.

Land Your Drone

1. Slowly move the throttle backward to descend. Avoid moving the throttle too quickly, as it can stop the propellers instantly and cause the drone to crash.
2. When you finish playing, turn off the remote control and drone.


Perform Stunts

CAUTION: Make sure there is enough space for the drone to perform stunts without crashing into objects or people.

1. In **Ex** mode, push the throttle control to activate stunt mode. The remote control beeps repeatedly.
2. Use the steering control to perform stunts:
 - **Front flip:** Move steering forward
 - **Back flip:** Move steering backward
 - **Barrel roll:** Move steering right or left
3. The drone automatically exits stunt mode after performing a stunt, or push in the throttle control again to exit immediately.

Replace Damaged Propellers

The left and right propellers of the drone are different, and marked **A/B** on the propeller. You must use the correct propeller in the correct location, otherwise the drone will fail to take off.



To replace a damaged propeller, use a screwdriver to remove the old propeller. Insert a new matching propeller onto the propeller axle, then screw securely, but do not overtighten as the propeller then won't turn.

WARNING:

- To avoid injury and damage, check the propellers for nicks and breaks and make sure they are securely attached before and after each flight. Replace any damaged propellers.
- Use only the supplied propellers. Do not alter, modify, or customize the propellers.

Troubleshooting

Drone does not respond

- Make sure the drone and remote control are switched on and paired.
- Drone battery maybe low. Fully charge the battery. See **"Charge the Drone."**
- Remote control batteries maybe low. Replace the batteries.
- Make sure the drone is within the control range (100 ft./30 m) and in line of sight.

Drone difficult to control

- The throttle control is very sensitive. Use small, fine movements to control.
- Practice in **Ez** (Easy) mode.
- Propellers maybe deformed or damaged. Adjust propellers by hand. If you cannot adjust them, replace with the spare propellers.

Drone swerves or moves erratically before taking off

- The gyroscope inside your drone needs calibrating: Do the following:
 1. With your drone and remote control switched on and paired, place the drone on level ground.
 2. Move the throttle all the way down.
 3. Move the steering forward and hold this position for a few seconds until the drone LEDs start to blink.
 4. Release the steering. The drone LEDs light steadily, indicating successful calibration. You are now ready for takeoff.
- See **"Trim Your Drone"** to fine tune hovering and movement to further improve control of your drone after calibration.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

Go to www.radioshack.com/help for details.

RadioShack Customer Relations

300 RadioShack Circle, Fort Worth, TX 76102

www.radioshack.com



© 2016 General Wireless Operations Inc.
All rights reserved. RadioShack is a registered trademark
used by General Wireless Operations Inc. dba RadioShack

Printed
in China

06A16
6001432