



Model: 66097

DRONE FIGHTER

Age 12+ **Infrared RC Battle Drone**

Features

- Infrared Combat Mode
- Six-Axis Gyro
- Auto-hovering feature
- USB charging

Package Contents

- Drone (2) • Remote Control (2)
- USB Charging Cable (2) • Spare Propellers (4)
- User's Guide • Screwdriver

Specifications

- Power: 3.7V lithium polymer battery
- Drone: 4 × AAA batteries
- Remote Control: 4 × AAA batteries
- Control Distance: 130ft. (40m)


Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

Fly Safely

- When flying outdoors, keep the drone away from power lines, trees, water, and other obstacles.
- When flying indoors, keep the drone away from walls, air conditioning, air vents, fans, breakable objects, and other obstacles.
- Do not fly the drone near or at other people or animals.
- Keep eyes, hands, hair, and loose clothing away from moving propellers.
- Adult supervision is recommended at all times.

Charge the Drone

1. Set the drone's ON/OFF switch to OFF.



2. Connect the included USB charging cable to the drone's CHG jack and a USB power source. The USB connector LED lights red during charging, and turns off when charging is complete. A full charge takes about 50 minutes, and gives you up to 5 minutes flight time.

3. After charging, unplug the charging cable.

CAUTION

- Only use the included USB charging cable to charge the drone's battery. Other cables may damage the drone.
- Always let the drone battery cool before recharging.



Perform Stunts

CAUTION: Make sure there is enough space for the drone to perform stunts without crashing into objects or people.

1. Push the throttle control to activate stunt mode. The remote control beeps repeatedly.
2. Use the steering control to perform stunts:
 - Front flip: Move steering forward
 - Back flip: Move steering backward
 - Barrel roll: Move steering right or left
3. The drone automatically exits stunt mode after performing a stunt, or push in the throttle control again to exit immediately.

Dogfight!

Battle with a friend. You will shoot deadly infrared need to fly within close range missiles. Each player has 3 lives per challenge. First drone to lose all 3 lives goes down!



Lithium Battery Notes

Your drone uses a built-in lithium polymer battery for power. Follow the instructions for charging.

- Do not charge longer than recommended. Unplug the charging cable when the drone is charged.
- Do not puncture or crush. Do not disassemble.
- Do not dispose of lithium batteries in the trash.
- If the electrolyte in the cells should get on your skin, thoroughly wash with soap and water. If in the eyes, rinse thoroughly with cool water. Immediately seek medical attention.
- Do not attempt to charge or operate damaged toys.

Install Batteries in the Remote Control

1. On the remote control, set the ON/OFF switch to OFF



2. Use a screwdriver to open the twin battery compartments. Then insert four AAA batteries (not included), matching the polarities (+ and -) marked inside. Replace the cover.

Note: If the remote control's LED flashes during use, the batteries are low and should be replaced.


Battery Notes

- Dispose of old batteries promptly and properly. Do not burn or bury them. Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- Remove batteries during longer storage periods. Batteries can leak chemicals that can damage electronic parts.

Replace Damaged Propellers

The left and right propellers, marked A/B on the propeller, of the drone are different, and you must use the correct propeller in the correct location.

To replace a damaged propeller, remove the old one and press the new one onto the propeller axle. If you cannot remove the old propeller by hand, use pliers.



WARNING:

- To avoid injury and damage, check the propellers for nicks and breaks and make sure they are securely attached before and after each flight. Replace any damaged propellers.
- Use only the supplied propellers. Do not alter, modify, or customize the propellers.

Troubleshooting Drone does not respond

WARNING:

- Make sure the drone and remote control are switched on and paired.
- Avoid pairing both drones at the same time within 10 feet as this causes interference. Pair each drone with its matching remote control individually.
- Drone battery may be low. Fully charge the battery. See "Charge the Drone."
- Remote control batteries may be low. Replace the batteries.
- Make sure the drone is within the control range (65 ft) and in line of sight.
- In battle mode, make sure you fly within IR range (16 ft), and level with your opponent to shoot. Stage your battles indoors to avoid strong sunlight which affects IR reception.



Pairing

Switch on and pair one drone and remote control at a time.

1. Turn on the drone. The drone's LEDs flash.
2. Place the drone on level ground.
3. Turn on the remote control. The remote control's LED flashes.
4. Move the throttle all the way up and then down to pair the remote control with the drone. The drone's propellers remain still during pairing. When paired, the LEDs on both the remote control and drone light steadily.

Note: If pairing fails, turn off the drone and remote control and repeat the steps above, or change locations to avoid interference.

Fly Your Drone

1. After pairing, press the steering control to switch between high speed (double beep) and low speed (single beep).

2. Press the (Take off) button or push the throttle up, the drone will take off and hover forward to fly. The drone adjusts itself automatically and flies stably.
3. To land your drone, press the (Land) button or slowly move the throttle backward to descend. Avoid moving the throttle too quickly, as that can stop the blades instantly and cause the drone to crash.
4. When you finish playing, disconnect and remove the drone battery and turn off the transmitter.

Trim Your Drone

Move the throttle forward and see how the drone reacts.

- Reverse/Forward Movement Trim: If the drone tends to move forward, press >; if it tends to move backward, press <.
- Left/Right Slide Trim: If the drone tends to slide right, press <; if it tends to slide left, press >.

Note: The remote control beeps when you press a trim control, but stops beeping when you reach maximum trim adjustment.

Drone difficult to control

- The throttle control is very sensitive. Use small, fine movements to control.
- Propellers may be bent. Adjust propellers by hand. If you cannot adjust them, replace with the spare propellers.
- Practice in low speed mode. See "Fly Your Drone."
- The gyroscope inside your drone may need calibrating:

Calibrate Your Drone

1. With your drone and remote control switched on and paired, place the drone on level ground.
 2. Move the throttle all the way down.
 3. Move the steering forward and hold this position for a few seconds until the drone LEDs start to blink.
 4. Release the steering. The drone LEDs light steadily, indicating successful calibration. You are now ready for takeoff.
- See "Trim Your Drone" to fine tune hovering and movement to further improve control of your drone after calibration.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Made in China Version : 20180806001

