



**Brook**  Brook Gaming

**ZEROPLUS TECHNOLOGY**

[www.brookaccessory.com](http://www.brookaccessory.com)

Visit our website for more information and assistance

Copyright © Zeroplus Technology Co., Ltd. All Rights Reserved.  
Brook is the registered trademark of Zeroplus Technology Co.,  
Ltd. ©2016 Nintendo, Inc. ©2016 Pokémon. ©1996-2016  
Nintendo / Creatures Inc. / GAME FREAK Inc. Pokémon® and  
Pokémon character names are trademarks of Nintendo. The  
Google Maps Pin is a trademark of Google Inc. All rights  
reserved. This Product is not sponsored, endorsed, or approved  
by Nintendo, The Pokémon Company Or Niantic.

**SUPPORT**



Made in Taiwan



## Pairing Connection

1. Turn on your mobile Bluetooth.



2. Tap the Main Menu.




3. Tap Settings.



4. Select Pokémon GO Plus in setting page. Pocket Auto Catch Lightning will start to pair automatically.

Unpaired ID ▶  **Green Light flashes**

Paired ID ▶  **Blue Light flashes**



5. Waiting for pairing. When the Pokémon GO Plus icon turns on, it means pairing is successful.

Not connected





Successful connection



Connected to Pokémon GO

## How to switch between Function Modes

Short press the button to switch between the two function modes.




- ▶  **Mode 1: Blue Light**  
Clear Bluetooth Pairing ID
- ↓
- ▶  **Mode 2: Green Light**  
Vibration on / off



### Reset to factory settings:

1. Hold button
2. Insert the charger cable and connect to a USB charger port.

## Function Modes Description

-  **Mode 1: Blue Light: Clear Bluetooth Pairing ID**  
Long press the button for 3 seconds  
▼  
Execute clearing ID   Green and Red flashing  
(Please wait 11-20 seconds when clearing ID)

Clear successful:

-  Blue Light flashes 3 times

Clear failed:

-  Red Light flashes 3 times

-  **Mode 2: Green Light: Vibration on / off**

Long press the button for 3 seconds

Vibration on:

-  Green Light flashes 3 times

Vibration off:

-  Red Light flashes 3 times




Situation	LED	Vibration
Low Power	● <b>flashing</b>	×
Waiting for connection	● <b>flashing</b> (unpaired)	<ul style="list-style-type: none"> <li>● 0 ~3 minutes: Vibrate 2 times for every 10 seconds.</li> <li>● 3 ~ 10 minutes: Vibrate 2 times for every 30 seconds.</li> <li>● Stop warning after 10 minutes.</li> <li>● If the situation is "Intermittent ", vibrate 3 times instead of 2.</li> </ul>
	● <b>flashing</b> (paired)	
No internet connection	● intermittent	
Items are full	○ White	<ul style="list-style-type: none"> <li>● Vibrate 2 times for every 2 seconds.</li> <li>● Stop after 3 cycles.</li> </ul>
Out of Pokéball	● <b>flashing 3 times</b>	
Pokémon up to maximum/ Far away from Pokéstop	● <b>Permanently on</b>	

### Charge your Device

- When charging Pocket Auto Catch Lightning, 3 colors (red, green, blue) will flash repeatedly.
- When the power is full, Pocket Auto Catch Lightning will display a white light.

When you are playing Pokémon Go, there will be no vibration.



## Warning

When it not used over a long period of time, the rechargeable battery may enter the protection mode and cannot be charged smoothly. You can activate the rechargeable battery by pressing and holding the button, then plugging and unplugging the USB charger several times until the white LED flashes, and then releasing the button.

Pocket Auto Catch Lightning may fail to pair to device because of the update of Pokémon Go app, or the upgrade of Android and iOS.

Pocket Auto Catch Lightning will time out automatically every hour, so players have to reconnect it.

Pocket Auto Catch Lightning will time out every 3-5 minutes if the mobile is idle.

Better keep it among -20°C ~ 45°C.

Suggested charging temperature: 10°C ~ 35°C.

Device requires Bluetooth low-energy compatible smartphone with Pokémon GO app installed. Compatible with iPhone 6S or higher devices with iOS Ver. 12 or higher version installed.

Compatible with Android devices with 4 GB RAM or more.

Bluetooth Smart (Bluetooth Ver. 4.0 or higher) capability and Android Ver. 7.0 or higher version installed.

This Product is not sponsored, endorsed, or approved by Nintendo, The Pokémon Company or Niantic.



## Brook Product Warranty

- ▶ Within one year from purchase date, Brook offers the product warranty with normal operating circumstances and non-human damage. It includes free maintenance and return.
- ▶ The following conditions are not included in the warranty service: natural disasters, customer induced damage, improper operation, and repaired by non-Brook authorized staff.
- ▶ Please be sure to keep both **Warranty card** and **Retailer invoice**. These two documents are necessary to guarantee a return.

### Product Name / Product Number

---

**Date of Purchase** \*Warranty Period : 1 year

\_\_\_\_ / \_\_\_\_ / \_\_\_\_  
Date                      Month                      Year

If the purchase or invoice dates are incorrect or unrecognized, the warranty service is unavailable.

## Warning

### Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.