Function Buttons Description

Golf/Sport Watch **Quick Start Guide**






Hold "Power" button for 2-3 seconds to turn On / Off



Changing the Clock Face




Golf / Running / Cycling / Swimming Mode



Steps / Mileage / Calories / Bluttooth Button



How to Charging



Battery / Charging Information

Battery Specifications: 3.7V / 450mAh Charging Specifications: 5V / 500mA

Please use the 5V output USB charger must comply with the CE directive and standards. This warranty does not cover any damage or defects sustained on the device as a result of an non-certified

ボタンの機能説明

ゴルフ・トライアスロン ウォッチ クイック スタート ガイド








電源ボタンを2~3秒押すとオン/オフ

文字盤を変更する




ゴルフ / ランニング / サイクリング / スイミング / トラ<mark>イアロン モード</mark>



ステップ/マイル数/カロリー/Bluetooth ボタン



充電方法



バッテリー / 充電 仕様

バッテリー: 3.7V / 450mAh、充電: 5V / 500mA



「CE認証」に準拠したDC5V出力充電器を使用して ください。「非CE認証のDC 5V充電器」が製品に 損傷をうければ、弊社は無償保証責任を免れること

高爾夫三鐵錶 **Golf/Sport Watch**



快速使用手册 **Quick Start Guide**

按鍵基本功能



按住電源鍵2~3秒開/關機



時間面盤切換



高尔夫三铁表 **Golf/Sport Watch**



快速使用手册 **Quick Start Guide**

按键基本功能



按住电源键2~3秒开/关机



时间面盘切换



高爾夫/跑步/自行車/訓練 模式




















高尔夫/跑步/自行车/训练 模式




















計步/里程/卡路里/藍芽開關






電池/充電資訊

電池規格: 3.7V / 450mAh; 充電規格: 5V / 500mA

計步/里程/卡路里/藍芽開關



充电方法



电池/充电资讯

电池规格: 3.7V / 450mAh; 充电规格: 5V / 500mA



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.