


## USER MANUAL FOR RGBW PUCK LIGHT KIT

Please read the instructions before assembling and using your new LED puck light kit.

**NOTICE: FOR INDOOR AND DRY LOCATION USE ONLY. ADHENSIVE TAPE MAY DAMAGE SURFACE WHEN REMOVE IT.**

### PARTS:



### INSTALLATION

Before installation, make sure the surface you intend to install is free of moisture, oil, grease, dust and dirt to ensure proper adhesive. Careful, the adhesive tape may damage the painted surface when removing.


#### STEP 1

Install the puck light. Mark the target place where you want to install. Remove one side of the tape and stick to the LED puck light. Then remove the other side of the tape and stick to the place you want to install. Remove one side of the double sided tape and secure to the sensor.




#### STEP 2

Use the same way to install the controller.



### STEP 3

Connect the plug in adapter connector to the puck light. Then connect the adapter to the adaptor connector by inserting the jack on the adapter.



### STEP 4

Plug the AC/DC adapter into the power supply, the LED puck light is ready to work.

### STEP 5

Control the puck light by remote control.



RC700 remote

### CAUTION

To reduce the risk of fire, electric shock or injury to persons:

- 1) Use only insulated staples or plastics ties to secure cords
- 2) Route and secure cords so that they will not be pinched or damaged when the cabinet is pushed to wall;
- 3) Position the portable cabinet light with respect to the cabinet so the lamp replacement marking are able to be read during re-lamping;
- 4) Not intended for recessed installation in ceiling, or soffits; and
- 5) The National Electrical Code (NEC) does not permit cords to be concealed where damage to insulation may go unnoticed. To prevent fire danger, do not run cords behind walls, ceiling, soffits, or cabinets where it may be inaccessible for examination. Cords should be visually examined periodically and immediately replaced when any damage is noted.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

*This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:*

- (1) This device may not cause interference; and*
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.*

*Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*