

# Connection Instruction

## Pair & Connect: Press Y and Home Button Simultaneously

**Step 1:** Find Controllers Option→Click Change Grip/Order.- Image 1/ Image 2

**Step 2:** Press and hold the Y and HOME button simultaneously, until the 4 LED lights flash in turn for 2 seconds, then release your finger and waiting for the connection to complete.- Image 3

**\*NOTE:** Enter the Change Grip/Order page, please complete the connection within 30 seconds as soon as possible. If you stay on this page for too long, you may not be able to connect to the NS console. - Image 3



**Image 1**



**Image 2**



**Image 3**

## Reconnect (Home)

### Reconnect: Press Home Button

If your controller was once paired and connected to your NS console, next time you can press the Home Button to make it to be rapidly connected.

### Note:

For reconnecting, please turn on the NS console first, does not support press Home button to wake up the console under standby mode.

### Unable to connect, please follow under three steps to solve:


1. Turn off airplane mode.
2. Delete the information of this controller and sensors-disconnect controllers.
3. Follow the first time connection method and re-pair again.

## Adjust Turbo Speed

Buttons can be set to the turbo speed(is called for short function

**buttons):** A/B/X/Y/L/ZL/R/ZR button

### **Enable/disable the manual and auto turbo speed function:**

**Step1:** Press the  button and one of the function button simultaneously, to enable the manual turbo speed function.

**Step 2:** Repeat the step 1, to enable the auto turbo speed function.

**Step 3:** Repeat the step 1 again, to disable the manual and auto turbo speed function of this button.

**Disable all the button's turbo speed function:** Press “-” button and the down button of direction button simultaneously.


### **There are 3 levels of turbo speed:**

Minimum: 5 shoots per-second, the corresponding channel light flash slowly.


Moderate: 12 shoots per-second, the corresponding channel light flash at a moderate rate.

Maximum: 20 shoots per-second, the corresponding channel light flash quickly.

### **How to increase the turbo speed:**

When the manual turbo function is on, upward the right joystick meanwhile press the  button for 5 seconds, which can increase one level of turbo speed.

### **How to decrease the turbo speed:**

When the manual turbo function is on, downward the right joystick meanwhile press the  button for 5 seconds, which can decrease one level of turbo speed.

## **Adjust Vibration Intensity**

There are 4 levels of vibration intensity: 100%-70%-30%-0%(no vibration)

### **How to increase the vibration intensity:**

Press the “+” button and the up button of direction button simultaneously for 5 seconds, which can increase one level of vibration intensity.

### **How to decrease the vibration intensity:**

Press the “-” button and the up button of direction button simultaneously for 5 seconds, which

can decrease one level of vibration intensity.

**FCC Caution :**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.