

TECKNET

M006 Wireless Mouse




Note:
German and French language user manuals can be downloaded from our website: www.tecknet.co.uk.

Welcome

Thank you for purchasing this TeckNet product. To ensure optimum performance and safety, please read these instructions carefully before operating the product. It is strongly recommended you keep this manual for future reference.

Product Layout



Technical Specifications

Button Count:	6 buttons
Operating Frequency:	2.4GHz
Resolution:	800/1200/1600/2000/2400DPI, Default 1200DPI
Receiver Interface:	USB version 2.0
Battery Type:	2 x AA Batteries
Battery Life:	18 months
Operating Voltage:	3.0V
Operating Current:	<4 mA
Stand by Current:	< 0,8mA
Sleep Current:	0.05mA
Sensor:	A3000
MCU:	MA3802-3
Distance:	10M

01

Package Contents

- 1 x M006 Cordless Mouse
- 1 x USB Nano Receiver
- 1 x User Manual
- 1 x Warranty Card

Note: Batteries NOT included

System Requirements

To use this mouse, your computer must meet the following hardware requirements and run one of the operating systems listed below.

Hardware

- PC with a Pentium processor or equivalent AMD processors
- USB 2.0

Operating System

- Windows 2000, 2003, XP, Vista, Win7, Win8, Win8.1, Win10

Note: The scroll wheel only works under the operating systems listed above. If you use the mouse under a different operating system, the mouse may either not work or lose its enhanced features.

Instructions

Battery Installation

The M006 optical mouse uses two AA batteries (not included).

1. Open the battery cover.
2. Insert the batteries into the compartment, ensuring they correspond with the polarity marking.
3. Replace the battery cover.
4. Switch on the mouse by adjusting the power switch underneath the mouse. The red LED of the power indicator at the top of the mouse will flash.

Note: Make sure that the polarity of the batteries is correct. The positive (+) and negative (-) ends of each battery must match the positive (+) and negative (-) markings in the battery housing.

02



18-Month Battery Life


The mouse consumes little power and offers a long battery life of up to 18 months without changing battery. However please note that the actual battery life may vary based on user and computing conditions.

Receiver Connection

Take out USB Nano receiver and plug it into a free USB port in your computer. The Plug & Play function of your system will detect that a new device has been connected and install it automatically.



Note: The receiver can be removed and stored in the battery compartment while not in use.



Take out the receiver

Store the receiver

03

Intelligent Power Saving (IPS)

The mouse is equipped with Intelligent Power Saving (IPS) function.

- When the USB Nano receiver is disconnected or the PC is switched off, the mouse will be switched off automatically for the purpose of power-saving.
- When your mouse is not operated for 10 seconds, it will automatically drop to the first level of IPS. To wake the mouse, click any button.
- When your mouse is not operated for 8minutes, it will automatically drop to the second level of IPS. To wake the mouse, click any button.

DPI Switch

The mouse supports five levels DPI: 800/1200/1600/2000/2400DPI. The default DPI is 1200.

Press the DPI button, DPI will raise to 1600, LED indicator will flash three times. Press the DPI button for each time, the DPI will raise to next level, and the DPI LED light will flash one more time.



DPI Switch

Low Battery Power Indicator

The mouse is equipped with low power indicator. When the battery power gets low during the period of use, the Indicator under the Scroll wheel will flash. Please replace the battery.

Note: We recommend you use AA alkaline dry cell battery.



Low Power Indicator

04

Reconnection

There is a connection code for this Mouse. High temperatures, electro-magnetic fields or vibration may influence the code signal and the Mouse may need to be reconnected. Both Mouse and Nano Receiver have a built-in code and one Mouse can be connected to one receiver, or several Mice to one Nano Receiver. The Mouse and Nano Receiver may need to be reconnected if subjected to high temperature, electromagnetic fields or strong vibrations.

1. Ensure the battery voltage is correct; if the voltage is low, replace the batteries.
2. Press the right button and middle button (under the scroll wheel) simultaneously (Do not release both buttons until you have completed step 3).
3. Plug the USB Nano receiver into a free USB port of your computer within 15 seconds.
4. Then release both buttons.

Attention

- 1.To maximize battery life, it is recommended to use the mouse on a white or light color surface.
- 2.If not used, the mouse will drop into auto-sleeping mode within 3 seconds. Press any key or scroll wheel to activate the mouse.
- 3.Do not use the mouse on a glass or mirrored surface, as these surfaces will cause the mouse to fail temporarily.
- 4.The mouse might not work smoothly on some special surfaces, such as smooth, dark or black, reflecting and 3D mouse pads surfaces.
- 5.Avoid using the mouse on a metal surface. Metals, such as iron, aluminum or copper, shield the radio frequency transmission and may slow down the mouse presenter's response time or cause the mouse to fail temporarily.
- 6.If your PC has a metal case that contains aluminum or magnesium, use the mouse to the side. The display panel may interfere with the radio frequency signal if you use the mouse directly in front of the PC.

FAQ

1.What should I do if the mouse does not work?

- Make sure that the polarity of the batteries is correct. The positive (+) and negative (-) ends of each battery must match the positive (+) and negative (-) markings in the battery housing.

05

- Make sure the batteries are not discharged.
- Please try to remove the batteries, and reinstall the batteries again.
- Verify that your computer's power management features are turned off.
- Check the Nano receiver's USB connector is firmly attached to the USB port of your computer.

- 2.The USB Nano receiver is recognized by Windows (2000, 2003, XP, Vista, Win7, Win8, Win8.1, Win10) but the cursor does not move?
- Check whether the low power indicator on the top of the mouse lights up. If the sensor lights up, it is likely that the batteries are discharged. Please replace them.
 - If replacing the batteries does not help, it is likely that the mouse is not connected to the receiver. Please try reconnection and ensure that the mouse is within the optimal operational working distance (1.5m) from its USB Nano receiver.

Warning

Please read all instructions and warnings prior to using this product for the first time. Failure to read and follow these safety and usage instructions could result in fire, explosion, electric shock or other hazard that could potentially cause property damage or even fatal injury.

- Keep the mouse and batteries out of the reach of children.
- Replace old or weak batteries promptly.
- Remove the batteries if the mouse is not going to be used for a long period of time.
- Do not disassemble, adjust or repair the mouse which may result in exposure or safety hazards.

Disclaimer

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned herein.

Warranty

We warrant that products purchased from authorized distributors will meet the applicable product specifications and be free from all defects in design, assembly, materials and workmanship. Please contact retailers or visit our website www.tecknet.co.uk for more information.

06

TECKNET

TeckNet
P.O. BOX 122
Liverpool
L9 7WQ
www.tecknet.co.uk

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.